# OMRON

## **Sysmac Library**

User's Manual for RFID Communications Library SYSMAC-XR019



#### NOTE

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form, or by any means, mechanical, electronic, photocopying, recording, or otherwise, without the prior written permission of OMRON.

No patent liability is assumed with respect to the use of the information contained herein. Moreover, because OMRON is constantly striving to improve its high-quality products, the information contained in this manual is subject to change without notice. Every precaution has been taken in the preparation of this manual. Nevertheless, OMRON assumes no responsibility for errors or omissions. Neither is any liability assumed for damages resulting from the use of the information contained in this publication.

#### - Trademarks -

- Sysmac and SYSMAC are trademarks or registered trademarks of OMRON Corporation in Japan and other countries for OMRON factory automation products.
- Microsoft, Windows, Windows Vista, Excel, and Visual Basic are either registered trademarks or trademarks of Microsoft Corporation in the United States and other countries.
- EtherCAT® is registered trademark and patented technology, licensed by Beckhoff Automation GmbH, Germany.
- ODVA, CIP, CompoNet, DeviceNet, and EtherNet/IP are trademarks of ODVA.

• The SD and SDHC logos are trademarks of SD-3C, LLC.



Other company names and product names in this document are the trademarks or registered trademarks of their respective companies.

#### Copyrights

Microsoft product screen shots reprinted with permission from Microsoft Corporation.

## Introduction

Thank you for purchasing an NJ/NX-series CPU Unit and NY-series Industrial PC.

This manual provides information required to use the function blocks in the NX-series RFID Unit NX-V680C<sup>[]</sup>. ("Function block" is sometimes abbreviated as "FB".) Please read this manual and make sure you understand the functionality and performance of the NJ/NX-series CPU Unit before you attempt to use it in a control system.

This manual provides function block specifications. It does not describe application restrictions or combinationrestrictions for Controllers, Units, and components.

Refer to the user's manuals for all of the products in the application before you use any of the products.

Keep this manual in a safe place where it will be available for reference during operation.

### Features of the Library

The RFID Communications Library provides a function for reading/writing the memory of RF Tag when performing production management based on individual recognition by using an NJ/NX-series CPU Unit, an NY-series Industrial PC, and an NX-series RFID Unit NX-V680C. Using the RFID Communications Library allows you reduce the programming works during the implementation of the processing of the RFID Unit.

### **Intended Audience**

This manual is intended for the following personnel,

who must also have knowledge of electrical systems (an electrical engineer or the equivalent).

- · Personnel in charge of introducing FA systems.
- Personnel in charge of designing FA systems.
- Personnel in charge of installing and maintaining FA systems.
- · Personnel in charge of managing FA systems and facilities.

For programming, this manual is intended for personnel who understand the programming language specifications in international standard IEC 61131-3 or Japanese standard JIS B 3503.

## **Applicable Products**

This manual covers the following products.

Item	Product name	Model	Version
Sysmac Library	NX-V680 Library	SYSMAC-XR019	Version 1.0.0 or later
Automation software	Sysmac Studio	SYSMAC-SE	Version 1.23 or later
Devices	CPU Unit	NX701-□□□	Version 1.18 or later
		NJ101-□□□	
		NJ501-□□□	Version 1.18 or later
		NJ301-□□□	
		NX1P2-00000(1)	Version 1.18 or later
		NX102-□□□	Version 1.30 or later
	Industrial PC	NY500-100	Version 1.18 or later
	NX-series RFID Unit	NX-V680C	Version 1.0 or later

## **Manual Structure**

### lcon

Special information in this manual is classified as follows:



#### Precautions for Safe Use

Precautions on what to do and what not to do to ensure safe usage of the product.



#### **Precautions for Correct Use**

Precautions on what to do and what not to do to ensure proper operation and performance.



#### Additional Information

Additional information to read as required.

This information is provided to increase understanding or make operation easier.



#### **Version Information**

Information on differences in specifications and functionality for CPU Units and Industrial PCs with different unit versions and for different versions of the Sysmac Studio are given.

References are provided to more detailed or related information.

## CONTENTS

Introduction	
Features of the Library	
Intended Audience	
Applicable Products	1
Manual Structure	2
lcon	
	۷۲
CONTENTS	4
Terms and Conditions Agreement	c
Warranty, Limitations of Liability Application Considerations	
Application Considerations Disclaimers	
Disclaimers	
Safety Precautions	8
Definition of Precautionary Information	
Symbols	
Caution	
Precautions for Correct Use	10
Related Manuals	11
Revision History	15
Procedure to Use Sysmac Libraries	17
Procedure to Use Sysmac Libraries Installed Using the Installer	
Procedure to Use Sysmac Libraries Uploaded from a CPU Unit or an Industrial PC	
Procedure to Use Sysmac Libraries Uploaded from a CPU Unit or an Industrial PC	
	25
Procedure to Use Sysmac Libraries Uploaded from a CPU Unit or an Industrial PC Common Specifications of Function Blocks	<b>25</b> 
Procedure to Use Sysmac Libraries Uploaded from a CPU Unit or an Industrial PC Common Specifications of Function Blocks Common Variables Precautions	<b>25</b> 
Procedure to Use Sysmac Libraries Uploaded from a CPU Unit or an Industrial PC Common Specifications of Function Blocks Common Variables Precautions. Individual Specifications of Function Blocks	25 
Procedure to Use Sysmac Libraries Uploaded from a CPU Unit or an Industrial PC Common Specifications of Function Blocks Common Variables Precautions Individual Specifications of Function Blocks Common Data Types for All Function Blocks	25 
Procedure to Use Sysmac Libraries Uploaded from a CPU Unit or an Industrial PC Common Specifications of Function Blocks Common Variables Precautions. Individual Specifications of Function Blocks	25 
Procedure to Use Sysmac Libraries Uploaded from a CPU Unit or an Industrial PC Common Specifications of Function Blocks Precautions Individual Specifications of Function Blocks Common Data Types for All Function Blocks ReadData_V680 WriteData_V680	25 26 31 33 33 34 36 59
Procedure to Use Sysmac Libraries Uploaded from a CPU Unit or an Industrial PC Common Specifications of Function Blocks Ormon Variables Precautions Individual Specifications of Function Blocks Common Data Types for All Function Blocks ReadData_V680 WriteData_V680 Appendix	25 26 31 33 33 34 36 59 
Procedure to Use Sysmac Libraries Uploaded from a CPU Unit or an Industrial PC Common Specifications of Function Blocks Precautions Individual Specifications of Function Blocks Common Data Types for All Function Blocks ReadData_V680 WriteData_V680	25 26 

## **Terms and Conditions Agreement**

## Warranty, Limitations of Liability

## Warranties

#### Exclusive Warranty

Omron's exclusive warranty is that the Products will be free from defects in materials and workmanship for a period of twelve months from the date of sale by Omron (or such other period expressed in writing by Omron). Omron disclaims all other warranties, express or implied.

### Limitations

OMRON MAKES NO WARRANTY OR REPRESENTATION, EXPRESS OR IMPLIED, ABOUT NON-INFRINGEMENT, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OF THE PRODUCTS. BUYER ACKNOWLEDGES THAT IT ALONE HAS DETERMINED THAT THE PRODUCTS WILL SUITABLY MEET THE REQUIREMENTS OF THEIR INTENDED USE.

Omron further disclaims all warranties and responsibility of any type for claims or expenses based on infringement by the Products or otherwise of any intellectual property right.

#### Buyer Remedy

Omron's sole obligation hereunder shall be, at Omron's election, to (i) replace (in the form originally shipped with Buyer responsible for labor charges for removal or replacement thereof) the non-complying Product, (ii) repair the non-complying Product, or (iii) repay or credit Buyer an amount equal to the purchase price of the non-complying Product; provided that in no event shall Omron be responsible for warranty, repair, indemnity or any other claims or expenses regarding the Products unless Omron's analysis confirms that the Products were properly handled, stored, installed and maintained and not subject to contamination, abuse, misuse or inappropriate modification. Return of any Products by Buyer must be approved in writing by Omron before shipment. Omron Companies shall not be liable for the suitability or unsuitability or the results from the use of Products in combination with any electrical or electronic components, circuits, system assemblies or any other materials or substances or environments. Any advice, recommendations or information given orally or in writing, are not to be construed as an amendment or addition to the above warranty.

## Limitation on Liability; Etc

OMRON COMPANIES SHALL NOT BE LIABLE FOR SPECIAL, INDIRECT, INCIDENTAL, OR CON-SEQUENTIAL DAMAGES, LOSS OF PROFITS OR PRODUCTION OR COMMERCIAL LOSS IN ANY WAY CONNECTED WITH THE PRODUCTS, WHETHER SUCH CLAIM IS BASED IN CONTRACT, WARRANTY, NEGLIGENCE OR STRICT LIABILITY.

Further, in no event shall liability of Omron Companies exceed the individual price of the Product on which liability is asserted.

## **Application Considerations**

## Suitability of Use

Omron Companies shall not be responsible for conformity with any standards, codes or regulations which apply to the combination of the Product in the Buyer's application or use of the Product. At Buyer's request, Omron will provide applicable third party certification documents identifying ratings and limitations of use which apply to the Product. This information by itself is not sufficient for a complete determination of the suitability of the Product in combination with the end product, machine, system, or other application or use. Buyer shall be solely responsible for determining appropriateness of the particular Product with respect to Buyer's application, product or system. Buyer shall take application responsibility in all cases.

NEVER USE THE PRODUCT FOR AN APPLICATION INVOLVING SERIOUS RISK TO LIFE OR PROPERTY WITHOUT ENSURING THAT THE SYSTEM AS A WHOLE HAS BEEN DESIGNED TO ADDRESS THE RISKS, AND THAT THE OMRON PRODUCT(S) IS PROPERLY RATED AND INSTALLED FOR THE INTENDED USE WITHIN THE OVERALL EQUIPMENT OR SYSTEM.

## **Programmable Products**

Omron Companies shall not be responsible for the user's programming of a programmable Product, or any consequence thereof.

### **Disclaimers**

## Performance Data

Data presented in Omron Company websites, catalogs and other materials is provided as a guide for the user in determining suitability and does not constitute a warranty. It may represent the result of Omron's test conditions, and the user must correlate it to actual application requirements. Actual performance is subject to the Omron's Warranty and Limitations of Liability.

## **Change in Specifications**

Product specifications and accessories may be changed at any time based on improvements and other reasons. It is our practice to change part numbers when published ratings or features are changed, or when significant construction changes are made. However, some specifications of the Product may be changed without any notice. When in doubt, special part numbers may be assigned to fix or establish key specifications for your application. Please consult with your Omron's representative at any time to confirm actual specifications of purchased Product.

## **Errors and Omissions**

Information presented by Omron Companies has been checked and is believed to be accurate; however, no responsibility is assumed for clerical, typographical or proofreading errors or omissions.

## **Safety Precautions**

## **Definition of Precautionary Information**

The following notation is used in this user's manual to provide precautions required to ensure safe usage of an NJ/NX-series CPU Unit and NY-series Industrial PC.

The safety precautions that are provided are extremely important to safety. Always read and heed the information provided in all safety precautions.

The following notation is used.

	Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury. Addi- tionally, there may be severe property damage.
▲ Caution	Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury, or prop- erty damage.

## **Symbols**

-

\_

	The circle and slash symbol indicates operations that you must not do.
	The specific operation is shown in the circle and explained in text.
	This example indicates prohibiting disassembly.
Λ	The triangle symbol indicates precautions (including warnings).
/公	The specific operation is shown in the circle and explained in text.
	This example indicates a precaution for electric shock.
Λ	The triangle symbol indicates precautions (including warnings).
	The specific operation is shown in the circle and explained in text.
$\sim$	This example indicates a general precaution.
	The filled circle symbol indicates operations that you must do.
	The specific operation is shown in the circle and explained in text.
	This example shows a general precaution for something that you must do.

## Caution

A WARNING	
The Sysmac Library and manuals are assumed to be used by personnel that is given in Intended Audience in this manual. Otherwise, do not use them.	$\bigwedge$
Read all related manuals carefully before you use this library.	$\underline{\land}$
Emergency stop circuits, interlock circuits, limit circuits, and similar safety measures must be provided in external control circuits.	$\underline{\land}$
To ensure that the actual device operates as intended, check the user program, data, and parameter settings for proper execution before you use them for actual opera- tion.	$\underline{\land}$
You must confirm that the user program and parameter values are appropriate to the specifications and operation methods of the devices.	$\underline{\land}$
The sample programming shows only the portion of a program that uses the function or function block from the library.	
Understand the contents of sample programming before you use the sample pro- gramming and create the user program.	$\underline{\land}$

## **Precautions for Correct Use**

## Using the Library

- When you use the library, functions or function blocks that are not described in the library manual may be displayed on the Sysmac Studio. Do not use functions or function blocks that are not described in the manual.
- You cannot change the source code of the functions or function blocks that are provided in the library.
- Do not turn OFF the power supply to the Controller or the Communications Coupler Unit or stop communications until the processing for the function blocks provided in the library ends normally or ends in an error.

## Using Sample Programming

- The sample programming shows only the portion of a program that uses the function or function block from the library.
- Create a user program so that the actual device operates as intended.
- Check the user program for proper execution before you use it for actual operation.

## **Related Manuals**

Manual name	Cat. No.	Model numbers	Application	Description
NX-series	Z401	NX-V680C	Learning how to use NX-series	The hardware, setup methods,
RFID Units			RFID Units.	and functions of the NX-series
User's Manual				RFID Units are described.
V680-series	Z248	V680-HA63B	Learning about the specifica-	The general specifications,
RF Tags and		V680-HS□□	tions, performance, and instal-	communications specifications,
Amplifiers		V680-H01-V2	lation of the V680-series RF tags and amplifiers (FRAM	and installation method of the V680-series RF tags and ampli-
(FRAM Type)		V680-D2K	type).	fiers (FRAM type) are
User's Manual		V680-D8K	-7F - 7	described.
		V680S-D2K		
		V680S-D8K		
V680-series	Z262	V680-HA63A	Learning about the specifica-	The general specifications,
RF Tags and		V680-HS□□	tions, performance, and instal-	communications specifications,
Amplifiers		V680-H01-V2	lation of the V680-series RF	and installation method of the
(EEPROM Type)		V680-D1KP	tags and amplifiers (EEPROM type).	V680-series RF tags and ampli- fiers (EEPROM type) are
User's Manual				described.
NX-series	W525	NX-00000	Referencing lists of the data	Lists of the power consump-
Data Reference			that is required to configure sys-	tions, weights, and other NX
Manual			tems with NX-series Units	Unit data that is required to con- figure systems with NX-series
				Units are provided.
NX-series	W523	NX-PD1	Learning how to use NX-series	The hardware and functions of
System Units		NX-PF0	System Units	the NX-series System Units are
User's Manual		NX-PC0		described.
		NX-TBX01		
Sysmac Studio	W504	SYSMAC-	Learning about the operating	Describes the operating proce-
Version 1		SE2	procedures and functions of the	dures of the Sysmac Studio.
Operation			Sysmac Studio	
Manual				
NX-IO Configura-	W585	CXONE-	Learning about the operating procedures and functions of the	Describes the operating proce-
tor		ALOD-V4	NX-IO Configurator.	dures of the NX-IO Configura- tor.
Operation Manual			line comganatori	
NJ/NX-series	W503	NX701-□□□	Learning about the errors that	Concepts on managing errors
Troubleshooting	11000	NJ501-□□□□	may be detected in an	that may be detected in an
Manual			NJ/NX-series Controller	NJ/NX-series Controller and
		NJ301-□□□		information on individual errors
		NJ101-□□□		are described.
		NX1P2-	Les minuels suit 0 0 1	Ormaneta en ma
NY-series	W564	NY532-□□□	Learning about the errors that may be detected in an	Concepts on managing errors that may be detected in an
Troubleshooting Manual		NY512-□□□	NY-series Industrial PC	NY-series Controller and infor-
waruar				mation on individual errors are
				described.

The following table shows related manuals. Use these manuals for reference.


Manual name	Cat. No.	Model numbers	Application	Description
NX-series EtherCAT® Coupler Unit User's Manual	W519	NX-ECC20□	NX-series Learning how to use the Ether- CAT Coupler Unit and Ether- CAT Slave Terminals.	The following items are described: the overall system and configuration methods of an EtherCAT Slave Terminal (which consists of an NX-series EtherCAT Coupler Unit and NX Units), and information on hard- ware, setup, and functions to
NX-series EtherNet/IP <sup>TM</sup> Coupler Unit User's Manual	W536	NX-EIC202	Learning how to use an NX-series EtherNet/IP Coupler Unit and EtherNet/IP Slave Ter- minals	ware, setup, and functions to set up, control, and monitor NX Units through EtherCAT. The following items are described: the overall system and configuration methods of an EtherNet/IP Slave Terminal (which consists of an NX-series EtherNet/IP Coupler Unit and NX Units), and information on hardware, setup, and functions to set up, control, and monitor NX Units.
NX-series CPU Unit Hardware User's Manual	W535	NX701-□□□	Learning the basic specifica- tions of the NX-series NX701 CPU Units, including introduc- tory information, designing, installation, and maintenance. Mainly hardware information is provided.	<ul> <li>An introduction to the entire NX701 CPU Unit system is pro- vided along with the following information on the CPU Unit.</li> <li>Features and system configu- ration</li> <li>Overview</li> <li>Part names and functions</li> <li>General specifications</li> <li>Installation and wiring</li> <li>Maintenance and inspection</li> </ul>
NX-series NX102CPU Unit Hardware User's Manual	W593	NX102-□□□	Learning the basic specifica- tions of the NX-series NX102 CPU Units, including introduc- tory information, designing, installation, and maintenance. Mainly hardware information is provided.	<ul> <li>An introduction to the entire NX102 CPU Unit system is pro- vided along with the following information on the CPU Unit.</li> <li>Features and system configu- ration</li> <li>Overview</li> <li>Part names and functions</li> <li>General specifications</li> <li>Installation and wiring</li> <li>Maintenance and inspection</li> </ul>
NX-series NX1P2 CPU Unit Hardware User's Manual	W578	NX1P2-	Learning the basic specifica- tions of the NX-series NX1P2 CPU Units, including introduc- tory information, designing, installation, and maintenance. Mainly hardware information is provided.	<ul> <li>An introduction to the entire NX1P2 CPU Unit system is pro- vided along with the following information on the CPU Unit.</li> <li>Features and system configu- ration</li> <li>Overview</li> <li>Part names and functions</li> <li>General specifications</li> <li>Installation and wiring</li> <li>Maintenance and inspection</li> </ul>

Manual name	Cat. No.	Model numbers	Application	Description
NJ-series	W500	NJ501-□□□	Learning the basic specifica-	An introduction to the entire
CPU Unit		NJ301-□□□□	tions of the NJ-series CPU	NJ-series system is provided
Hardware User's		NJ101-□□□□	Units, including introductory information, designing, installa-	along with the following infor- mation on the CPU Unit.
Manual			tion, and maintenance.	<ul> <li>Features and system configu-</li> </ul>
			Mainly hardware information is	ration
			provided.	Overview
				Part names and functions
				General specifications
				<ul> <li>Installation and wiring</li> </ul>
				Maintenance and inspection
NY-series IPC	W557	NY532-000	Learning the basic specifica-	An introduction to the entire
Machine Control-			tions of the NY-series Industrial	NY-series system is provided
ler Industrial Panel			Panel PCs, including introduc-	along with the following infor-
PC Hardware User's Manual			tory information, designing, installation, and maintenance.	mation on the Industrial Panel PC.
USEI S Mariual				
Lleer's Menuel			Mainly hardware information is provided.	Features and system configu- ration
User's Manual				Overview
NY-series IPC MachineControl-				<ul> <li>Part names and functions</li> </ul>
ler IndustrialPanel				General specifications
PC HardwareU-				<ul> <li>Installation and wiring</li> </ul>
ser's Manual				Maintenance and inspection
NY-series IPC	W556	NY512-000	Learning the basic specifica-	An introduction to the entire
Machine Control-			tions of the NY-series Industrial	NY-series system is provided
ler Industrial Box			Box PCs, including introductory	along with the following infor-
PC Hardware User's Manual			information, designing, installa- tion, and maintenance.	mation on the Industrial Box PC.
User's Mariuar				
			Mainly hardware information is provided.	Features and system configu- ration
				Overview
				Part names and functions
				General specifications
				<ul> <li>Installation and wiring</li> </ul>
				Maintenance and inspection
NJ/NX-series	W501	NX701-000	Learning how to program and	The following information is pro-
CPU Unit		NJ501-□□□□	set up an NJ/NX-series CPU	vided on an NJ/NX-series CPU
Software User's		NJ301-□□□□	Unit.	Unit.
Manual		NJ101-□□□	Mainly software information is	CPU Unit operation
			provided.	CPU Unit features
		NX1P2-		<ul> <li>Initial settings</li> </ul>
				Programming based on IEC
				61131-3 language specifica- tions
NY-series	W558	NY532-000	Learning how to program and	The following information is pro-
IPC Machine Con-		NY512-000	set up the Controller functions	vided on NY-series Machine
troller			of an NY-series Industrial PC	Automation Control Software.
Industrial Panel				Controller operation
PC /				Controller features
Industrial Box PC				Controller settings
Software User's				<ul> <li>Programming based on IEC</li> </ul>
Manual				61131-3 language specifica-
				tions

Manual name	Cat. No.	Model numbers	Application	Description
NJ/NX-series	W505	NX701-□□□□	Using the built-in EtherCAT port	Information on the built-in Eth-
CPU Unit Built-in		NJ501-□□□□	on an NJ/NX-series CPU Unit	erCAT port is provided.
EtherCAT® Port		NJ301-□□□□		This manual provides an intro-
User's Manual		NJ101-□□□□		duction and provides informa- tion on the configuration,
		NX1P2-000		features, and setup.
NY-series	W562	NY532-000	Using the built-in EtherCAT port	Information on the built-in Eth-
IPC Machine Con-		NY512-000	on an NY-series Industrial PC	erCAT port is provided.
troller				This manual provides an intro-
Industrial Panel				duction and provides informa- tion on the configuration,
PC / Industrial Box PC				features, and setup.
Built-in Ether-				
CAT®				
Port User's Man-				
ual NJ/NX-series	W502	NX701-□□□	Learning detailed specifica-	The instructions in the instruc-
Instructions Refer-	VV302	NJ501-□□□□	tions on the basic instructions of	tion set (IEC 61131-3 specifica-
ence Manual			an NJ/NX-series CPU Unit	tions) are described.
		NJ301-□□□		
		NJ101-□□□□		
		NX1P2-000		
NY-series	W560	NY532-□□□□	Learning detailed specifica-	The instructions in the instruc-
Instructions Refer- ence		NY512-000	tions on the basic instructions of an NY-series Industrial PC	tion set (IEC 61131-3 specifica- tions) are described.
Manual				

## **Revision History**

A manual revision code appears as a suffix to the catalog number on the front and back covers of the manual.



Revision code	Date	Revised content
01	October 2018	Original production
02	May 2021	Corrected mistakes

## **Procedure to Use Sysmac Libraries**

Sysmac Library User's Manual for RFID Communications Library (W609)

# Procedure to Use Sysmac Libraries Installed Using the Installer

This section describes the procedure to use Sysmac Libraries that you installed using the installer. There are two ways to use libraries.

- · Using newly installed Sysmac Libraries
- Using upgraded Sysmac Libraries



Version Information

To use Sysmac Libraries, you need the Sysmac Studio version 1.14 or higher.

### **Using Newly Installed Libraries**


1 Start the Sysmac Studio and open or create a new project in which you want to use Sysmac Libraries.

Offline	Project Properties Project name New Project
Open Project	Author
im <sup>₽</sup> Import	Comment
Export	Type Standard Project
A Online	Select Device
4 Connect to Device	Category Controller  Device NJ501  Image: 1500
License	Version 1.10

#### **Precautions for Correct Use**

If you create a new project, be sure to configure the settings as follows to enable the use of Sysmac Libraries. If you do not configure the following settings, you cannot proceed to the step 2 and later steps.

- · Set the project type to Standard Project or Library Project.
- · Set the device category to Controller.
- Set the device version to 1.01 or later.



#### Precautions for Correct Use

If you have more than one registered device in the project, make sure that the device selected currently is an NJ/NX-series CPU Unit or an NY-series Industrial PC. If you do not select an NJ/NX-series CPU Unit or an NY-series Industrial PC as the device, Library References does not appear in the above menu. When the device selected currently is an NJ/NX-series CPU

Unit or an NY-series Industrial PC, the device icon **III** is displayed in the Multiview Explorer.

**3** Add the desired Sysmac Library to the list and click the **OK** Button.




The Sysmac Library file is read into the project.


Now, when you select the Ladder Editor or ST Editor, the function blocks and functions included in a Sysmac Library appear in the Toolbox.

For the procedure for adding and setting libraries in the above screen, refer to the *Sysmac Studio Version 1 Operation Manual* (Cat. No. W504).

- **4** Insert the Sysmac Library's function blocks and functions into the circuit using one of the following two methods.
  - Select the desired function block or function in the Toolbox and drag and drop it onto the programming editor.



 Right-click the programming editor, select Insert Function Block in the menu, and enter the fully qualified name (\\name of namespace\name of function block).



#### Precautions for Correct Use


After you upgrade the Sysmac Studio, check all programs and make sure that there is no error of the program check results on the Build Tab Page.

Select Project – Check All Programs from the Main Menu.

## **Using Upgraded Libraries**

1 Start the Sysmac Studio and open a project in which any old-version Sysmac Library is included.


```
2 Select Project – Library – Show References.
```



#### Precautions for Correct Use


If you have more than one registered device in the project, make sure that the device selected currently is an NJ/NX-series CPU Unit or an NY-series Industrial PC. Otherwise, Library References does not appear in the above menu. When the device selected currently is an

NJ/NX-series CPU Unit or an NY-series Industrial PC, the device icon **H** is displayed in the Multiview Explorer.





4 Add the desired Sysmac Library to the list and click the **OK** Button.



# Procedure to Use Sysmac Libraries Uploaded from a CPU Unit or an Industrial PC

You can use Sysmac Libraries uploaded from a CPU Unit or an Industrial PC to your computer if they are not installed.

The procedure to use uploaded Sysmac Libraries from a CPU Unit or an Industrial PC is as follows.



To use Sysmac Libraries, you need the Sysmac Studio version 1.14 or higher.

**1** Start the Sysmac Studio and create a new project in which you want to use Sysmac Libraries.

Offline	Project Properties
New Project	Project name New Project Author
	Comment
Export	Type Standard Project
A Online	Select Device
<b>4</b> Connect to Device	Category Centroller Device NJ501 1500
License	Version 1.10 Create

2 Connect the computer to the CPU Unit or the Industrial PC and place it online.

**3** Upload POUs in which any Sysmac Library is used to the computer.

Now, when you select the Ladder Editor or ST Editor, the function blocks and functions included in the Sysmac Library used in the uploaded POUs appear in the Toolbox.

4 Insert the Sysmac Library's function blocks and functions into the circuit using one of the following two methods.

• Select the desired function block or function in the Toolbox and drag and drop it onto the Ladder Editor.

- Section	Section0 - Program0 ×						
Varia	al anna a' anna a'			<b>A</b>	<search></search>		
0	Enter Funct \\OmronLib\MC_Too Enable				OmronLib_MC_Toolbox_V     F     DeadBand {OmronLib\M		
	Enter Variable InCalc	CalcRsit Enter Variable	7		FB FirstOrderlag (OmronLi		
	Enter Variable— Kp Enter Variable— TimeConst	Busy — Enter Variable	Drug & Drop		FB LeadLag (OmronLib\MC		
	Enter Variable SampTime	ErrorID — Enter Variable		- 1	FB PIDFeedFwd {OmronLib		
		ErrorIDEx Enter Variable		- 1	Analog Conversion     BCD Conversion		

• Right-click the programming editor, select **Insert Function Block** in the menu, and enter the fully qualified name (\\name of namespace\name of function block).

Section0 - Program0 X	Toolbox 🗸 🖣
Variables	<search></search>
Enter Function Block     (\OmronLib\MC_Toolbox)	▼ OmronLib_MC_Toolbox_V
si FirstOrderlag	
B <sup>P</sup> PIDFeedFwd	FB FirstOrderlag (OmronLib
	FB LeadLag {OmronLib\MC.
	FB PIDFeedFwd {OmronLib\
	Analog Conversion



### **Precautions for Correct Use**

• The Sysmac Studio installs library files of the uploaded Sysmac Studio to the specified folder on the computer if they are not present. However, the Sysmac Studio does not install library files to the specified folder on the computer if they are present.

The specified folder here means the folder in which library files are installed by the installer.

 Note that uploading Sysmac Libraries from a CPU Unit or an Industrial PC does not install the manual and help files for the Sysmac Libraries, unlike the case where you install then using the installer. Please install the manual and help files using the installer if you need them.

## **Common Specifications of Function Blocks**

# **Common Variables**

This section describes the specifications of variables (*EN*, *Execute*, *Enable*, *Abort*, *ENO*, *Done*, *CalcRslt*, *Enabled*, *Busy*, *CommandAborted*, *Error*, *ErrorID*, and *ErrorIDEx*) that are used for more than one function or function block. The specifications are described separately for functions, for execute-type function blocks, and for enable-type function blocks.


## **Definition of Input Variables and Output Variables**

Common input variables and output variables used in functions and function blocks are as follows.

		Data	blo	ction/func ck type to			
Variable	I/O	type	Functio Execute- type	n block Enable- type	Function	Meaning	Definition
EN	Input	BOOL			OK	Execute	The processing is executed while the variable is TRUE.
Execute			ОК			Execute	The processing is executed when the variable changes to TRUE.
Enable				OK		Run	The processing is executed while the variable is TRUE.
Abort		BOOL	OK			Abort	The processing is aborted. You can select the aborting method.
ENO	Output	BOOL			ОК	Done	The variable changes to TRUE when the processing ends normally. It is FALSE when the processing ends in an error, the processing is in progress, or the execution condition is not met.
Done		BOOL	OK			Done	The variable changes to TRUE when the processing ends normally. It is FALSE when the processing ends in an error, the processing is in progress, or the execution condition is not met.
Busy	-	BOOL	ОК	ОК		Executing	The variable is TRUE when the process- ing is in progress. It is FALSE when the processing is not in progress.
CalcRsIt		LREAL		OK		Calculation Result	The calculation result is output.
Enabled		BOOL		OK		Enabled	The variable is TRUE when the output is enabled. It is used to calculate the con- trol amount for motion control, tempera- ture control, etc.
Command Aborted		BOOL	ОК			Command Aborted	The variable changes to TRUE when the processing is aborted. It changes to FALSE when the process- ing is re-executed the next time.
Error		BOOL	ОК	ОК		Error	This variable is TRUE while there is an error. It is FALSE when the processing ends normally, the processing is in progress, or the execution condition is not met.
ErrorID ErrorIDEx	-	WORD DWORD	OK OK	OK OK		Error Code Expansion	An error code is output. An expansion error code is output.
		DWORD	Or	Or		Expansion Error Code	

### **Execute-type Function Blocks**


- · Processing starts when Execute changes to TRUE.
- When Execute changes to TRUE, Busy also changes to TRUE. When processing is completed normally, Busy changes to FALSE and Done changes to TRUE.
- When continously executes the function blocks of the same instance, change the next *Execute* to TRUE for at least one task period after *Done* changes to FALSE in the previous execution.
- If the function block has a CommandAborted (Instruction Aborted) output variable and processing is aborted, CommandAborted changes to TRUE and Busy changes to FALSE.
- If an error occurs in the function block, Error changes to TRUE and Busy changes to FALSE.
- For function blocks that output the result of calculation for motion control and temperature control, you can use the BOOL input variable *Abort* to abort the processing of a function block. When *Abort* changes to TRUE, *CommandAborted* changes to TRUE and the execution of the function block is aborted.



- If *Execute* is TRUE and *Done*, *CommandAborted*, or *Error* changes to TRUE, *Done*, *Command-Aborted*, and *Error* changes to FALSE when *Execute* is changed to FALSE.
- If *Execute* is FALSE and *Done*, *CommandAborted*, or *Error* changes to TRUE, *Done*, *Command-Aborted*, and *Error* changes to TRUE for only one task period.
- If an error occurs, the relevant error code and expansion error code are set in *ErrorID* (Error Code) and *ErrorIDEx* (Expansion Error Code). The error codes are retained even after *Error* changes to FALSE, but *ErrorID* is set to 16#0000 and *ErrorIDEx* is set to 16#0000 0000 when *Execute* changes to TRUE.


## **Timing Charts**

This section provides timing charts for a normal end, aborted execution, and errors.




#### • Normal End


### Canceled Execution



### Aborted Execution




• Errors



### **Enable-type Function Blocks**

- · Processing is executed while Enable is TRUE.
- When *Enable* changes to TRUE, *Busy* also changes to TRUE. *Enabled* is TRUE during calculation of the output value.
- If an error occurs in the function block, *Error* changes to TRUE and *Busy* and *Enabled* change to FALSE. When *Enable* changes to FALSE, *Enabled*, *Busy*, and *Error* change to FALSE.





- If an error occurs, the relevant error code and expansion error code are set in *ErrorID* (Error Code) and *ErrorIDEx* (Expansion Error Code). The error codes are retained even after *Error* changes to FALSE, but *ErrorID* is set to 16#0000 and *ErrorIDEx* is set to 16#0000 0000 when *Enable* changes to TRUE.
- For function blocks that calculate the control amount for motion control, temperature control, etc., Enabled is FALSE when the value of CalcRslt (Calculation Result) is incorrect. In such a case, do not use CalcRslt. In addition, after the function block ends normally or after an error occurs, the value of CalcRslt is retained until Enable changes to TRUE. The control amount will be calculated based on the retained CalcRslt value, if it is the same instance of the function block that changed Enable to TRUE. If it is a different instance of the function block, the control amount will be calculated based on the initial value.

## **Timing Charts**

This section provides timing charts for a normal end and errors.

### Normal End





## **Precautions**

This section provides precautions for the use of this function block.

### Nesting

You can nest calls to this function block for up to four levels. For details on nesting, refer to the software user's manual.

## **Instruction Options**

You cannot use the upward differentiation option for this function block.

### **Re-execution of Function Blocks**

Execute-type function blocks cannot be re-executed by the same instance. If you do so, the output value will be the initial value.

For details on re-execution, refer to the motion control user's manual.

## Individual Specifications of Function Blocks

Function block name	Name	Page	
ReadData_V680	RF Tag data read for V680	P.36	
WriteData_V680	RF Tag data write for V680	P.59	

# Common Data Types for All Function Blocks

This section describes the data types used in common in all function blocks included in the "NX\_V680" library.

### Structure sV680DeviceVariables

Members	Name	Data Type	Valld range	Description
Status	Status	WORD	Depends on data	Allocated from the I/O map Status in
			type.	the input area of the RFID Unit.
RefreshCount	Refresh Count	UINT	0 to 65535	Allocated from the I/O map Refresh
				Count in the input area of the RFID Unit.
ResponseCode	Response Code	WORD	Depends on data	Allocated from the I/O map
			type.	Response Code in the input area of
				the RFID Unit.
InputSID	Input SID	UINT	0 to 512	Allocated from the I/O map Input SID
				in the input area of the RFID Unit.
OutputSIDRe-	Output SID	UINT	0 to 512	Allocated from the I/O map Output
sponse	Response			SID Response in the input area of the
				RFID Unit.
InputData1	Input Data 1	ARRAY[015]	Depends on data	Allocated from the I/O map Input Data
		OF BYTE	type.	<i>1</i> in the input area of the RFID Unit.
UID	UID	ARRAY[07]	Depends on data	Allocated from the I/O map UID in the
		OF BYTE	type.	input area of the RFID Unit.
RFCommunica-	RF Communica-	UINT	0 to 65535	Allocated from the I/O map RF Com-
tionsTime	tions Time			munications Time in the input area of
				the RFID Unit.
NoiseLevel	Noise Level	UINT	0 to 100	Allocated from the I/O map Noise
				Level in the input area of the RFID
				Unit.
OperationCom-	Operation Com-	BYTE	Depends on data	Allocated to the I/O map Operation
mand	mand		type.	Command in the output area of the
				RFID Unit.
RFCommunica-	RF Communica-	USINT	Depends on data	Allocated to the I/O map RF Commu-
tionsOption	tions Option		type.	nications Option in the output area of
0 10 1				the RFID Unit.
CommandCode	Command Code	WORD	Depends on data	Allocated to the I/O map <i>Command</i>
			type.	<i>Code</i> in the output area of the RFID Unit.
Mana a m ( A al al ma a a		UINT	Denende en dete	
MemoryAddress	Memory Address	UINT	Depends on data	Allocated to the I/O map <i>Memory</i> <i>Address</i> in the output area of the
			type.	RFID Unit.
DataSize	Data Size	UINT	Depends on data	Allocated to the I/O map Data Size in
			-	the output area of the RFID Unit.
RefreshCoun-	Refresh Count	UINT	type. 0 to 65535	Allocated to the I/O map <i>Refresh</i>
tResponse	Response		01000000	<i>Count Response</i> in the output area of
litesponse	Response			the RFID Unit.
OutputSID	Output SID	UINT	0 to 512	Allocated to the I/O map <i>Output SID</i>
Calpatolo			0.0012	in the output area of the RFID Unit.
InputSIDResponse	Input SID	UINT	0 to 512	Allocated to the I/O map <i>Input SID</i>
			0.0012	<i>Response</i> in the output area of the
	Response			

Members	Name	Data Type	Valld range	Description
OutputData1	Output Data 1	ARRAY[015]	Depends on data	Allocated to the I/O map Output Data
		OF BYTE	type.	<i>1</i> in the output area of the RFID Unit.
SelectUID	Select UID	ARRAY[07]	Depends on data	Allocated to the I/O map Select UID
		OF BYTE	type.	in the output area of the RFID Unit.



## Precautions for Correct Use

• The I/O allocation settings of the RFID Unit used in the structure *sV680DeviceVariables* are as described below.

Refer to Section 6 I/O Data Specifications in the NX-series RFID Units User's Manual (Z401) for details on the I/O entry mapping of the RFID Unit.

Area	Data name	Size (Byte)	Data type	Assigned.
Output	Chn Status	2	WORD,BOOL	Fixed
	Chn Refresh Count	2	UINT	Fixed
	Chn Response Code	2	WORD	Fixed
	Chn Measurement Result	2	UINT?	Fixed
	Chn Input SID	2	UINT	Fixed
	Chn Output SID Response	2	UINT	Fixed
	Chn Input Data 1	16	ARRAY[015] OF BYTE	Fixed
	Chn UID	8	ARRAY[07] OF BYTE	Variable
	Chn RF Communica- tions Time	2	UINT	Variable
	Chn Noise Level	2	UINT	Variable
output	Chn Operation Com- mand	1	BYTE,BOOL	Fixed
	Chn RF Communica- tions Option	1	USINT	Fixed
	Chn Command Code	2	WORD	Fixed
	Chn Memory Address	2	UINT	Fixed
	Chn Data Size	2	UINT	Fixed
	Chn Refresh Count Response	2	UINT	Fixed
	Chn Output SID	2	UINT	Fixed
	Chn Input SID Response	2	UINT	Fixed
	Chn Output Data 1	16	ARRAY[015] OF BYTE	Fixed
	Chn Select UID	8	ARRAY[07] OF BYTE	Variable

• When the 2CH Unit NX-V680C2 is used, do not set together the I/O ports of 1CH and 2CH in the structure *sV680DeviceVariables*. Doing so may result in the malfunction of the function block. Always arrange the I/O ports of the same CH.

# ReadData\_V680

This command reads data from the memory of an RF Tag in the communications range of the antenna mounted on the RFID Unit (NX-V680).

Program part names	Series	FB/ FUN	Graphic expression	STexpression
ReadD-	RF Tag data	FB		ReadData_V680_instance(
ata_V680	read			Execute := <parameter>,</parameter>
	for V680		\\OmronLib\NX_V680\ReadData_V680	RFCommunicationsOption := <parameter>,</parameter>
			Execute Done	ReadKind := <parameter>,</parameter>
			RFCommunicationsOption Busy	MemoryAddr := <parameter>,</parameter>
			ReadKind Result	DataSize := <parameter>,</parameter>
			MemoryAddr CommandAborted	Abort := <parameter>,</parameter>
			– DataSize Error –	SelectUID := <parameter>,</parameter>
			Abort ErrorID	Done => <parameter>,</parameter>
			SelectUID ErrorIDEx	Busy => <parameter>,</parameter>
			DeviceVariables — DeviceVariables	Result => <parameter>,</parameter>
			ReadData — ReadData —	CommandAborted => <parame- ter&gt;,</parame- 
			Warning	Error => <parameter>,</parameter>
			- DIU	ErrorID => <parameter>,</parameter>
			RFCommunicationsTime	ErrorIDEx => <parameter>,</parameter>
			NoiseLevel	Warning => <parameter>,</parameter>
				UID => <parameter>,</parameter>
				RFCommunicationsTime => <pre><parameter>,</parameter></pre>
				NoiseLevel => <parameter>,</parameter>
				ReadData := <parameter>,</parameter>
				DeviceVariables := <parameter>,</parameter>
				);

# **Function Block and Function Information**

ltem	Description
Library file name	OmronLib_NX_V680_Vx_x.slr (x indicates the version)
Namespace	OmronLib\NX_V680
Function block and function	00213
number	
Source code	Do not publish.

# Input variable

Variables	Name	Data Type	Description	Valid range	Unit	Initial value
Execute	Execute	BOOL	The processing is started when the variable changes to TRUE.	TRUE or FALSE		FALSE
			TRUE: Execute			
			FALSE: Do not execute			
RFCommunica-	RF Communica-	USINT	Specify the operation sequence	0 to 7		0
tionsOption	tions Option		during communications.			
			0: Trigger			
			1: Auto			
			2: Repeat			
			3: FIFO Trigger			
			4: FIFO Repeat			
			5: Multi Trigger			
			6: Multi Repeat			
			7: Selective			
ReadKind	Read Type	USINT	Specify the type of the read	0 to 2		0
			command. <sup>*1</sup>			
			0: Normal			
			1: With error detection			
			2: With error correction			
MemoryAddr	Memory	UINT	Specify the start address of the	0 to 65535	Byte	0
	Address		memory to which data is read			
<u> </u>			from the RF Tag. <sup>*2</sup>	4.1. 0.100	<b>D</b> (	0
DataSize	Data Size	UINT	Enter the size of the data to be read from the RF Tag. <sup>*3</sup>	1 to 8192	Byte	0
Abort	Abort	BOOL	The processing is aborted when	TRUE or		FALSE
			the variable changes to TRUE.	FALSE		
SelectUID	Select UID	ARRAY[0	Specify the UID of the communi-	Depends on		16#00
		7]OF BYTE	cations target RF Tag when the	data type.		
			RF communications option is Selective.			

\*1. Refer to the List of Commands in the *NX-series RFID Units User's Manual* (Z401) for details on the types of read command and differences in their operation.

\*2. Enter a value in consideration of the memory map of the RF Tag actually used.

\*3. Enter a value in consideration of the memory capacity of the RF Tag actually used. When 0 is specified, no operation is performed and the processing ends.

# **Output Variables**

Variables	Name	Data Type	Description	Valid range	Unit	Initial value
Done	Done	BOOL	The variable changes to TRUE	TRUE or FALSE		FALSE
			when the processing is completed.			
Busy	Busy	BOOL	The variable changes to TRUE	TRUE or FALSE		FALSE
			when the processing is acknowl-			
			edged.			
Result	Result	BOOL	The value of the variable alternately	TRUE or FALSE		FALSE
			changes between TRUE and			
			FALSE each time the result of com-			
			munications with the RF Tag is out- put when the communications			
			specification is set to <i>Repeat</i> , <i>FIFO</i>			
			repeat, Multi trigger, or Multi repeat.			
Command	Instruction	BOOL	The variable changes to TRUE	TRUE or FALSE		FALSE
Aborted	Aborted		when the processing is aborted.			
Error	Error	BOOL	This variable is TRUE while there is	TRUE or FALSE		FALSE
			an error.			
			TRUE: Error end			
			FALSE: Normal end or Executing			
ErroriD	Error code	WORD	An error code is output.	*1		0
			This is the error ID for an error end.			
			The value is 16#0 for a normal end.			
ErrorIDEx	Expansion	DWORD	An expansion error code is output.	*1		0
	error code		This is the error ID for an error end.			
			The value is 16#0 for a normal end.			
Warning	Warning	BOOL	The variable changes to TRUE	TRUE or FALSE		FALSE
			when an error correction occurs.			
UID	UID	ARRAY[07]	The UID of the RF Tag with which	Depends on data		16#00
		OF BYTE	communications are performed is	type.		
			output.			
RFCom-	RF Com-	UINT	The measured RF communications	0 to 65535	ms	0
munica-	munica-		time is output.			
tionsTime	tions Time			0 to 00		
NoiseLevel	Noise Level	UINT	The measured noise level is output.	0 to 99		0
	Level				1	

\*1. For details, refer to *Troubleshooting* on page 52.


## **In-Out Variables**

Variables	Name	Data Type	Description	Valid range	Unit	Initial value
DeviceVari-	device vari-	Omron-	Device variables of the RFID Unit	Depends on data		
ables	able	Lib\RFID\sNX	(I/O port of the input area / output	type.		
		-V680Device-	area)			
		Variables				
ReadData	Read Data	ARRAY	Data array read from the RF Tag	Depends on data		
		[Variable		type.		
		length]				
		OF BYTE				


Note A BYTE array of any length can be specified. However, the array length must be equal to or more than the DataSize. Both 0 and n can be set for the array start number.

## Operation

This function block controls the command for reading the memory of the RF Tag for an RFID Unit (NX-V680) that is exchanging data with an NJ/NX/NY-series Controller. Therefore, the device variables (the I/O port of the output area and the I/O port of the input area) of the RFID Unit to be controlled must be set in the input/output variable *DeviceVariables* of the function block.



• When *Execute* changes to TRUE, the data read from the memory of the RF Tag is saved to the byte array specified by *ReadData*.




In-Out Variables	Meaning
ReadData[0]	11
ReadData[1]	22
ReadData[2]	33
ReadData[3]	44


• The memory capacity read from the RF Tag in a single execution varies depending on the specified *ReadKind*. The values that can be specified in *MemoryAddr* and *DataSize* are described below.

ReadKind	MemoryAddr	DataSize
0: Normal	0 to 65535	1 to 8192
1: With error detec-	0 to 65533	1 to 8190
tion		
2: With error correc-	0 to 65530	1 to 510
tion		

• If *ReadKind* is executed as *With error detection*, the data and check code are read from the RF Tag, and errors in the data are detected. When using this function, write beforehand the data and check code in the target area as *With error detection* of the function block "WriteData\_V680".



• If *ReadKind* is executed as *With error correction*, the data and check code are read from the RF Tag, and errors in the data are detected, and 1-bit errors are corrected. When using this function, write beforehand the data and check code in the target area as *With error correction* of the function block "WriteData\_V680".



Note If the data and check code are not written beforehand in the target area as *With error detection* and *With error correction* of the function block "WriteData\_V680" when *ReadKind* is executed as "With error detection", a communications error (RF Tag Data Error Detected) will occur.

## **Timing Chart**


The timing charts are shown below.

## Communicating with One RF Tag (RF Communications Option: Trigger, Auto, FIFO trigger or Selective)

If this function block is started by specifying Trigger, Auto, FIFO trigger, or Selective in *RFCommunicationsOption*, the result of communications with one RF Tag present in the communications range of the antenna is output.


#### Timing Chart for Normal End

- Busy (Executing) changes to TRUE when Execute (Execute) changes to TRUE.
- If reading of data from the memory of the RF Tag ends normally, *Done* changes to TRUE, and *Busy* (Executing) changes to FALSE. At the same time, a data string is output in *ReadData* and UID, and a value is output in *RFCommunicationsTime* and *NoiseLevel*.
- If *Execute* remains TRUE even after the execution of this function block is complete, the output value of *Done* is retained.
- If Execute changes to FALSE before the execution of this function block is complete, *Done* changes to TRUE only for one task period after the execution of the function block is complete.




## • Timing Chart for Error End

- If an error occurs while the execution of this function block is in progress, *Error* changes to TRUE and *Busy* (Executing) changes to FALSE.
- You can find out the cause of the error by referencing the values output to *ErrorID* (Error Code) and *ErrorIDEx* (Expansion Error Code).
- If *Execute* remains TRUE even after the execution of this function block is complete, the output value of *Error* is retained.
- The output values of *ErrorID* (Error Code) and *ErrorIDEx* (Expansion Error Code) are retained until this function block is executed again.
- If *Execute* changes to FALSE before the execution of this function block is complete, *Error* changes to TRUE only for one task period after the execution of the function block is complete.



## • Timing Chart when the Function Block is Aborted

To abort communications with the RF Tag while the execution of this function block is in progress, set *Abort* to TRUE. If *Abort* changes to TRUE, *Busy* (Executing) changes to FALSE and *Command-Aborted* changes to TRUE.





# Communicating with Multiple RF Tags (RF Communications Option: Multi Trigger)

If this function block is started by specifying Multi trigger in *RFCommunicationsOption*, the result of communications with the multiple RF Tags present in the communications range of the antenna is output.

### • Timing Chart for Communications with Multiple RF Tags


- Busy (Executing) changes to TRUE when Execute (Execute) changes to TRUE.
- Each time communications are performed with multiple RF Tags, the *Result* toggles between FALSE -> TRUE -> FALSE -> TRUE.
- When communications with all RF Tags in the communications range are complete, *Done* changes to TRUE and *Busy* (Executing) changes to FALSE.
- If reading of data from the memory of the RF Tag ends normally, a data string is output in *ReadD-ata* and UID, and a value is output in *RFCommunicationsTime* and *NoiseLevel* at the same time as a change in *Result*.
- If reading of data from the memory of the RF Tag ends in an error, *Error* changes to TRUE at the same time as a change in *Result*. You can find out the cause of the error by accessing the values output to ErrorID (Error Code) and ErrorIDEx (Expansion Error Code).






## Timing Chart when the Function Block is Aborted

- To abort communications with the RF Tag while the execution of this function block is in progress, set *Abort* to TRUE. If *Abort* changes to TRUE, *Busy* (Executing) changes to FALSE and *CommandAborted* changes to TRUE.
- Result changes to FALSE at the same time when CommandAborted changes to FALSE.



#### Timing Chart when the Tag is Missing

- If communications are not performed with the RF Tag even once while the execution of this function block is in progress, *Result* and *Error* change to TRUE, and *Busy* (Executing) changes to FALSE.
- You can find out the cause of the error by accessing the values output to ErrorID (Error Code) and ErrorIDEx (Expansion Error Code).
- If *Execute* remains TRUE even after the execution of this function block is complete, the output values of *Result* and *Error* are retained.
- The output values of *ErrorID* (Error Code) and *ErrorIDEx* (Expansion Error Code) are retained until this function block is executed again.
- If *Execute* changes to FALSE before the execution of this function block is complete, *Result* and *Error* change to TRUE only for one task period after the execution of the function block is complete.




# Communicating Repeatedly with an RF Tag (RF Communications Option: Repeat, FIFO Repeat or Multi Repeat)


If this function block is started by specifying Repeat, FIFO repeat, or Multi-access repeat in *RFCommunicationsOption* (RF Communications Option), the result of repeated communications with an RF Tag that has moved into the communications range of the antenna is output.

#### • Timing Chart for Repeated Communications

- Busy (Executing) changes to TRUE when Execute (Execute) changes to TRUE.
- Each time communications are performed with multiple RF Tags, the *Result* toggles between FALSE -> TRUE -> FALSE -> TRUE.
- If reading of data from the memory of the RF Tag ends normally, a data string is output in *ReadData* and UID, and a value is output in *RFCommunicationsTime* and *NoiseLevel* at the same time as a change in *Result*.
- If reading of data from the memory of the RF Tag ends in an error, *Error* changes to TRUE at the same time as a change in *Result*. You can find out the cause of the error by accessing the values output to ErrorID (Error Code) and ErrorIDEx (Expansion Error Code).




- To end repeated communications with an RF Tag, you must set *Abort* to TRUE. If *Abort* changes to TRUE, *Busy* (Executing) changes to FALSE and *CommandAborted* changes to TRUE.
- Result changes to FALSE at the same time when CommandAborted changes to FALSE.



### • Timing Chart for Error End

- If a specific error occurs while the execution of this function block is in progress, *Error* changes to TRUE and *Busy* (Executing) changes to FALSE, and the repetitive process is aborted.
- Result changes to FALSE at the same time when Error changes to FALSE.
- You can find out the cause of the error by accessing the values output to ErrorID (Error Code) and ErrorIDEx (Expansion Error Code).
- If *Execute* remains TRUE even after the execution of this function block is complete, the output value of *Error* is retained.
- The output values of *ErrorID* (Error Code) and *ErrorIDEx* (Expansion Error Code) are retained until this function block is executed again.
- If *Execute* changes to FALSE before the execution of this function block is complete, *Error* changes to TRUE only for one task period after the execution of the function block is complete.



Note The specific errors due to which repeated communications are stopped are as described below.

Expansion error	Expansion error	Status
code	code	Olalus
16#3D13	16#6AA00000	Antenna Configuration Error
	16#6AA10000	Amplifier Power Supply
		Error
	16#6AA20000	Amplifier Disconnection
		Detection
	16#6A720000	RF Tag Missing Error

# **Common Behavior**


#### • Timing Chart when an Error is Detected during Startup

- If an error is detected when this function block is started, *Error* changes to TRUE. *Busy* (Executing) remains FALSE.
- You can find out the cause of the error by accessing the values output to ErrorID (Error Code) and ErrorIDEx (Expansion Error Code).
- If *Execute* remains TRUE even after the execution of this function block is complete, the output value of *Error* is retained.
- The output values of *ErrorID* (Error Code) and *ErrorIDEx* (Expansion Error Code) are retained until this function block is executed again.

Execute			
Abort			
Done			
Busy			
ReadData			
CommandAborted			1 1 1 1 1
Error	[		
ErrorID		ErrorID	
ErrorIDEx		ErrorIDEx	

# • Timing Chart for a Normal End when 1-bit Error Correction is Performed (Read Type: With Error Correction)

- When a 1-bit error is detected and corrected in the data read from the memory of the RF Tag, *Done* becomes TRUE, and at the same time, *Warning* becomes TRUE.
- If *Execute* remains TRUE even after the execution of this function block is complete, the output value of *Warning* is retained.



- When a 1-bit error is detected and corrected in the data read from the memory of the RF Tag during repeated communications, *Warning* also varies simultaneously when *Result* performs tog-gle operation.
- If error correction is performed next, *Warning* remains TRUE and does not change.

Execute			1		
Abort			 		
Done					
Busy			1 1 1 1		
Result	 <b>≜</b>	↓	1	<b>↓</b>	
		ReadData#1		ReadData#3	55
ReadData	/			1.0002.000.00	
CommandAborted					
Error	 				
ErrorID		16#0000	ErrorID#02	16#0000	55
ErrorIDEx		16#0000 0000	ErrorIDEx#02	16#0000 0000	55
Warning	 •	¥	<b>▲</b>	↓	
Training .					

## **Precautions for Correct Use**

- If the RFID Unit is in the Busy state due to the execution of a command already in progress, *Error* is output as TRUE indicating an error end, and the functions of this function block are not executed.
- When using the RFID Unit (NX-V680C2), integrate the device variables used as the input/output variables for this function block in either channel Ch1 or Ch2. If the device variables of different channels are set together, the operation will not be performed properly.
- Before executing this function block, carefully read the manual of the NX-V680C□ to use and ensure the safety for use.
- If the operation parameter *Data storage order* of the RFID Unit is *Descending*, do not specify the data size of the odd bytes. If you do so, you will not be able to read the correct data.
- Do not add the I/O entry *Input Data 2 to 8* to a channel used in the RFID Unit. If the total size of the input data increases, correct operation will not be performed.

# Troubleshooting

Expan- sion error code	Expansion error code	Status	Description	Corrective action
16#0000	16#00000000	Normal End		
16#3D13	16#0000001	Invalid RF Commu- nications Option	The value of RFCommunication- sOption is outside the valid range.	Set the correct value in RFCom- municationsOption.
	16#0000002	Invalid Read Type	The value of ReadKind is out- side the valid range.	Set the correct value in Read- Kind.
	16#0000003	Invalid Memory Address	The value of MemoryAddr is out- side the valid range.	Set the correct value in Memory- Addr.
	16#00000004	Invalid Data Size	The value of DataSize is outside the valid range.	Set the correct value in Data- Size.
	16#00000005	Invalid Data Array	The array length of ReadData is below DataSize.	Set the array length of ReadD- ata to DataSize or above.
	16#0000006	Execution Disabled	This function block cannot be started because the command is not ready for execution in the RFID Unit.	Check the status of the RFID Unit to confirm that the com- mand is ready for execution, and then execute the function block again.
	16#6AA00000	Antenna Configura- tion Error	An unsupported antenna is con- nected. * Combination of the NX-V680C2 Unit and the V680-H01-V2 Unit	Connect an antenna other than V680-H01-V2 with NX-V680C2. Alternatively, use NX-V680C1.
	16#6AA10000	Amplifier Power Supply Error	No power is supplied to drive the amplifier.	Check the input of the I/O power supply.
	16#6AA20000	Amplifier Discon- nection Detection	An amplifier disconnection is detected. The amplifier could not be rec- ognized.	Connect the amplifier. Alternatively, replace the ampli- fier.
	16#6A720000	RF Tag Missing Error	There is no RF Tag in the com- munications range.	Adjust the equipment so that the RF Tag enters inside the com- munications range.
	16#6A700000 RF Tag Commun cations Failure		An error occurred during com- munications with the RF Tag, preventing a normal end.	Change the movement speed of the RF Tag and the distance between RF Tags so that they are within the specified range.
				Also, implement noise counter- measures if there is excessive ambient noise.
	16#6A760000	RF Tag Data Error	An RF Tag data error has been detected.	Check the data within the data check target range, and make sure no unexpected data has been written.
	16#6A7A0000	RF Tag Address Error	The address of the RF Tag is incorrect.	Check the memory capacity of the RF Tag being used, and cor- rect the specified address so that it is within the range of the memory capacity.

The list of error codes output when this function block ends in an error is shown below.

Expan- sion error code	Expansion error code	Status	Description	Corrective action
16#3D13	16#6A790000	RF Tag Response       The RF Tag returned an erresponse, preventing a normalized end.		Implement noise countermea- sures if there is excessive ambi- ent noise. <sup>1</sup>
	16#6A7F0000     RF Tag Customer       Code Error       16#6AC00000     Undefined Com- mand		Communications were per- formed with an RF Tag that can- not be used.	Change the RF Tag.
			It cannot be executed because it is an undefined command.	Set the correct variables in DeviceVariables.
	16#6AC10000	Invalid Command Parameter	The command cannot be exe- cuted because the command parameter is erroneous.	Set the correct variables in DeviceVariables.
	16#6AC20000 Command Execu- tion Failure		The command cannot be exe- cuted because the command execution conditions have not been established.	Correct to a RF communications option that can be executed for the command.

\*1. Change the RF Tag if the problem is not solved with noise countermeasures.

## Sample programming

# **Program Description**

Read the 16-byte data from memory address 8 of the RF Tag.

## Preconditions


Create device variables for the RFID Unit to be operated, and use external references to the variables in the user program. Refer to the *Sysmac Studio Version 1 Operation Manual* (W504) for details on how to create device variables.


# **Main Variables**

Variable or member	Name	Data Type	Default value	Description
ReadD-	Read Data V680	OmronLib\NX_V680		Function block for implementing
ata_V680_In-	FB	\ReadData_V680		read for the NX-V680
stance				
V680_Ch1_D	Ch1 Device Variable	Omron-		Structure of Ch1 Device Variable
eviceVariables		Lib\NX_V680\sV680		
		DeviceVariables		
R_Data	Buffer for Read Data	ARRAY[08191] OF	16#00	Output variable for ReadD-
		BYTE		ata_V680_Instance
ReadTrig	Read Execution	BOOL	FALSE	The variable is TRUE when read is
	Flag			executed
RFCommuni-	RF Communica-	USINT	0	Set the RF communications option
cationsOption	tions Option			
ReadKind	Read Type	USINT	0	Set the read type
MemoryAddr	Memory Address	UINT	0	Set the communications start
				address
DataSize	Data Size	UINT	0	Set the communications data size

Variable or member	Name	Data Type	Default value	Description
Abort	Execution Stop Flag	BOOL	FALSE	The variable is TRUE when read execution has stopped
SelectUID	Select UID	ARRAY[07] OF BYTE	16#00	Set the UID of the communications target tag
Command- Stage	Command Busy	UINT	0	Execution status of the ST program
Execute	Execution Flag	BOOL	FALSE	Execution status flag in the ST pro- gram
Done	Execution Comple- tion Flag	BOOL		Output variable for <i>ReadD-</i> ata_V680_Instance
Busy	Enable	BOOL		Output variable for <i>ReadD-</i> ata_V680_Instance
Result	Result Flag	BOOL		Output variable for <i>ReadD-</i> ata_V680_Instance
Command- Aborted	Abort Flag	BOOL		Output variable for <i>ReadD-</i> ata_V680_Instance
Error	Error Flag	BOOL		Output variable for <i>ReadD-</i> ata_V680_Instance
Warning	Warning Flag	BOOL		Output variable for <i>ReadD-</i> ata_V680_Instance
ErroriD	Error code	WORD		Output variable for <i>ReadD-</i> ata_V680_Instance
ErrorIDEx	Expansion error code	DWORD		Output variable for <i>ReadD</i> - ata_V680_Instance
RFCommuni- cationsTime	RF Communica- tions Time	UINT		Output variable for <i>ReadD</i> - ata_V680_Instance
NoiseLevel	Noise Level	UINT		Output variable for <i>ReadD</i> - ata_V680_Instance
UID	UID	ARRAY[07] OF BYTE		Output variable for <i>ReadD-</i> ata_V680_Instance

## Ladder Diagram





#### • Code of Inline ST (Zeroth Line of Ladder Diagram):

```
// Read Parameter Setting
RFCommunicationsOption := USINT#0;
ReadKind := USINT#0;
MemoryAddr := UINT#8;
DataSize := UINT#16;
// Communications Target Tag UID Setting (Used only when RF Communications Option =
Selective)
SelectUID[0]:=BYTE#16#66;
SelectUID[1]:=BYTE#16#66;
SelectUID[2]:=BYTE#16#78;
SelectUID[2]:=BYTE#16#4B;
SelectUID[3]:=BYTE#16#4B;
SelectUID[4]:=BYTE#16#65;
SelectUID[5]:=BYTE#16#65;
SelectUID[5]:=BYTE#16#05;
SelectUID[6]:=BYTE#16#06;
SelectUID[7]:=BYTE#16#08;
SelectUID[7]:=BYTE#16#66;
```

#### • Code of Inline ST (First Line of Ladder Diagram):

```
// V680_CH1_IO Parameter Refresh
// Input Parameter Setting
V680_Ch1_DeviceVariables.Status := N1_Ch1_Status;
V680_Ch1_DeviceVariables.Refreshcount := N1_Ch1_Refresh_Count;
V680_Ch1_DeviceVariables.ResponseCode := N1_Ch1_Response_Code;
V680_Ch1_DeviceVariables.InputSID := N1_Ch1_Input_SID;
V680_Ch1_DeviceVariables.InputData1 := N1_Ch1_Input_Data_1;
V680_Ch1_DeviceVariables.UID := N1_Ch1_UID;
V680_Ch1_DeviceVariables.RFCommunicationsTime := N1_Ch1_RF_Communications_Time;
V680_Ch1_DeviceVariables.NoiseLevel := N1_Ch1_Noise_level;
```

#### Code of Inline ST (Third Line of Ladder Diagram):

```
// V680_CH1_IO Parameter Refresh
// Output Parameter Setting
N1_Ch1_Operation_Command := V680_Ch1_DeviceVariables.OperationCommand;
N1_Ch1_RF_Communications_Option := V680_Ch1_DeviceVariables.RFCommunicationsOption;
N1_Ch1_Command_Code := V680_Ch1_DeviceVariables.CommandCode;
N1_Ch1_Memory_Address := V680_Ch1_DeviceVariables.MemoryAddress;
N1_Ch1_Data_Size := V680_Ch1_DeviceVariables.DataSize;
N1_Ch1_Refresh_Count_Response := V680_Ch1_DeviceVariables.RefreshCountResponse;
N1_Ch1_Input_SID_response := V680_Ch1_DeviceVariables.InputSIDResponse;
N1_Ch1_Select_UID := V680_Ch1_DeviceVariables.SelectUID;
```

## ST

```
// V680 CH1 IO Parameter Refresh
// Input Parameter Setting
V680_Ch1_DeviceVariables.Status := N1_Ch1_Status;
V680_Ch1_DeviceVariables.Refreshcount := N1_Ch1_Refresh_Count;
V680 Ch1 DeviceVariables.ResponseCode := N1 Ch1 Response Code;
V680_Ch1_DeviceVariables.InputSID := N1 Ch1 Input SID;
V680 Ch1 DeviceVariables.InputData1 := N1 Ch1 Input Data 1;
V680 Ch1 DeviceVariables.UID := N1 Ch1 UID;
V680 Ch1 DeviceVariables.RFCommunicationTime := N1 Ch1 RF Communications Time;
V680 Ch1 DeviceVariables.NoiseLevel := N1 Ch1 Noise level;
CASE CommandStage OF
   (*Idle*)
   0:
   //\ \mbox{If ReadTrig changes to TRUE, the command is executed}
   IF ( ReadTrig = TRUE ) THEN
       // Read Parameter Setting
       RFCommunicationsOption := USINT#0;
       ReadKind := USINT#0;
       MemoryAddr := UINT#8;
       DataSize := UINT#16;
       // Communications Target Tag UID Setting (Used only when RF Communications
Option = Selective)
       SelectUID[0]:=BYTE#16#66;
       SelectUID[1]:=BYTE#16#78;
       SelectUID[2]:=BYTE#16#2D;
       SelectUID[3]:=BYTE#16#4B;
       SelectUID[4]:=BYTE#16#53;
       SelectUID[5]:=BYTE#16#05;
       SelectUID[6]:=BYTE#16#08;
       SelectUID[7]:=BYTE#16#E0;
       // Read Execution Flag Setting
       Execute := TRUE;
       // Transit to Read Execution Status
       CommandStage := UINT#1;
   END_IF;
   (*Acquisition of read execution result*)
   1 :
   IF (Busy = FALSE) THEN
       IF (Done = TRUE) THEN
       // Normal End
          (* ↑-----↑ *)
          // Transit to Unit Operation Stop Wait Status
          CommandStage := UINT#2;
       ELSIF (Error = TRUE) THEN
          (* ------*)
          (* ↑----- * *)
          // Transit to Unit Operation Stop Wait Status
          CommandStage := UINT#2;
       END IF;
   END IF;
```

```
(*Unit operation stop wait*)
    2 :
    // If ReadTrig changes to FALSE, transition to idle state occurs
    IF ( ReadTrig = FALSE ) THEN
       CommandStage := UINT#0;
        // Read Execution End Flag Setting
       Execute := FALSE;
    END IF;
END CASE;
// Read Data FB
ReadData V680 instance
(
   Execute :=Execute,
   RFCommunicationsOption := RFCommunicationsOption,
   ReadKind := ReadKind,
   MemoryAddr := MemoryAddr,
   DataSize := DataSize,
   Abort := Abort,
    SelectUID := SelectUID,
   Done => Done,
   Busy => Busy,
   Result => Result,
   CommandAborted => CommandAborted,
   Error => Error,
   ErrorID => ErrorID,
   ErrorIDEx => ErrorIDEx,
   Warning => Warning,
   UID => UID,
   RFCommunicationsTime => RFCommunicationsTime,
   NoiseLevel => NoiseLevel,
   DeviceVariables := V680 Ch1 DeviceVariables,
   ReadData := R Data
);
// V680 CH1 IO Parameter Refresh
// Output Parameter Setting
N1 Ch1 Operation Command := V680 Ch1 DeviceVariables.OperationCommand;
N1_Ch1_RF_Communications_Option := V680_Ch1_DeviceVariables.RFCommunicationsOption;
N1_Ch1_Command_Code := V680_Ch1_DeviceVariables.CommandCode;
N1 Ch1 Memory Address := V680 Ch1 DeviceVariables.MemoryAddress;
N1_Ch1_Data_Size := V680_Ch1_DeviceVariables.DataSize;
N1_Ch1_Refresh_Count_Response := V680_Ch1_DeviceVariables.RefreshCountResponse;
N1_Ch1_Input_SID_response := V680_Ch1_DeviceVariables.InputSIDResponse;
N1 Ch1 Select UID := V680 Ch1 DeviceVariables.SelectUID;
```

# WriteData\_V680

This command writes data to the memory of an RF Tag in the communications range of the antenna mounted on the RFID Unit (NX-V680).

Program part names	Series	FB/ FUN	Graphic expression	STexpression
Write-	RF	FB		WriteData_V680_instance(
Data_V680	Tag data			Execute := <parameter>,</parameter>
	write for V680			RFCommunicationsOption := <parameter>,</parameter>
			\\OmronLib\NX_V680\WriteData_V680	WriteKind := <parameter>,</parameter>
				MemoryAddr := <parameter>,</parameter>
			RFCommunicationsOption Busy	DataSize := <parameter>,</parameter>
			WriteKind Result	Abort := <parameter>,</parameter>
			MemoryAddr CommandAborted	SelectUID := <parameter>,</parameter>
			— DataSize Error —	Done => <parameter>,</parameter>
			Abort ErrorID	Busy => <parameter>,</parameter>
			- SelectUID ErrorIDEx	Result => <parameter>,</parameter>
			— DeviceVariables — — DeviceVariables —	CommandAborted => <parame- ter&gt;,</parame- 
			WriteData — WriteData —	Error => <parameter>,</parameter>
			UID—	ErrorID => <parameter>,</parameter>
			RFCommunicationsTime	ErrorIDEx => <parameter>,</parameter>
			NoiseLevel	UID => <parameter>,</parameter>
				RFCommunicationsTime => <parameter>,</parameter>
				NoiseLevel => <parameter>,</parameter>
				WriteData := <parameter>,</parameter>
				DeviceVariables := <parameter>,</parameter>
				);

## **Function Block and Function Information**

ltem	Description
Library file name	OmronLib_NX_V680_Vx_x.slr (x indicates the version)
Namespace	OmronLib\NX_V680
Function block and function	00214
number	
Source code	Do not publish.

## Input variable

Variables	Name	Data Type	Description	Valid range	Unit	Initial value
Execute	Execute	BOOL	The processing is started when	TRUE or		FALSE
			the variable changes to TRUE.	FALSE		
			TRUE: Execute			
			FALSE: Do not execute	-		
RFCommunica-	RF Communica- tions Option	USINT	Specify the operation sequence	0 to 7		0
tionsOption	tions Option		during communications.			
			0: Trigger			
			1: Auto			
			2: Repeat			
			3: FIFO Trigger			
			4: FIFO Repeat			
			5: Multi Trigger			
			6: Multi Repeat			
			7: Selective <sup>*1</sup>			
WriteKind	Write Type	USINT	Specify the type of the write	0 to 2		0
			command. <sup>*2</sup>			
			0: Normal			
			1: With error detection			
			2: With error correction			
MemoryAddr	Memory Address	UINT	Specify the start address of the memory to which data is written	0 to 65535	Byte	0
			from the RF Tag. <sup>*3</sup>			
DataSize	Data Size	UINT	Enter the size of the data to be	1 to 8192	Byte	0
			written from the RF Tag. <sup>*4</sup>			
Abort	Abort	BOOL	The processing is aborted when	TRUE or		FALSE
			the variable changes to TRUE.	FALSE		
SelectUID	Select UID	ARRAY[0 7]OF BYTE	Specify the UID of the communi- cations target RF Tag when the RF communications option is <i>Selective</i> .	Depends on data type.		16#00

\*1. When using Selective, do not add the I/O entry Select UID to a channel used in the RFID Unit.

\*2. Refer to the List of Commands in the *NX-series RFID Units User's Manual* (Z401) for details on the types of write commands and differences in their operation.

\*3. Enter a value in consideration of the memory map of the RF Tag actually used.

\*4. Enter a value in consideration of the memory capacity of the RF Tag actually used. When 0 is specified, no operation is performed and the processing ends.

# **Output Variables**

Variables	Name	Data Type	Description	Valid range	Unit	Initial value
Done	Done	BOOL	The variable changes to TRUE when the processing is completed.	TRUE or FALSE		FALSE
Busy	Busy	BOOL	The variable changes to TRUE when the processing is acknowl-edged.	TRUE or FALSE		FALSE
Result	Result	BOOL	The value of the variable alter- nately changes between TRUE and FALSE each time the result of communications with the RF Tag is output.	TRUE or FALSE		FALSE
Command Aborted	Instruction Aborted	BOOL	The variable changes to TRUE when the processing is aborted.	TRUE or FALSE		FALSE
Error	Error	BOOL	This variable is TRUE while there is an error. TRUE: Error end FALSE: Normal end or Execut- ing	TRUE or FALSE		FALSE
ErroriD	Error code	WORD	An error code is output. This is the error ID for an error end. The value is 16#0 for a normal end.	*1		0
ErrorIDEx	Expansion error code	DWORD	An expansion error code is out- put. This is the error ID for an error end. The value is 16#0 for a normal end.	*1		0
UID <sup>*2</sup>	UID	ARRAY[0 7]OF BYTE	The UID of the RF Tag with which communications are per- formed is output.	Depends on data type.		16#00
RFCommunica- tionsTime <sup>*3</sup>	RF Communica- tions Time	UINT	The measured RF communica- tions time is output.	0 to 65535	ms	0
NoiseLevel <sup>*4</sup>	Noise Level	UINT	The measured noise level is output.	0 to 99		0

\*1. For details, refer to *Troubleshooting* on page 72.

\*2. During use, add the I/O entry UID to the channel used in the RFID Unit.

\*3. During use, add the I/O entry *RF Communications Time* to the channel used in the RFID Unit.

\*4. During use, add the I/O entry Noise Level to the channel used in the RFID Unit.


## **In-Out Variables**

Variables	Name	Data Type	Description	Valid range	Unit	Initial value
DeviceVari-	device variable	Omron-	Device variables of the	Depends on		
ables		Lib\RFID\sNX-	RFID Unit (I/O port of the	data type.		
		V680DeviceV-	input area / output area)	-		
		ariables				
WriteData	Write Data	ARRAY[Vari-	Data array to be written to	Depends on		-
		able length]	the RF Tag	data type.		
		OF BYTE				


Note A BYTE array of any length can be specified. However, the array length must be equal to or more than the DataSize. Both 0 and n can be set for the array start number.

## Operation

This function block controls the command for writing the memory of the RF Tag for an RFID Unit (NX-V680) that is exchanging data with an NJ/NX/NY-series Controller. Therefore, the device variables (the I/O port of the output area and the I/O port of the input area) of the RFID Unit to be controlled must be set in the input/output variable *DeviceVariables* of the function block.




• When *Execute* changes to TRUE, the data of the byte array specified in *WriteData* is written to the memory of the RF Tag.




• The memory capacity written to the RF Tag in a single execution varies depending on the specified *WriteKind*. The values that can be specified in *MemoryAddr* and *DataSize* are described below.

WriteKind	MemoryAddr	DataSize
0: Normal	0 to 65535	1 to 8192
1: With error detection	0 to 65533	1 to 8190
2: With error correction	0 to 65530	1 to 510

• If *WriteKind* is executed as *With error detection*, data is written to the RF Tag target area, and the check code for error detection is written to the last two bytes of the area.



• If *WriteKind* is executed as *With error correction*, data is written to the RF Tag target area, and the check code for error correction is written to the last five bytes of the area.



## **Timing Chart**

The timing charts are shown below.

## Communicating with One RF Tag (RF Communications Option: Trigger, Auto, FIFO trigger or Selective)

If this function block is started by specifying Trigger, Auto, FIFO trigger, or Selective in *RFCommunicationsOption*, the result of communications with one RF Tag present in the communications range of the antenna is output.

#### • Timing Chart for Normal End

- Busy (Executing) changes to TRUE when Execute (Execute) changes to TRUE.
- If writing of data to the memory of the RF Tag ends normally, *Done* changes to TRUE, and *Busy* (Executing) changes to FALSE. At the same time, a data string is output in UID, and a value is output in *RFCommunicationsTime* and *NoiseLevel*.
- If *Execute* remains TRUE even after the execution of this function block is complete, the output value of *Done* is retained.
- If Execute changes to FALSE before the execution of this function block is complete, *Done* changes to TRUE only for one task period after the execution of the function block is complete.

Execute				]	
WriteData	Write	PData	X	WriteData	
Abort					
Done					
Busy					
CommandAborted					
Error					
ErrorID	16#0	0000	×	16#0000	
ErrorIDEx	16#000	00 0000	×	16#0000 0000	
			!		


## • Timing Chart for Error End

- If an error occurs while the execution of this function block is in progress, *Error* changes to TRUE and *Busy* (Executing) changes to FALSE.
- You can find out the cause of the error by accessing the values output to ErrorID (Error Code) and ErrorIDEx (Expansion Error Code).
- If *Execute* remains TRUE even after the execution of this function block is complete, the output value of *Error* is retained.
- The output values of *ErrorID* (Error Code) and *ErrorIDEx* (Expansion Error Code) are retained until this function block is executed again.
- If *Execute* changes to FALSE before the execution of this function block is complete, *Error* changes to TRUE only for one task period after the execution of the function block is complete.

Execute					]	
WriteData	WriteData	1	1		WriteData	
Abort				-		
Done	 1 1 1 1			-		
Busy						1
CommandAborted						
Error				-		
ErrorID	16#0000		ErrorID	$\overline{\mathbf{X}}$	16#0000	ErrorID
ErrorIDEx	16#0000 000		ErrorIDEx	$\mathbf{X}$	16#0000 0000	ErrorIDEx
			1			1

## • When the Function Block Is Aborted

To abort communications with the RF Tag while the execution of this function block is in progress, set *Abort* to TRUE. If *Abort* changes to TRUE, *Busy* (Executing) changes to FALSE and *Command-Aborted* changes to TRUE.




# Communicating with Multiple RF Tags (RF Communications Option: Multi Trigger)

If this function block is started by specifying Multi trigger in *RFCommunicationsOption*, the result of communications with the multiple RF Tags present in the communications range of the antenna is output.


### • Timing Chart for Communications with Multiple RF Tags

- Busy (Executing) changes to TRUE when Execute (Execute) changes to TRUE.
- Each time communications are performed with multiple RF Tags, the *Result* toggles between FALSE -> TRUE -> FALSE -> TRUE.
- When communications with all RF Tags in the communications range are complete, *Done* changes to TRUE and *Busy* (Executing) changes to FALSE.
- If writing of data to the memory of the RF Tag ends normally, a data string is output in UID, and a value is output in *RFCommunicationsTime* and *NoiseLevel* at the same time as a change in *Result*.
- If writing of data to the memory of the RF Tag ends in an error, *Error* changes to TRUE at the same time as a change in *Result*. You can find out the cause of the error by accessing the values output to ErrorID (Error Code) and ErrorIDEx (Expansion Error Code).
- *Result* changes to FALSE at the same time when *Done* changes to FALSE.




### When the Function Block Is Aborted

- To abort communications with the RF Tag while the execution of this function block is in progress, set *Abort* to TRUE. If *Abort* changes to TRUE, *Busy* (Executing) changes to FALSE and *CommandAborted* changes to TRUE.
- Result changes to FALSE at the same time when CommandAborted changes to FALSE.



#### Timing Chart when the Tag is Missing

- If communications are not performed with the RF Tag even once while the execution of this function block is in progress, *Result* and *Error* change to TRUE, and *Busy* (Executing) changes to FALSE.
- You can find out the cause of the error by accessing the values output to ErrorID (Error Code) and ErrorIDEx (Expansion Error Code).
- If *Execute* remains TRUE even after the execution of this function block is complete, the output values of *Result* and *Error* are retained.
- The output values of *ErrorID* (Error Code) and *ErrorIDEx* (Expansion Error Code) are retained until this function block is executed again.
- If *Execute* changes to FALSE before the execution of this function block is complete, *Result* and *Error* change to TRUE only for one task period after the execution of the function block is complete.




# Communicating Repeatedly with an RF Tag (RF Communications Option: Repeat, FIFO Repeat or Multi Repeat)


If this function block is started by specifying Repeat, FIFO repeat, or Multi-access repeat in RFCommunicationsOption (RF Communications Option), the result of repeated communications with an RF Tag that has moved into the communications range of the antenna is output.

## • Timing Chart for Repeated Communications

- Busy (Executing) changes to TRUE when Execute (Execute) changes to TRUE.
- Each time communications are performed with multiple RF Tags, the *Result* toggles between FALSE -> TRUE -> FALSE -> TRUE.
- If writing of data to the memory of the RF Tag ends normally, a data string is output in *ReadData* and UID, and a value is output in *RFCommunicationsTime* and *NoiseLevel* at the same time as a change in *Result*.
- If writing of data to the memory of the RF Tag ends in an error, *Error* changes to TRUE at the same time as a change in *Result*. You can find out the cause of the error by accessing the values output to ErrorID (Error Code) and ErrorIDEx (Expansion Error Code).




- To end repeated communications with an RF Tag, you must set *Abort* to TRUE. If *Abort* changes to TRUE, *Busy* (Executing) changes to FALSE and *CommandAborted* changes to TRUE.
- Result changes to FALSE at the same time when CommandAborted changes to FALSE.



#### • Timing Chart for Error End

- If a specific error occurs while the execution of this function block is in progress, *Error* changes to TRUE and *Busy* (Executing) changes to FALSE, and the repetitive process is aborted.
- Result changes to FALSE at the same time when Error changes to FALSE.
- You can find out the cause of the error by accessing the values output to ErrorID (Error Code) and ErrorIDEx (Expansion Error Code).
- If *Execute* remains TRUE even after the execution of this function block is complete, the output value of *Error* is retained.
- The output values of *ErrorID* (Error Code) and *ErrorIDEx* (Expansion Error Code) are retained until this function block is executed again.
- If *Execute* changes to FALSE before the execution of this function block is complete, *Error* changes to TRUE only for one task period after the execution of the function block is complete.



Note The specific errors due to which repeated communications are stopped are as described below.

Expansion error code	Expansion error code	Status
16#3D14	16#6AA00000	Antenna Configuration Error
	16#6AA10000	Amplifier Power Supply Error
	16#6AA20000	Amplifier Disconnection Detection
	16#6A720000	RF Tag Missing Error

# **Common Behavior**

#### Timing Chart when an Error is Detected during Startup

- If an error is detected when this function block is started, *Error* changes to TRUE. *Busy* (Executing) remains FALSE.
- You can find out the cause of the error by accessing the values output to ErrorID (Error Code) and ErrorIDEx (Expansion Error Code).
- If *Execute* remains TRUE even after the execution of this function block is complete, the output value of *Error* is retained.
- The output values of *ErrorID* (Error Code) and *ErrorIDEx* (Expansion Error Code) are retained until this function block is executed again.

Execute		
Abort		
Done		
Busy		
ReadData		
CommandAborted		
Error		
ErrorID	ErrorID	
ErrorIDEx	ErrorIDEx	
EITOTIDEX		

### **Precautions for Correct Use**

- If the RFID Unit is in the Busy state due to the execution of a command already in progress, *Error* is output as TRUE indicating an error end, and the functions of this function block are not executed.
- When using the RFID Unit (NX-V680C2), integrate the device variables used as the input/output variables for this function block in either channel Ch1 or Ch2. If the device variables of different channels are set together, the operation will not be performed properly.
- Before executing this function block, carefully read the manual of the NX-V680C□ to use and ensure the safety for use.
- If the operation parameter *Data storage order* of the RFID Unit is *Descending*, do not specify the data size of the odd bytes. If you do so, the correct data will not be written to the RF Tag.
- Do not add the I/O entry *Output Data 2 to 8* to a channel used in the RFID Unit. If the total size of the output data increases, correct operation will not be performed.

# Troubleshooting

Expan- sion error code	Expansion error code	Status	Description	Corrective action
16#0000	16#0000000	Normal End		
16#3D14	16#0000001	Invalid RF Commu- nications Option	The value of RFCommunication- sOption is outside the valid range.	Set the correct value in RFCom- municationsOption.
	16#0000002	Invalid Write Type	The value of WriteKind is outside the valid range.	Set the correct value in Write- Kind.
	16#0000003	Invalid Memory Address	The value of MemoryAddr is out- side the valid range.	Set the correct value in Memory- Addr.
	16#00000004	Invalid Data Size	The value of DataSize is outside the valid range.	Set the correct value in Data- Size.
	16#00000005	Invalid Data Array	The array length of WriteData is below DataSize.	Set the array length of Write- Data to DataSize or above.
	16#0000006	Execution Disabled	This function block cannot be started because the command is not ready for execution in the RFID Unit.	Check the status of the RFID Unit to confirm that the com- mand is ready for execution, and then execute the function block again.
	16#6AA00000	Antenna Configura- tion Error	An unsupported antenna is con- nected.	Connect an antenna other than V680-H01-V2 with NX-V680C2.
			* Combination of the NX-V680C2 Unit and the V680-H01-V2 Unit	Alternatively, use NX-V680C1.
	16#6AA10000	Amplifier Power Supply Error	No power is supplied to drive the amplifier.	Check the input of the I/O power supply.
	16#6AA20000	Amplifier Discon- nection Detection	An amplifier disconnection is detected. The amplifier could not be rec- ognized.	Connect the amplifier. Alternatively, replace the ampli- fier.
	16#6A720000	RF Tag Missing Error	There is no RF Tag in the com- munications range.	Adjust the equipment so that the RF Tag enters inside the com- munications range.
	16#6A700000	RF Tag Communi- cations Failure	An error occurred during com- munications with the RF Tag, preventing a normal end.	Change the movement speed of the RF Tag and the distance between RF Tags so that they are within the specified range.
				Also, implement noise counter- measures if there is excessive ambient noise.
	16#6A710000	RF Tag Verification Error	The correct data could not be written to the RF Tag.	Change the movement speed of the RF Tag and the distance between RF Tags so that they are within the specified range.
				Also, implement noise counter- measures if there is excessive ambient noise.

The list of error codes output when this function block ends in an error is shown below.

Expan- sion error code	Expansion error code	Status	Description	Corrective action
16#3D14	16#6A730000	RF Tag Data Loss	Correct data is not written to the RF Tag, and there is a possibility that the data has been lost.	Perform re-processing when the RF Tag exists in the communica- tions range of the reader/writer.
				Change the movement speed of the RF Tag and the distance between RF Tags so that they are within the specified range.
				Also, implement noise counter- measures if there is excessive ambient noise.
	16#6A7A0000	RF Tag Address Error	The address of the RF Tag is incorrect.	Check the memory capacity of the RF Tag being used, and cor- rect the specified address so that it is within the range of the memory capacity.
	16#6A7D0000	RF Tag Write Pro- tect Error	An attempt was made to write to a write-protected area of the RF Tag.	Correct the specified address and number of bytes to the cor- rect value. Alternatively, remove write protection.
	16#6A790000	RF Tag Response Error	The RF Tag returned an error response, preventing a normal end.	Implement noise countermea- sures if there is excessive ambi- ent noise. <sup>1</sup>
	16#6A7E0000	RF Tag Lock Error	An attempt was made to write to a locked area of the RF Tag.	Change the RF Tag.
	16#6A7F0000	RF Tag Customer Code Error	Communications were per- formed with an RF Tag that can- not be used.	Change the RF Tag.
	16#6AC00000	Undefined Com- mand	It cannot be executed because it is an undefined command.	Set the correct variables in DeviceVariables.
	16#6AC10000	Invalid Command Parameter	The command cannot be exe- cuted because the command parameter is erroneous.	Set the correct variables in DeviceVariables.
	16#6AC20000	Command Execu- tion Failure	The command cannot be exe- cuted because the command execution conditions have not been established.	Correct to a RF communications option that can be executed for the command.

\*1. Change the RF Tag if the problem is not solved with noise countermeasures.

## Sample programming

# **Program Description**

Write the 16-byte data to memory address 8 of the RF Tag.

# Preconditions


Create device variables for the RFID Unit to be operated, and use external references to the variables in the user program. Refer to the *Sysmac Studio Version 1 Operation Manual* (W504) for details on how to create device variables.


# Main Variables

Variable or mem- ber	Name	Data Type	Default value	Description
WriteData_V680_In- stance	Write Data V680 FB	OmronLib\NX_V680 \WriteData_V680		Function block for implementing write for the NX-V680
V680_Ch1_Device- Variables	Ch1 Device Variable	Omron- Lib\NX_V680\sV680 DeviceVariables		Structure of Ch1 Device Variable
W_Data	Buffer for Write Data	ARRAY[08191] OF BYTE	16#00	Set the write data
WriteTrig	Write Execution Flag	BOOL	FALSE	The variable is TRUE when write is executed
RFCommunication- sOption	RF Communica- tions Option	USINT	0	Set the RF commu- nications option
WriteKind	Write Type	USINT	0	Set the write type
MemoryAddr	Memory Address	UINT	0	Set the communica- tions start address
DataSize	Data Size	UINT	0	Set the communica- tions data size
Abort	Execution Stop Flag	BOOL	FALSE	The variable is TRUE when write execution has stopped
SelectUID	Select UID	ARRAY[07] OF BYTE	16#00	Set the UID of the communications tar- get tag
CommandStage	Command Busy	UINT	0	Execution status of the ST program
Execute	Execution Flag	BOOL	FALSE	Execution status flag in the ST program
Done	Execution Comple- tion Flag	BOOL		Output variable for WriteData_V680_In- stance
Busy	Enable	BOOL		Output variable for WriteData_V680_In- stance
Result	Result Flag	BOOL		Output variable for WriteData_V680_In- stance

Variable or mem- ber	Name	Data Type	Default value	Description
CommandAborted	Abort Flag	BOOL		Output variable for WriteData_V680_In- stance
Error	Error Flag	BOOL		Output variable for <i>WriteData_V680_In-</i> <i>stance</i>
ErroriD	Error code	WORD		Output variable for <i>WriteData_V680_In-</i> <i>stance</i>
ErrorIDEx	Expansion error code	DWORD		Output variable for WriteData_V680_In- stance
UID	UID	ARRAY[07] OF BYTE		Output variable for <i>WriteData_V680_In-</i> <i>stance</i>
RFCommunications- Time	RF Communica- tions Time	UINT		Output variable for WriteData_V680_In- stance
NoiseLevel	Noise Level	UINT		Output variable for WriteData_V680_In- stance

# Ladder Diagram





#### • Code of Inline ST (Zeroth Line of Ladder Diagram):

```
//Write Parameter Setting
RFCommunicationsOption := USINT#0;
WriteKind := USINT#0;
MemoryAddr := UINT#8;
DataSize := UINT#16;
//Communications Target Tag UID Setting (Used only when RF Communications Option =
Selective)
SelectUID[0]:=BYTE#16#66;
SelectUID[1]:=BYTE#16#78;
SelectUID[2]:=BYTE#16#2D;
SelectUID[3]:=BYTE#16#4B;
SelectUID[4]:=BYTE#16#53;
SelectUID[5]:=BYTE#16#05;
SelectUID[6]:=BYTE#16#08;
SelectUID[7]:=BYTE#16#E0;
//Write Data Setting
W Data[0] := BYTE#16#00;
W Data[1] := BYTE#16#11;
11
       :
11
W Data[15] := BYTE#16#FF;
```

#### • Code of Inline ST (First Line of Ladder Diagram):

```
//V680_CH1_IO Parameter Refresh
//Input Parameter Setting
V680_Ch1_DeviceVariables.Status := N1_Ch1_Status;
V680_Ch1_DeviceVariables.Refreshcount := N1_Ch1_Refresh_Count;
V680_Ch1_DeviceVariables.ResponseCode := N1_Ch1_Response_Code;
V680_Ch1_DeviceVariables.OutputSIDResponse := N1_Ch1_Output_SID_response;
V680_Ch1_DeviceVariables.UID := N1_Ch1_UID;
V680_Ch1_DeviceVariables.RFCommunicationsTime := N1_Ch1_RF_Communications_Time;
V680_Ch1_DeviceVariables.NoiseLevel := N1_Ch1_Noise_level;
```

#### • Code of Inline ST (Third Line of Ladder Diagram):

```
//V680_CH1_IO Parameter Refresh
//Output Parameter Setting
N1_Ch1_Operation_Command := V680_Ch1_DeviceVariables.OperationCommand;
N1_Ch1_RF_Communications_Option := V680_Ch1_DeviceVariables.RFCommunicationsOption;
N1_Ch1_Command_Code := V680_Ch1_DeviceVariables.CommandCode;
N1_Ch1_Memory_Address := V680_Ch1_DeviceVariables.MemoryAddress;
N1_Ch1_Data_Size := V680_Ch1_DeviceVariables.DataSize;
N1_Ch1_Refresh_Count_Response := V680_Ch1_DeviceVariables.RefreshCountResponse;
N1_Ch1_Output_SID := V680_Ch1_DeviceVariables.OutputSID;
N1_Ch1_Output_Data_1 := V680_Ch1_DeviceVariables.OutputData1;
N1_Ch1_Select_UID := V680_Ch1_DeviceVariables.SelectUID;
```

## ST

```
//V680 CH1 IO Parameter Refresh
//Input Parameter Setting
V680_Ch1_DeviceVariables.Status := N1_Ch1_Status;
V680_Ch1_DeviceVariables.Refreshcount := N1_Ch1_Refresh_Count;
V680_Ch1_DeviceVariables.ResponseCode := N1_Ch1_Response_Code;
V680_Ch1_DeviceVariables.OutputSIDResponse := N1_Ch1_Output_SID_response;
V680 Ch1 DeviceVariables.UID := N1 Ch1 UID;
V680 Ch1 DeviceVariables.RFCommunicationsTime := N1 Ch1 RF Communications Time;
V680 Ch1 DeviceVariables.NoiseLevel := N1 Ch1 Noise level;
CASE CommandStage OF
   (*Idle*)
   0 :
   // If WriteTrig changes to TRUE, the command is executed
   IF ( WriteTrig = TRUE ) THEN
       //Write Parameter Setting
       RFCommunicationsOption := USINT#0;
      WriteKind := USINT#0;
      MemoryAddr := UINT#8;
       DataSize := UINT#16;
       //Communications Target Tag UID Setting (Used only when RF Communications
Option = Selective)
       SelectUID[0]:=BYTE#16#66;
       SelectUID[1]:=BYTE#16#78;
       SelectUID[2]:=BYTE#16#2D;
       SelectUID[3]:=BYTE#16#4B;
       SelectUID[4]:=BYTE#16#53;
       SelectUID[5]:=BYTE#16#05;
       SelectUID[6]:=BYTE#16#08;
       SelectUID[7]:=BYTE#16#E0;
       //Write Data Setting
       W Data[0] := BYTE#16#00;
       W Data[1] := BYTE#16#11;
       11
       11
                :
      W Data[15] := BYTE#16#FF;
       //Write Execution Flag Setting
       Execute := TRUE;
       //Transit to Write Execution Status
       CommandStage := UINT#1;
   END_IF;
   (*Write execution result acquisition*)
   1 :
   IF (Busy = FALSE) THEN
       IF (Done = TRUE) THEN
       //Normal End
          (* ______ *)
          //Transit to Unit Operation Stop Wait Status
          CommandStage := UINT#2;
       ELSIF (Error = TRUE) THEN
          (* ------*) Specify error processing.-----*)
          //Transit to Unit Operation Stop Wait Status
          CommandStage := UINT#2;
       END IF;
   END_IF;
```

```
(*Unit operation stop wait*)
    2:
    // If WriteTrig changes to FALSE, transition to idle state occurs
    IF ( WriteTrig = FALSE ) THEN
        CommandStage := UINT#0;
        //Write Execution End Flag Setting
        Execute := FALSE;
    END IF;
END CASE;
//Write Data FB
WriteData V680 instance
(
    Execute :=Execute,
    RFCommunicationsOption := RFCommunicationsOption,
    WriteKind := WriteKind,
    MemoryAddr := MemoryAddr,
    DataSize := DataSize,
    Abort := Abort,
    SelectUID := SelectUID,
    Done => Done,
    Busy => Busy,
    Result => Result,
    CommandAborted => CommandAborted,
    Error => Error,
    ErrorID => ErrorID,
    ErrorIDEx => ErrorIDEx,
    UID => UID,
    RFCommunicationsTime => RFCommunicationsTime,
    NoiseLevel => NoiseLevel,
    DeviceVariables := V680 Ch1 DeviceVariables,
    WriteData := W Data
);
//V680 CH1 IO Parameter Refresh
//Output Parameter Setting
N1 Ch1 Operation Command := V680 Ch1 DeviceVariables.OperationCommand;
N1_Ch1_RF_Communications_Option := V680_Ch1_DeviceVariables.RFCommunicationsOption;
N1_Ch1_Command_Code := V680_Ch1_DeviceVariables.CommandCode;
N1_Ch1_Memory_Address := V680_Ch1_DeviceVariables.MemoryAddress;
N1 Ch1 Data Size := V680 Ch1 DeviceVariables.DataSize;
N1_Ch1_Refresh_Count_Response := V680_Ch1_DeviceVariables.RefreshCountResponse;
N1_Ch1_Output_Data_1 := V680_Ch1_DeviceVariables.OutputData1;
N1_Ch1_Output_SID := V680_Ch1_DeviceVariables.OutputSID;
N1 Ch1 Select UID := V680 Ch1 DeviceVariables.SelectUID;
```

# Appendix

Sysmac Library User's Manual for RFID Communications Library (W609)

# **Referring to Library Information**

When you make an inquiry to OMRON about the library, you can refer to the library information to identify the library to ask about.

The library information is useful in identifying the target library among the libraries provided by OMRON or created by the user.

The library information consists of the attributes of the library and the attributes of function blocks and functions contained in the library.

Attributes of libraries

Information for identifying the library itself

· Attributes of function blocks and functions

Information for identifying the function block and function contained in the library

Use the Sysmac Studio to access the library information.

#### **Attributes of Libraries, Function Blocks and Functions**

The following attributes of libraries, function blocks and functions are provided as the library information.

#### • Attributes of Libraries

No.*1	Attribute	Description
(1)	Library file name	The name of the library file
(2)	Library version	The version of the library
(3)	Author	The name of creator of the library
(4)	Comment	The description of the library <sup>*2</sup>

\*1. These numbers correspond to the numbers shown on the screen images in the next section, *Referring* to Attributes of Libraries, Function Blocks and Functions on page 83.

\*2. It is provided in English and Japanese.

#### • Attributes of Function Blocks and Functions

No.*1	Attribute	Description
(5)	FB/FUN name	The name of the function block or function
(6)	Name space	The name of name space for the function block or function
(7)	FB/FUN version	The version of the function block or function
(8)	Author	The name of creator of the function block or function
(9)	FB/FUN number	The function block number or function number
(10)	Comment	The description of the function block or function <sup>*2</sup>

\*1. These numbers correspond to the numbers shown on the screen images in the next section, *Referring to Attributes of Libraries, Function Blocks and Functions* on page 83.

\*2. It is provided in English and Japanese.


### **Referring to Attributes of Libraries, Function Blocks and Functions**

You can refer to the attributes of libraries, function blocks and functions of the library information at the following locations on the Sysmac Studio.

- Library Reference Dialog Box
- Toolbox Pane
- · Ladder Editor

#### (a) Library Reference Dialog Box


When you refer to the libraries, the library information is displayed at the locations shown below.



(b) Toolbox Pane

Select a function block and function to display its library information at the bottom of the Toolbox Pane.

The text "by OMRON" which is shown on the right of the library name (1) indicates that this library was provided by OMRON.



(c) Ladder Editor

Place the mouse on a function block and function to display the library information in a tooltip.

Section0 - Program0 ×	Toolbox 👻 🖡
Variables	<search></search>
0 In001 In00	OmronLib_BC_DeviceMonitor_V
Instance Name: DataRecorderCSVWrite Instance Type: \\OmronLib\BC_DeviceMonitor\DataRecorderCSVWrite Comment: No.00025 The DataRecorderCSVWrite function block writes the records that are stored in the data rec データレコーダに指納されているレコードを、SD メモリカードにCSV 形式で書き込みます。	corder to an SD Mem (9)FB/FUN number (10)FB/FUN comment

# Referring to Function Block and Function Source Codes

You can refer to the source codes of function blocks and functions provided by OMRON to customize them to suit the user's environment.

User function blocks and user functions can be created based on the copies of these source codes.

The following are the examples of items that you may need to customize.

- · Customizing the size of arrays to suit the memory capacity of the user's Controller
- · Customizing the data types to suit the user-defined data types

Note that you can access only function blocks and functions whose Source code published/not published is set to Published in the library information shown in their individual specifications.

Use the following procedure to refer to the source codes of function blocks and functions.

- Select a function block or function in the program.
- **2** Double-click or right-click and select **To Lower Layer** from the menu.

The source code is displayed.

1

🖶 Secti	ion0 - Program0	DataRecorderCSVWr	/rite···· ×	-
Varia	ables			-
0	Execute	Busy	MOVE EN ENO aRecorder—In Out—WriteDataRecorder In Out—WriteDataRecorder SizeOfDataRecorder.Top > SizeO Control SizeO Con	)fD
1	Execute	FClose.Done	NG Writing EMOVE EN ENO WORD#16#0 In Out ErrorID DWORD#16#0 In Out E	Erro
2			FOpen	

#### Precautions for Correct Use

For function blocks and functions whose source codes are not published, the following dialog box is displayed in the above step 2. Click the **Cancel** button.

