SCARA Robots XC Series

R6Y - XC series

USER'S MANUAL

OMRON

Before using the robot(Be sure to read the following notes.)

At this time, our thanks for your purchase of this OMRON XC series SCARA robot.

1. Please be sure to perform the following tasks before using the robot.

Failing to perform the tasks below will require re-teaching of the robot since the origin position cannot be set to the same previous position. Robot malfunctions (vibration, noise) may also occur.

The origin position of the XC series robots is adjusted to the robot arm extended position at the factory prior to shipment, so the reference or standard coordinates are temporarily set.

The customer should set the origin position before any other job. There are 2 types of origin position settings as shown below.

- [1] Setting the robot arm extended position (the origin position adjusted at the factory prior to shipment) as the origin position (When setting the origin position with the robot arm extended, you must check that there will not be any interference from any peripheral equipment during the next absolute reset.)
- [2] Setting a position **OTHER** than the robot arm extended position (the origin position adjusted at the factory prior to shipment) as the origin position
- [1] To set the robot arm extended position (the origin position adjusted at the factory prior to shipment) as the origin position.

Absolute Reset

The XC series robots only require the absolute reset to be performed once when the robot is introduced.

Once the absolute reset is performed, you do not need to reperform it when the power is turned on next time.

Set the origin position while referring to absolute reset methods in "3. Adjusting the origin" in Chapter 4 of this manual and in "Absolute Reset" of the "OMRON Robot Controller User's Manual". Setting of reference coordinates is not required in the above case.



NEVER ENTER THE ROBOT MOVEMENT RANGE ONCE THE ROBOT SERVO IS TURNED ON AS THIS IS EXTREMELY HAZARDOUS.

[2] To set a position **OTHER** than the robot arm extended position (the origin position adjusted at the factory prior to shipment) as the origin position.

1. Absolute reset

The XC series robots only require the absolute reset to be performed once when the robot is introduced.

Once the absolute reset is performed, you do not need to reperform it when the power is turned on next time.

Set the origin position while referring to absolute reset methods in "3. Adjusting the origin" in Chapter 4 of this manual and in "Absolute Reset" of the "OMRON Robot Controller User's Manual".

Set the origin position with the absolute reset.



NEVER ENTER THE ROBOT MOVEMENT RANGE ONCE THE ROBOT SERVO IS TURNED ON AS THIS IS EXTREMELY HAZARDOUS.

2. Affixing the origin position sticker

Set in emergency stop when absolute reset is complete, and immediately affix the origin point sticker according to instructions in "6. Affixing Stickers for Origin Positions, Movement Directions and Axis Names" in Chapter 4 of this manual.

3. Setting the reference coordinates

Set the reference coordinates while referring to instructions in "5. Setting the Reference Coordinates" in Chapter 4 of this manual and also to "Setting the Reference Coordinates" in the "OMRON Robot Controller User's Manual". Robot malfunctions (vibration, noise) may occur if the reference coordinates

are not set correctly.

Even though there is no problem with the robot, the following error messages are issued when the robot and controller are connected and power first turned on.

(Actual error messages may differ according to how the robot and controller are connected.)

Error messages issued when robot & controller are connected (YRC)

17.81 : D?.ABS.battery wire breakage

17.83 : D?.Backup position data error 1

17.85 : D?.Backup position data error 2

17.92 : D?.Resolver disconnected during power off

17.93 : D?.Position backup counter overflow

etc.

2. If the X, Y or R axis rotation angle is small.

If the X, Y or R axis rotation angle is smaller than 5° so that it always moves in the same position, an oil film is difficult to be formed on the joint support bearing, possibly leading to damage to the bearing. In this type of operation, add a movement so that the joint moves through 90° or more, about 5 times a day.

Copyright

The following shall be described in the Copyright section and the description shall not be changed without permission.

© OMRON, 2010

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form, or by any means, mechanical, electronic, photocopying, recording, or otherwise, without the prior written permission of OMRON.

No patent liability is assumed with respect to the use of the information contained herein. Moreover, because OMRON is constantly striving to improve its high-quality products, the information contained in this manual is subject to change without notice. Every precaution has been taken in the preparation of this manual. Nevertheless, OMRON assumes no responsibility for errors or omissions. Neither is any liability assumed for damages resulting from the use of the information contained in this publication.

Introduction

This user's manual was prepared for XC series ceiling-mount models (R6YXCH250 to R6YXC1000) of the OMRON industrial robots.

This user's manual describes the safety measures, handling, adjustment and maintenance of XC series robots for correct, safe and effective use. Be sure to read this manual carefully before installing the robot. Even after you have read this manual, keep it in a safe and convenient place for future reference.

This user's manual should be used with the robot and considered an integral part of it. When the robot is moved, transferred or sold, send this manual to the new user along with the robot. Be sure to explain to the new user the need to read through this manual.

For the operating or maintenance procedures not described in this manual, please refer to the description of standard models listed in the "OMRON SCARA Robot User's Manual". Also refer to that manual for precautions and warranty. If there are any obscure points in handling the robot, be sure to contact OMRON sales office or dealer.

For details on specific operation and programming of the robot, refer to the separate "OMRON Robot Controller User's Manual".

Disclaimers

CHANGE IN SPECIFICATIONS

Product specifications and accessories may be changed at any time based on improvements and other reasons. It is our practice to change model numbers when published ratings or features are changed, or when significant construction changes are made. However, some specifications of the products may be changed without any notice. When in doubt, special model numbers may be assigned to fix or establish key specifications for your application on your request. Please consult with your OMRON representative at any time to confirm actual specifications of purchased products.

DIMENSIONS AND WEIGHTS

Dimensions and weights are nominal and are not to be used for manufacturing purposes, even when tolerances are shown.

PERFORMANCE DATA

Performance data given in this manual is provided as a guide for the user in determining suitability and does not constitute a warranty. It may represent the result of OMRON's test conditions, and the users must correlate it to actual application requirements. Actual performance is subject to the OMRON Warranty and Limitations of Liability.

ERRORS AND OMISSIONS

The information in this manual has been carefully checked and is believed to be accurate; however, no responsibility is assumed for clerical, typographical, or proofreading errors, or omissions.

CONTENTS

CHAPTER	1	Using the Robot Safely	
		1 Safety Information	1-1
		2 Essential Caution Items	1-2
		3 Special Training for Industrial Robot Operation	1-8
		4 Robot Safety Functions	1-9
		5 Safety Measures for the System	1-10
		5 Trial Operation	1-11
		7 Work Within the Safeguard Enclosure	1-12
		8 Automatic Operation	1-13
		Adjustment and Inspection	1-13
		10 Repair and Modification	1-13
		11 Warranty	1-14
		12 CE Marking	1-16
CHAPTER	2	Functions	
		l Robot Manipulator	2-1
		2 Robot Controller	2-5
CHAPTER	3	Installation	
		Robot Installation Conditions 1-1 Installation environments	
		1-2 Installation base	
		2 Installation	
		2-2 Checking the product	
		2-3 Moving the robot	
		2-3-2 Moving the R6YXC500, R6YXC600, R6YXC700, R6YXC800, F	
		2-4 Installing the robot	3-11
		3 Protective Bonding	3-12
		4 Robot Cable Connection	3-14

	5	User Wiring and User Tubing	3-16
	7	Attaching The End Effector 6-1 R-axis tolerable moment of inertia and acceleration coefficient 6-1-1 Acceleration coefficient vs. moment of inertia (R6YXCH250)	3-203-223-233-243-253-363-463-463-473-51
	/	(Excluding R6YXCH250, R6YXCH350, R6YXCH400)	
CHAPTER 4	8 A	Working Envelope and Mechanical Stopper Positions for Maximum Working Envelope	3-55
	1	Overview	4-1
	2	Safety Precautions	4-1
	3	Adjusting the origin 3-1 Absolute reset method	4-2 4-2 4-2 4-2 4-2
	4	Setting the Soft Limits	4-6
	5	Setting the Standard Coordinates	4-8
	6	Affixing Stickers for Origin Positions, Movement Directions and Axis Names	
		Movement Directions and Axis Names	エ ⁻ ノ

		8	Adjusting the Timing Belt Tension)4-16 4-18
CHAPTER	5	Pe	eriodic Inspecition	
		1	Overview	5-1
		2	Precautions	5-2
		3	Daily Inspection	5-3
		4	Six-Month Inspection	5-5
		5	Replacing the Harmonic Drive	
			5-2 Basic replacement procedure for harmonic drive and precautions	5-9
			5-2-1 R6YXCH250, R6YXCH350, R6YXCH400	5-11
			5-2-2 R6YXC500, R6YXC600	
			5-2-3 R6YXC700, R6YXC800, R6YXC1000	5-42
		6	Replacing the bellows	5-59
CHAPTER	6	Sp	pecifications	
		1	Manipulator	6-1
			1-1 Basic specification	
			1-2 Robot inner wiring diagram	6-4
			1-3 Wiring table	6-6

CHAPTER 1

Using the Robot Safely

1	Safety Information	1-1
2	Essential Caution Items	1-2
3	Special Training for Industrial Robot Operation	1-8
4	Robot Safety Functions	1-9
5	Safety Measures for the System	1-10
6	Trial Operation	1-11
7	Work Within the Safeguard Enclosure	1-12
8	Automatic Operation	1-13
9	Adjustment and Inspection	1-13
10	Repair and Modification	1-13
11	Warranty	1-14
12	CE Marking	1-16

Safety Information 1

Industrial robots are highly programmable, mechanical devices that provide a large degree of freedom when performing various manipulative tasks. To ensure correct and safe use of OMRON industrial robots, carefully read this manual and make yourself well acquainted with the contents. FOLLOW THE WARNINGS, CAUTIONS AND INSTRUCTIONS INCLUDED IN THIS MANUAL. Failure to take necessary safety measures or mishandling due to not following the instructions in this manual may result in trouble or damage to the robot and injury to personnel (robot operator or service personnel) including fatal accidents. Warning information in this manual is shown classified into the following items.



DANGER

FAILURE TO FOLLOW DANGER INSTRUCTIONS WILL RESULT IN SEVERE INJURY OR DEATH TO THE ROBOT OPERATOR, A BYSTANDER OR A PERSON INSPECTING OR REPAIRING THE ROBOT. ADDITIONALLY, THERE MAY BE SEVERE PROPERTY DAMAGE.



WARNING

FAILURE TO FOLLOW WARNING INSTRUCTIONS COULD RESULT IN SEVERE INJURY OR DEATH TO THE ROBOT OPERATOR, A BYSTANDER OR A PERSON INSPECTING OR REPAIRING THE ROBOT. ADDITIONALLY, THERE MAY BE SEVERE PROPERTY DAMAGE..



ACAUTION

FAILURE TO FOLLOW CAUTION INSTRUCTIONS MAY RESULT IN INJURY TO THE ROBOT OPERATOR, A BYSTANDER OR A PERSON INSPECTING OR REPAIRING THE ROBOT, OR DAMAGE TO THE ROBOT AND/OR ROBOT CONTROLLER.



NOTE

Explains the key point in the operation in a simple and clear manner.

Refer to the instruction manual by any of the following methods to operate or adjust the robot safely and correctly.

- 1. Operate or adjust the robot while referring to the printed version of the instruction manual (available for an additional fee).
- 2. Operate or adjust the robot while viewing the CD-ROM version of the instruction manual on your computer screen.
- 3. Operate or adjust the robot while referring to a printout of the necessary pages from the CD-ROM version of the instruction manual.

It is not possible to detail all safety items within the limited space of this manual. So it is essential that the user have a full knowledge of basic safety rules and also that the operator makes correct judgments on safety procedures during operation. This manual and warning labels supplied with or affixed to the robot are written in English.

2 Essential Caution Items

Particularly important cautions for handling or operating the robot are described below. In addition, safety information about installation, operation, inspection and maintenance is provided in each chapter. Be sure to comply with these instructions to ensure safe use of the robot.

(1) Observe the following cautions during automatic operation.

Warning labels 1 (Fig. 1-1) are affixed to the robot. See Fig. 2-2 to Fig. 2-4 for the locations of warning labels.

- Install a safeguard enclosure (protective enclosure) to keep any person from entering within the movement range of the robot and suffering injury due to being struck by moving parts.
- Install a safety interlock that triggers emergency stop when the door or panel is opened.
- Install safeguards so that no one can enter inside except from doors or panels equipped with safety interlocks.
- The warning labels shown in Fig. 1-1 are supplied with the robot and should be affixed to a conspicuous spot on doors or panels equipped with safety interlocks.



SERIOUS INJURY OR DEATH WILL RESULT FROM IMPACT WITH MOVING ROBOT.

- KEEP OUTSIDE OF GUARD DURING OPERATION.
- LOCK OUT POWER BEFORE APPROACHING ROBOT.


(2) Use caution to prevent hands or fingers from being pinched or crushed.

Warning labels 2 (Fig. 1-2) are affixed to the robot. See Fig. 2-2 to Fig. 2-4 for the locations of warning labels.


Be careful not to let hands or fingers be pinched or crushed by the moving parts of the robot during transportation or teaching.



MOVING PARTS CAN PINCH OR CRUSH. KEEP HANDS AWAY FROM ROBOT ARMS.



■Fig. 1-1 Warning label 1



■Fig. 1-2 Warning label 2

(3) Follow the instructions on warning labels and in this manual.

Warning label 3 (Fig. 1-3) is affixed to the robot. See Fig. 2-2 to Fig. 2-4 for the locations of warning labels.

- Be sure to read the warning label and this manual carefully and make you thoroughly understand the contents before attempting installation and operation of the robot.
- Before starting the robot operation, even after you have read through this manual, read again the corresponding procedures and cautions in this manual as well as descriptions in this chapter (Chapter 1, "Using the Robot Safely").
- Never install, adjust, inspect or service the robot in any manner that does not comply with the instructions in this manual.



IMPROPER INSTALLATION OR OPERATION CAN RESULT IN SERIOUS INJURY OR DEATH.

READ USER'S MANUAL AND ALL WARNING LABELS BEFORE OPERATION.




Improper Installation or operation can result in serious injury or death. Read user's (owner's) manual and all warning labels before operation.

■Fig. 1-3 Warning label 3

(4) Do not use the robot in environments containing inflammable gas, etc.



- THIS ROBOT WAS NOT DESIGNED FOR OPERATION IN ENVIRONMENTS WHERE INFLAMMABLE OR EXPLOSIVE SUBSTANCES ARE PRESENT.
- DO NOT USE THE ROBOT IN ENVIRONMENTS CONTAINING INFLAMMABLE GAS, DUST OR LIQUIDS. EXPLOSIONS OR FIRE COULD OTHERWISE RESULT.
- (5) Do not use the robot in locations possibly subject to electromagnetic interference, etc.



(6) Use caution when releasing the Z-axis (vertical axis) brake. WARNING

THE Z-AXIS WILL SLIDE DOWN WHEN THE Z-AXIS BRAKE IS RELEASED, CAUSING A HAZARDOUS SITUATION.

- •PRESS THE EMERGENCY STOP BUTTON AND PROP UP THE Z-AXIS WITH A SUPPORT STAND BEFORE RELEASING THE BRAKE.
- •USE CAUTION NOT TO LET YOUR BODY GET CAUGHT BETWEEN THE Z-AXIS AND INSTALLATION BASE WHEN RELEASING THE BRAKE TO PERFORM DIRECT TEACH.
- (7) Provide safety measures for end effector (gripper, etc.).



- END EFFECTORS MUST BE DESIGNED AND MANUFACTURED SO THAT THEY CAUSE NO HAZARDS (FOR EXAMPLE, LOOSENING OF WORKPIECE) EVEN IF POWER (ELECTRICITY, AIR PRESSURE, ETC.) IS SHUT OFF OR POWER FLUCTUATIONS OCCUR.
- •IF THERE IS A POSSIBLE DANGER THAT THE OBJECT GRIPPED BY THE END EFFECTOR MAY FLY OFF OR DROP, THEN PROVIDE APPROPRIATE SAFETY PROTECTION TAKING INTO ACCOUNT THE OBJECT SIZE, WEIGHT, TEMPERATURE AND CHEMICAL PROPERTIES.
- (8) Be cautious of possible Z-axis movement when the controller is turned off or emergency stop is triggered. (2-axis robots with air-driven Z-axis)



THE Z-AXIS MOVES UP WHEN THE POWER TO THE CONTROLLER OR PLC IS TURNED OFF, THE PROGRAM IS RESET, EMERGENCY STOP IS TRIGGERED, OR AIR IS SUPPLIED TO THE SOLENOID VALVE FOR THE Z-AXIS AIR CYLINDER.

- •DO NOT LET HANDS OR FINGERS GET CAUGHT AND SQUEEZED BY MOVING PARTS OF THE Z-AXIS.
- •KEEP THE USUAL ROBOT POSITION IN MIND SO THAT THE Z-AXIS WILL NOT INTERFERE WITH OBSTACLES DURING RAISING OF THE Z-AXIS. EXCEPT IN CASE OF EMERGENCY STOP.
- (9) Use the following caution items when the Z-axis is interfering with peripheral equipment. (2-axis robots with air driven Z-axis)

MWARNING

WHEN THE Z-AXIS COMES TO A STOP DUE TO OBSTRUCTIONS FROM PERIPHERAL EQUIPMENT, THE Z-AXIS MAY MOVE SUDDENLY WHEN THE OBSTRUCTION IS REMOVED, CAUSING INJURY SUCH AS PINCHED OR CRUSHED HANDS.

- •TURN OFF THE CONTROLLER AND REDUCE THE AIR PRESSURE BEFORE ATTEMPTING TO REMOVE THE OBSTRUCTION.
- •BEFORE REDUCING THE AIR PRESSURE, PLACE A SUPPORT STAND UNDER THE Z-AXIS BECAUSE IT WILL DROP UNDER ITS OWN WEIGHT.

(10) Use caution on Z-axis movement when air supply is stopped. (2-axis robots with air-driven Z-axis)



WARNING

THE Z-AXIS MAY SUDDENLY DROP WHEN THE AIR PRESSURE TO THE Z-AXIS AIR CYLINDER SOLENOID VALVE IS REDUCED, CREATING A HAZARDOUS SITUATION.

TURN OFF THE CONTROLLER AND PLACE A PROP OR SUPPORT UNDER THE Z-AXIS BEFORE CUTTING OFF THE AIR SUPPLY.

(11) Use the following caution items when disassembling or replacing the pneumatic equipment.



⚠ WARNING

AIR OR PARTS MAY FLY OUTWARDS IF PNEUMATIC EQUIPMENT IS DISASSEMBLED OR PARTS REPLACED WHILE AIR IS STILL SUPPLIED.

- DO SERVICE WORK AFTER FIRST TURNING OFF THE CONTROLLER AND REDUCING THE AIR PRESSURE.
- BEFORE REDUCING THE AIR PRESSURE, PLACE A SUPPORT STAND UNDER THE Z-AXIS (2-AXIS ROBOTS WITH AIR DRIVEN Z-AXIS) SINCE IT WILL DROP UNDER ITS OWN WEIGHT.
- (12) Use the following caution items when removing the Z-axis motor.



WARNING

THE Z-AXIS WILL DROP WHEN THE Z-AXIS MOTOR IS REMOVED, POSSIBLY RESULTING IN INJURY.

- •TURN OFF THE CONTROLLER AND SET A SUPPORT STAND UNDER THE Z-AXIS BEFORE REMOVING THE MOTOR.
- •USE CAUTION NOT TO ALLOW HANDS OR BODY TO BE SOUEEZED OR CRUSHED BY MOVING PARTS ON THE Z-AXIS OR BETWEEN THE Z-AXIS AND THE INSTALLATION BASE.
- (13) Use the following caution during inspection of controller.



⚠ WARNING

- WHEN YOU NEED TO TOUCH THE TERMINALS OR CONNECTORS ON THE OUTSIDE OF THE CONTROLLER DURING INSPECTION, ALWAYS FIRST TURN OFF THE CONTROLLER POWER SWITCH AND ALSO THE POWER SOURCE IN ORDER TO PREVENT POSSIBLE ELECTRICAL SHOCK.
- NEVER TOUCH ANY INTERNAL PARTS OF THE CONTROLLER.

For precautions on handling the controller, refer to the "OMRON Robot Controller User's Manual".

(14) Consult	t us f	or	corrective	action	when	the	robot	is	damaged	\mathbf{or}	mal-
function	ı occı	urs									

	Δ	١.
_/	1	\

WARNING

IF ANY PART OF THE ROBOT IS DAMAGED OR ANY MALFUNCTION OCCURS. CONTINUOUS OPERATION MAY BE VERY DANGEROUS. PLEASE CONSULT OMRON DEALER FOR CORRECTIVE ACTION.

Damage or Trouble	Possible Danger
Damage to machine harness or robot cable	Electrical shock, malfunction of robot
Damage to exterior of robot	Flying outwards of damaged parts during robot operation
Abnormal operation of robot (positioning error, excessive vibration, etc.)	Malfunction of robot
Z-axis brake trouble	Dropping of load

(15) Use caution not to touch the controller rear panel cooling fan.



WARNING

- BODILY INJURY MAY OCCUR FROM COMING INTO CONTACT WITH THE COOLING FAN WHILE IT IS ROTATING.
- •WHEN REMOVING THE FAN COVER FOR INSPECTION, FIRST TURN OFF THE CONTROLLER AND MAKE SURE THE FAN HAS STOPPED.
- (16) Use caution not to touch the high temperature motor or speed reduction gear casing.



WARNING

THE MOTOR AND SPEED REDUCTION GEAR CASING ARE EXTREMELY HOT AFTER AUTOMATIC OPERATION, SO BURNS MAY OCCUR IF THESE ARE TOUCHED.

BEFORE TOUCHING THESE PARTS DURING INSPECTIONS OR SERVICING, TURN OFF THE CONTROLLER, WAIT FOR A WHILE AND CHECK THAT THE TEMPERATURE HAS COOLED.

(17) Do not remove, alter or stain the warning labels.



WARNING

IF WARNING LABELS ARE REMOVED OR DIFFICULT TO SEE, NECESSARY CAUTIONS MAY NOT BE TAKEN, RESULTING IN AN ACCIDENT.

- •DO NOT REMOVE, ALTER OR STAIN THE WARNING LABELS ON THE ROBOT.
- DO NOT ALLOW THE WARNING LABELS TO BE HIDDEN BY THE DEVICE INSTALLED TO THE ROBOT BY THE USER.
- PROVIDE PROPER LIGHTING SO THAT THE SYMBOLS AND INSTRUCTIONS ON THE WARNING LABELS CAN BE CLEARLY SEEN EVEN FROM THE OUTSIDE OF SAFEGUARDS.

(18) Protective bonding



WARNING

BE SURE TO GROUND THE ROBOT AND CONTROLLER TO PREVENT ELECTRICAL SHOCK.

(19) Be sure to make correct parameter settings.

CAUTION

THE ROBOT MUST BE OPERATED WITH CORRECT TOLERABLE MOMENT OF INERTIA AND ACCELERATION COEFFICIENTS ACCORDING TO THE MANIPULATOR TIP MASS AND MOMENT OF INERTIA. IF THIS IS NOT OBSERVED, PREMATURE END TO THE LIFE OF THE DRIVE UNITS, DAMAGE TO THE ROBOT PARTS OR RESIDUAL VIBRATION DURING POSITIONING MAY RESULT.

(20) Do not use the robot for tasks requiring motor thrust.



CAUTION

AVOID USING THE XC SERIES ROBOTS FOR TASKS WHICH MAKE USE OF MOTOR THRUST (PRESS-FITTING, BURR REMOVAL, ETC.). THESE TASKS MAY CAUSE MALFUNCTIONS OF THE ROBOT.

(21) If the X, Y or R axis rotation angle is small



CAUTION

IF THE X, Y OR R AXIS ROTATION ANGLE IS SMALLER THAN 5° SO THAT IT ALWAYS MOVES IN THE SAME POSITION, AN OIL FILM IS DIFFICULT TO BE FORMED ON THE JOINT SUPPORT BEARING, POSSIBLY LEADING TO DAMAGE TO THE BEARING. IN THIS TYPE OF OPERATION, ADD A MOVEMENT SO THAT THE JOINT MOVES THROUGH 90° OR MORE, ABOUT 5 TIMES A DAY.

3 Special Training for Industrial Robot Operation

Companies or factories using industrial robots must make sure that every person, who handles the robot such as for teaching, programming, movement check, inspection, adjustment and repair, has received appropriate training and also has the skills needed to perform the job correctly and safely.

Since the XC series robots fall under the industrial robot category, the user must observe local regulations and safety standards for industrial robots, and provide special training for every person involved in robot-related tasks (teaching, programming, movement check, inspection, adjustment, repair, etc.).

4 Robot Safety Functions

(1) Overload detection

This function detects an overload applied to the motor and shuts off the servo power. If an overload error occurs, take the following measures.

- 1. Insert a timer in the program.
- 2. Reduce the acceleration coefficient.

(2) Overheat detection

This function detects an abnormal temperature rise in the driver inside the controller and shuts off the servo power. If an overheat error occurs, take the following measures.

- 1. Insert a timer in the program.
- 2. Reduce the acceleration coefficient.

(3) Soft limits

Soft limits can be set on each axis to limit the working envelope in manual operation after return-to-origin and during automatic operation. Note: The working envelope is the area limited by soft limits.

(4) Mechanical stoppers

If the servo power is suddenly shut off during high-speed operation by emergency stop or safety functions, these mechanical stoppers prevent the axis from exceeding the movement range. The movement ranges of the X-axis arm can be limited as needed by use of mechanical stoppers. (Excluding the R6YXCH250, R6YXCH350 and R6YXCH400)

On the Y-axis arm, mechanical stoppers are fixed at both ends of the maximum movement range.

The Z-axis has a mechanical stopper at the upper end and lower end. No mechanical stopper is provided on the R-axis.

Note: The movement range is the area limited by mechanical stoppers.



AXIS MOVEMENT WILL NOT STOP IMMEDIATELY AFTER THE SERVO POWER SUPPLY IS SHUT OFF BY EMERGENCY STOP OR OTHER SAFETY FUNCTIONS.

(5) Z-axis (vertical axis) brake

An electromagnetic brake is installed on the Z-axis to prevent the Z-axis from sliding down when servo power is turned off. This brake is working when the controller is off or the Z-axis servo power is off even when the controller is on. The Z-axis brake can be released by means of the programming box or by a command in the program when the controller is on.



THE Z-AXIS WILL SLIDE DOWN WHEN THE Z-AXIS BRAKE IS RELEASED, CREATING A HAZARDOUS SITUATION.

- PRESS THE EMERGENCY STOP BUTTON AND PROP THE Z-AXIS WITH A SUPPORT STAND BEFORE RELEASING THE BRAKE.
- USE CAUTION NOT TO LET YOUR BODY GET CAUGHT BETWEEN THE Z-AXIS AND INSTALLATION BASE WHEN RELEASING THE BRAKE TO PERFORM DIRECT TEACH.

5 Safety Measures for the System

Since the robot is commonly used in conjunction with an automated system, dangerous situations are more likely to occur from the automated system than from the robot itself. Accordingly, appropriate safety measures must be taken on the part of the system manufacturer according to the individual system. The system manufacturer should provide a proper instruction manual for safe, correct operation and servicing of the system.

6 Trial Operation

After making installations, adjustments, inspections, maintenance or repairs to the robot, make a trial run using the following procedures.

- (1) If a safeguard enclosure has not yet been provided right after installation of the robot, rope off or chain off around the movement area of the manipulator in place of the safeguard enclosure, and observe the following points.
 - 1. Use sturdy, stable posts which will not fall over easily.
 - 2. The rope or chain should be easily visible by everyone around the robot.
 - 3. Place a sign to keep the operator or other personnel from entering the movement range of the manipulator.
- (2) Check the following points before turning on the controller.
 - 1. Is the robot securely and correctly installed?
 - 2. Are the electrical connections to the robot correct?
 - 3. Are items such as air pressure correctly supplied?
 - 4. Is the robot correctly connected to peripheral equipment?
 - 5. Have safety measures (safeguard enclosure, etc.) been taken?
 - 6. Does the installation environment meet the specified standards?
- (3) After the controller is turned on, check the following points from outside the safeguard enclosure.
 - 1. Does the robot start and stop as intended? Can the operation mode be selected correctly?
 - 2. Does each axis move as intended within the soft limits?
 - 3. Does the end effector move as intended?
 - 4. Are the signal transmissions to the end effector and peripheral equipment correct?
 - 5. Does emergency stop work?
 - 6. Are the teaching and playback functions normal?
 - 7. Are the safeguard enclosure and interlock working as intended?
 - 8. Does the robot move correctly during automatic operation?

7 Work Within the Safeguard Enclosure

- (1) When work is required inside the safeguard enclosure, always turn off the controller and place a sign indicating that the robot is being adjusted or serviced in order to keep any other person from touching the controller switch or operation panel, except for the following cases.
 - 1) Origin position setting (See Section 3 in Chapter 4.)
 - 2) Soft limit settings (See Section 4 in Chapter 4.)
 - 3) Standard coordinate settings (See Section 5 in Chapter 4.)
 - 4) Teaching

For items 1) to 3), follow the precautions and procedure for each section. To perform item 4), refer to the description in (2) below.

(2) Teaching

When performing teaching within the safeguard enclosure, comply with the instructions listed below.

- 1) Check or perform the following points from outside the safeguard enclosure.
 - 1. Make sure that no hazards are present within the safeguard enclosure by a visual check.
 - 2. Check that the programming box (PB) operates correctly.
 - 3. Check that no failures are found in the robot.
 - 4. Check that emergency stop works correctly.
 - 5. Select teaching mode and prohibit automatic operation.
- 2) Never enter the movement range of the manipulator while within the safeguard enclosure.

8 Automatic Operation

Automatic operation described here includes all operations in AUTO mode.

- (1) Check the following before starting automatic operation.
 - 1. No one is within the safeguard enclosure.
 - 2. The programming box and tools are in their specified locations.
 - 3. The alarm or error lamps on the robot and peripheral equipment do not flash.
 - 4. The safeguard enclosure is securely installed with safety interlocks actuated.
- (2) Observe the following during automatic operation or in cases where an error occurs.
 - 1) After automatic operation has started, check the operation status and warning lamp to ensure that the robot is in automatic operation.
 - 2) Never enter the safeguard enclosure during automatic operation.
 - 3) If an error occurs in the robot or peripheral equipment, observe the following procedure before entering the safeguard enclosure.
 - 1. Press the emergency stop button to set the robot to emergency stop.
 - 2. Place a sign on the start switch, indicating that the robot is being inspected in order to keep any other person from touching the start switch and restarting the robot.

9 Adjustment and Inspection

Do not attempt any installation, adjustment, inspection or maintenance unless it is described in this manual.

10 Repair and Modification

Do not attempt any repair, parts replacement and modification unless described in this manual. These works require technical knowledge and skill, and may also involve work hazards.

Warranty

The OMRON robot and/or related product you have purchased are warranted against the defects or malfunctions as described below.

Warranty description : If a failure or breakdown occurs due to

defects in materials or workmanship in the genuine parts constituting this OMRON robot and/or related product within the warranty period, then OMRON shall supply free of charge the necessary replacement/repair parts.

Warranty Period : The warranty period ends 24 months after the

date of manufacturing as shown on the

products.

Exceptions to the Warranty

: This warranty will not apply in the following cases:

- (1) Fatigue arising due to the passage of time, natural wear and tear occurring during operation (natural fading of painted or plated surfaces, deterioration of parts subject to wear, etc.)
- (2) Minor natural phenomena that do not affect the capabilities of the robot and/or related product (noise from computers, motors, etc.).
- (3) Programs, point data and other internal data that were changed or created by the user.

Failures resulting from the following causes are not covered by warranty.

- 1) Damage due to earthquakes, storms, floods, thunderbolt, fire or any other natural or man-made disasters.
- 2) Troubles caused by procedures prohibited in this manual.
- 3) Modifications to the robot and/or related product not approved by OMRON or OMRON sales representatives.
- 4) Use of any other than genuine parts and specified grease and lubricants.
- 5) Incorrect or inadequate maintenance and inspection.
- 6) Repairs by other than authorized dealers.

WARRANTY

OMRON's exclusive warranty is that the products are free from defects in materials and workmanship for a period of one year (or other period if specified) from date of sale by OMRON.

OMRON MAKES NO WARRANTY OR REPRESENTATION, EXPRESS OR IMPLIED, REGARDING NONINFRINGEMENT, MERCHANTABILITY, OR FITNESS FOR PARTICULAR PURPOSE OF THE PRODUCTS. ANY BUYER OR USER ACKNOWLEDGES THAT THE BUYER OR USER ALONE HAS DETERMINED THAT THE PRODUCTS WILL SUITABLY MEET THE REQUIREMENTS OF THEIR INTENDED USE. OMRON DISCLAIMS ALL OTHER WARRANTIES, EXPRESS OR IMPLIED.

LIMITATIONS OF LIABILITY

OMRON SHALL NOT BE RESPONSIBLE FOR SPECIAL, INDIRECT, OR CONSEQUENTIAL DAMAGES, LOSS OF PROFITS OR COMMERCIAL LOSS IN ANY WAY CONNECTED WITH THE PRODUCTS, WHETHER SUCH CLAIM IS BASED ON CONTRACT, WARRANTY, NEGLIGENCE, OR STRICT LIABILITY.

In no event shall the responsibility of OMRON for any act exceed the individual price of the product on which liability is asserted.

IN NO EVENT SHALL OMRON BE RESPONSIBLE FOR WARRANTY, REPAIR, OR OTHER CLAIMS REGARDING THE PRODUCTS UNLESS OMRON'S ANALYSIS CONFIRMS THAT THE PRODUCTS WERE PROPERLY HANDLED, STORED, INSTALLED, AND MAINTAINED AND NOT SUBJECT TO CONTAMINATION, ABUSE, MISUSE, OR INAPPROPRIATE MODIFICATION OR REPAIR.

12 **CE Marking**

When the OMRON robots are exported to or used in EU (European Union) countries, refer to the separate "OMRON Robot Controller User's Manual" or "CE marking Supplement Manual" for related information about CE marking.

Functions

1	Robot Manipulator	2-	1
2	Robot Controller.	2-	5

1 Robot Manipulator

The XC series robots are available in 4-axis models having an X/Y-axis arm (equivalent to human arm) and a Z/R-axis (equivalent to human wrist).

With these 4 axes, the XC series robots can move as shown in Fig. 2-1. By attaching different types of end effector (gripper) to the end of the arm, a wide range of tasks can be performed with high precision at high speeds.

The (+) and (-) signs show the direction of axis movement when the jog keys on the programming box are pressed (standard setting at the factory). Fig. 2-2 to Fig. 2-4 on the subsequent pages show part names and functions of each robot model.




Fig. 2-1 Manipulator movement




Fig. 2-2 R6YXCH250, R6YXCH350, R6YXCH400





Fig. 2-3 R6YXC500, R6YXC600






Fig. 2-4 R6YXC700, R6YXC800, R6YXC1000

2 Robot Controller

The XC series robot comes supplied with a robot controller YRC. For more details, refer to the separate "OMRON Robot Controller User's Manual".




Fig. 2-5 Robot controller

Installation

1	KOUG	ot mstanation conditions	3-1
	1-1	Installation environments	3-1
	1-2	Installation base	3-3
2	Insta	llation	3-5
	2-1	Unpacking	3-5
	2-2	Checking the product	3-6
	2-3	Moving the robot	3-7
		2-3-1 Moving the R6YXCH250, R6YXCH350, R6YXCH400	3-7
		2-3-2 Moving the R6YXC500, R6YXC600, R6YXC700, R6YXC800, R6YX	C1000 3-8
	2-4	Installing the robot	3-11
3	Prote	ective Bonding	3-12
4	Robo	ot Cable Connection	3-14
5	User	Wiring and User Tubing	3-16
6	Atta	ching The End Effector	3-20
	6-1	R-axis tolerable moment of inertia and acceleration coefficient	3-20
		6-1-1 Acceleration coefficient vs. moment of inertia (R6YXCH250)	3-22
		6-1-2 Acceleration coefficient vs. moment of inertia (R6YXCH350)	3-23
		6-1-3 Acceleration coefficient vs. moment of inertia (R6YXCH400)	3-24
		6-1-4 Acceleration coefficient vs. moment of inertia (R6YXC500)	3-25
		6-1-5 Acceleration coefficient vs. moment of inertia (R6YXC600)	3-28
		6-1-6 Acceleration coefficient vs. moment of inertia (R6YXC700)	3-31
		6-1-7 Acceleration coefficient vs. moment of inertia (R6YXC800)	3-36
		6-1-8 Acceleration coefficient vs. moment of inertia (R6YXC1000)	3-41
	6-2	Equation for moment of inertia calculation	3-46
	6-3	Example of moment of inertia calculation	
	6-4	Attaching the end effector	3-47
	6-5	Gripping force of end effector	
7	Limi	ting the Movement Range with X-Axis Mechanical Stoppe	ers
	(Exc	cluding R6YXCH250, R6YXCH350, R6YXCH400)	3-52
8		king Envelope and Mechanical Stopper Positions for	
	Max	imum Working Envelope	3-55

Robot Installation Conditions 1

1-1 **Installation environments**

Be sure to install the robot in the following environments.

Items	Specifications			
Allowable ambient temperature	0 to 40°C			
Allowable ambient humidity	35 to 85% RH (non condensation)			
Altitude	0 to 1000 meters above sea level			
Ambient environments	Avoid installing near water, cutting water, oil, dust, metallic chips and organic solvent.			
	Avoid installation near corrosive gas and corrosive materials.			
	Avoid installation in atmosphere containing inflammable gas, dust or liquid.			
	Avoid installation near objects causing electromagnetic interference, electrostatic discharge or radio frequency interference.			
Vibration	Do not subject to impacts or vibrations.			
Air supply pressure, etc.	Below 0.58MPa (6.0kgf/cm ₂); clean dry air not containing deteriorated compressor oil; filtration 40μm or less			
Working space	Allow sufficient space margin to perform jobs (teaching, inspection, repair, etc.)			

For detailed information on how to install the robot controller, refer to the separate "OMRON Robot Controller User's Manual".



⚠ WARNING

AVOID INSTALLING THE ROBOT IN LOCATIONS WHERE THE AMBIENT CONDITIONS MAY EXCEED THE ALLOWABLE TEMPERATURE OR HUMIDITY, OR IN ENVIRONMENTS WHERE WATER, CORROSIVE GASES, METALLIC POWDER OR DUST ARE GENERATED. MALFUNCTION, FAILURE OR SHORT CIRCUITS MAY OTHERWISE RESULT.

WARNING

- THIS ROBOT WAS NOT DESIGNED FOR OPERATION IN ENVIRONMENTS WHERE INFLAMMABLE OR EXPLOSIVE SUBSTANCES ARE PRESENT.
- •DO NOT USE THE ROBOT IN ENVIRONMENTS CONTAINING INFLAMMABLE GAS, DUST OR LIQUIDS. EXPLOSIONS OR FIRE COULD OTHERWISE RESULT.

WARNING

AVOID USING THE ROBOT IN LOCATIONS SUBJECT TO ELECTROMAGNETIC INTERFERENCE, ELECTROSTATIC DISCHARGE OR RADIO FREQUENCY INTERFERENCE. MALFUNCTION MAY OTHERWISE OCCUR.



DO NOT USE THE ROBOT IN LOCATIONS SUBJECT TO EXCESSIVE VIBRATION. ROBOT INSTALLATION BOLTS MAY OTHERWISE BECOME LOOSE CAUSING THE MANIPULATOR TO FALL OVER.

1-2 Installation base

1) Prepare a sufficiently rigid and stable installation base, taking account of the robot weight including the end effector (gripper), workpiece and reaction force while the robot is operating. The maximum reaction force (see Fig. 3-1) applied to the X-axis and Z-axis of each robot during operation is shown in the table below. These values are an instantaneous force applied to the robot during operation and do not indicate the maximum load capacity.

The maximum reaction force

Fxmax **M**xmax **Fzmax** Robot Model Ν kgf Nm kgfm Ν kgf R6YXCH250 R6YXCH350 R6YXCH400 R6YXC500 R6YXC600 R6YXC700 R6YXC800 R6YXC1000




Fig. 3.1 Maximum reaction force applied during operation

- 2) The parallelism of the installation base surface must be machined within a precision of ± 0.05 mm/500mm. The robot base mount must be installed facing down and in a level position (except ceiling-mount models which should be installed with the base mount facing up).
- 3) Tap holes into the surface of the installation base. For machining dimensions and positions, refer to the dimensional outlines listed in our robot catalog.

4) Securely fix the installation base on the floor with anchor bolts.

WARNING

DO NOT PLACE THE ROBOT ON A MOVING INSTALLATION BASE. EXCESSIVE LOADS WILL BE APPLIED TO THE ROBOT ARM BY MOVEMENT OF THE INSTALLATION BASE, RESULTING IN DAMAGE TO THE ROBOT.

CAUTION

THE MANIPULATOR POSITIONING MIGHT DECREASE IF THE INSTALLATION SURFACE PRECISION IS INSUFFICIENT.



CAUTION

IF THE INSTALLATION BASE IS NOT SUFFICIENTLY RIGID AND STABLE OR A THIN METALLIC PLATE IS ATTACHED TO THE INSTALLATION BASE, VIBRATION (RESONANCE) MAY OCCUR DURING OPERATION, CAUSING DETRIMENTAL EFFECTS ON THE MANIPULATOR WORK.

2 Installation

2-1 Unpacking

WARNING

THE ROBOT AND CONTROLLER ARE HEAVY. TAKE SUFFICIENT CARE NOT TO DROP THEM DURING MOVING OR UNPACKING AS THIS MAY DAMAGE THE EQUIPMENT OR CAUSE BODILY INJURY.

CAUTION

WHEN MOVING THE ROBOT OR CONTROLLER BY EQUIPMENT SUCH AS A FOLKLIFT THAT REQUIRE A LICENSE, ONLY PROPERLY QUALIFIED PERSONNEL MAY OPERATE IT. THE EQUIPMENT AND TOOLS USED FOR MOVING THE ROBOT SHOULD BE SERVICED DAILY.

The XC series robot comes packed with a robot controller and accessories, according to the order specifications. Using a carrying cart (dolly) or forklift, move the package to near the installation base. Take sufficient care not to apply shocks to the equipment when unpacking it.

R6YXCH250, R6YXCH350, R6YXCH400




Fig. 3-2 Packed state

2-2 **Checking the product**

After unpacking, check the product configuration and conditions.

The following configurations are typical examples, so please check that the product is as specified in your order.

CAUTION


IF THERE IS ANY DAMAGE DUE TO TRANSPORTATION OR INSUFFICIENT PARTS, PLEASE NOTIFY YOUR OMRON SALES OFFICE OR DEALER IMMEDIATELY.

[Example] Controller: YRC

Robot : R6YXCH250, R6YXCH350, R6YXCH400,

R6YXC500, R6YXC600, R6YXC700, R6YXC800,

R6YXC1000



Eyebolts are not supplied with R6YXCH250, R6YXCH350 and R6YXCH400




Fig. 3-3 Product configurations

2-3 Moving the robot

WARNING

SERIOUS INJURY MAY OCCUR IF THE ROBOT FALLS AND PINS SOMEONE UNDER IT.


- DO NOT ALLOW ANY PART OF YOUR BODY TO ENTER THE AREA BENEATH THE ROBOT DURING WORK.
- ALWAYS WEAR A HELMET, SAFETY SHOES AND GLOVES DURING WORK.

To check the mass of each robot, refer to "1-1 Basic specifications" in Chapter 6.

2-3-1 Moving the R6YXCH250, R6YXCH350, R6YXCH400

- 1) Fold the X and Y axis arms as shown in Fig. 3-4, and wind the robot cable around the upper part of the pedestal, then fasten the robot cable with adhesive tape so as not to cover the bolt installation holes.
- 2) Holding the support parts as shown in the figure with both hands, place the robot on the installation base and secure it temporarily by tightening the bolts.

(For tightening torque to secure the robot firmly, see the next section, "2-4 Installing the robot".)



2-3-2 Moving the R6YXC500, R6YXC600, R6YXC700, R6YXC800, **R6YXC1000**

WARNING

SERIOUS INJURY MAY OCCUR IF THE ROBOT FALLS AND PINS SOMEONE UNDER IT.

- •CHECK THAT THERE ARE NO CRACKS AND CORROSION ON THE EYEBOLT INSTALLATION. IF FOUND, DO NOT USE EYEBOLTS TO MOVE THE ROBOT.
- SCREW THE EYEBOLTS SECURELY INTO THE TAPPED HOLES UNTIL THE BEARING SURFACE OF EYEBOLT MAKES TIGHT CONTACT WITH THE BEARING SURFACE ON THE ARM.
- •USE A HOIST AND ROPE WITH CARRYING CAPACITY STRONG ENOUGH TO SUPPORT THE ROBOT WEIGHT.
- MAKE SURE THE ROPE STAYS SECURELY ON THE HOIST HOOK.
- REMOVE ALL LOADS ATTACHED TO THE ROBOT MANIPULATOR END. IF ANY LOAD IS STILL ATTACHED, THE ROBOT MAY LOSE BALANCE WHILE BEING CARRIED, AND TOPPLE OVER CAUSING ACCIDENTS.




CAUTION

- WHEN MOVING THE ROBOT BY EQUIPMENT SUCH AS CRANES THAT REQUIRE A LICENSE, ONLY PROPERLY QUALIFIED PERSONNEL MAY OPERATE IT.
- THE EQUIPMENT AND TOOLS USED FOR MOVING THE ROBOT SHOULD BE SERVICED DAILY.

To move a robot (for example, the R6YXC500) correctly and safely, follow the procedure below. (See Fig. 3-5.) Use the same procedure to move other robots.

- 1) If the Z-axis is not at the origin position, perform return-to-origin from outside the safeguard enclosure. Then, turn off the controller and unplug the robot cable from the controller. (The Z-axis is fixed at the origin position prior to shipping.)
- 2) Remove the X-axis arm cover and set screws.
- 3) Fold the X and Y-axis arms as shown in the drawing, and clamp the Y axis arm to the robot pedestal by using the stay and bolts that come with the robot. If the arms cannot be folded in the carrying position due to the X-axis mechanical stoppers, then remove them. (When the robot is shipped, the mechanical stoppers are installed to provide the maximum movement range.)
- 4) Screw the two eyebolts securely into the tapped hole on the machined bearing surface of the X-axis arm.

- 5) Wind the robot cable around the upper part of the robot pedestal so that it does not hang up on the base mount, then fasten the cable end with adhesive tape.
- 6) Prepare two looped ropes with the same length to allow a good lifting balance, then pass each rope through each eyebolt and catch it on the hoist hook.
- 7) Slightly lift the hoist so that each rope has light tension to hold the robot. In this state, remove the bolts securing the robot base to the pallet supplied or installation base (if robot is to be moved to another installation base).
- 8) Using caution to keep the balance of the robot and avoid subjecting it to any strong vibrations and shocks, operate the hoist carefully to move to the installation base. The angle between each rope and the arm surface should be kept at 45 degrees or more.
- 9) Slightly lower the robot on the installation base and temporarily secure it by tightening the bolts.(For tightening torque to secure the robot firmly, see the next section, "2-4 Installing the robot".)
- 10) Remove the ropes, eyebolts and arm clamping stay, then reattach the cover and the set screws on the X-axis arm. (Be sure to fit the set screws and the cover in position to protect the tapped holes for eyebolts.) Keep the eyebolts, arm clamping stay, bolts and pallet for future use in case the robot needs to be moved or transported.






Fig. 3-5

2-4 Installing the robot

Install the robot securely with the four hex socket head bolts as shown in Fig. 3-6.

M WARNING

WHEN INSTALLING THE ROBOT, BE SURE TO USE THE SPECIFIED SIZE AND QUANTITY OF BOLTS THAT MATCH THE DEPTH OF TAPPED HOLES IN THE INSTALLATION BASE, AND SECURELY TIGHTEN THE BOLTS TO THE CORRECT TORQUE. IF THE BOLTS ARE NOT TIGHTENED CORRECTLY, THE ROBOT MIGHT FALL OVER DURING OPERATION CAUSING A SERIOUS ACCIDENT.

Tightening torque

Robot Model	Bolts Used	Tightening torque
R6YXCH250, R6YXCH350, R6YXCH400	M8	37N·m (380kgf · cm)
R6YXC500, R6YXC600	M10	71N·m (720kgf · cm)
R6YXC700, R6YXC800, R6YXC1000	M12	128N·m (1310kgf · cm)

Depth of tapped holes in installation base:

Iron installation base Bolt diameter \times 1.5 or more Aluminum installation base Bolt diameter \times 3 or more




Fig. 3-6 Installing the robot

3 Protective Bonding

MARNING	ĭ
----------------	---

BE SURE TO GROUND THE ROBOT AND CONTROLLER TO PREVENT ELECTRICAL SHOCK.

M WARNING

TURN OFF THE CONTROLLER BEFORE GROUNDING THE ROBOT.

The robot must be grounded as follows:

1) Provide a terminal marked "PE" for the protective conductor of the entire system and connect it to an external protective conductor. In addition, securely connect the ground terminal on the robot pedestal to the same protective conductor. (See Fig. 3-7 for example of the R6YXC500.)



(Symbol 417-IEC-5019)

- 2) When the end effector uses an electrical device which, if it malfunctions, might make contact with the power supply, the user must provide proper grounding on his own responsibility. The XC series robots do not have a ground terminal for this purpose.
- 3) For details on protective bonding on the robot body to comply with CE markings, follow the instructions on protective bonding explained in the "OMRON Robot Controller User's Manual".
- 4) Use a ground cable with a conductor wire cross section of at least 2.0mm² and a length within 1 meter.




Fig. 3-7 Ground terminal

Robot Cable Connection 4

The robot cable is pre-connected to the XC series robot. For details on connections to the robot controller, refer to Fig. 3-8 and the "OMRON Robot Controller User's Manual". After making connections, check the operation while referring to "6 Trial operation" in Chapter 1.

WARNING

- •BEFORE CONNECTING THE CABLES, CHECK THAT THERE ARE NO BENDS OR BREAKS IN THE CONNECTOR PINS OF THE ROBOT CABLE AND THAT THE CABLES ARE NOT DAMAGED. BENT OR BROKEN PINS OR CABLE DAMAGE MAY CAUSE MALFUNCTION OF THE ROBOT.
- ENSURE THAT THE CONTROLLER IS OFF BEFORE CONNECTING THE ROBOT CABLE TO THE CONTROLLER.



WARNING

IN THE YRC CONTROLLER, THE MOTOR CONNECTORS XM AND ZM, AND YM AND RM EACH HAVE IDENTICAL SHAPES. IN ADDITION, THE PI CONNECTORS XY AND ZR HAVE IDENTICAL SHAPES. DO NOT CONFUSE THESE CONNECTORS WHEN MAKING CONNECTIONS. WRONG CONNECTIONS MAY RESULT IN MALFUNCTION AND HAZARDOUS SITUATIONS.



WARNING

- IF THE CONNECTOR INSTALLATION IS INADEQUATE OR IF THERE ARE CONTACT FAILURES IN THE PINS, THE ROBOT MAY MALFUNCTION CAUSING A HAZARDOUS SITUATION. RECONFIRM THAT EACH CONNECTOR IS SECURELY INSTALLED BEFORE TURNING ON THE CONTROLLER.
- TO ATTACH THE PI CONNECTOR SECURELY, TIGHTEN THE SCREWS SUPPLIED WITH THE ROBOT.
- TAKE CAUTION NOT TO APPLY AN EXCESSIVE LOAD TO THE CONNECTORS DUE TO STRESS OR TENSION ON THE CABLES



⚠ WARNING

LAY OUT THE CABLES SO THAT THEY DO NOT OBSTRUCT THE MOVEMENT OF THE MANIPULATOR. DETERMINE THE ROBOT WORK AREA IN WHICH THE ROBOT CABLES WILL NOT INTERFERE WITH THE LOAD OR WORKPIECE PICKED UP BY THE MANIPULATOR. IF THE ROBOT CABLES INTERFERE WITH THE MOVABLE PARTS OF THE ROBOT, THE CABLES MAY BE DAMAGED CAUSING MALFUNCTION AND HAZARDOUS SITUATIONS. FOR THE EXTERNAL VIEW AND DIMENSIONS OF EACH ROBOT, REFER TO THE DIMENSIONAL OUTLINES LISTED IN OUR ROBOT CATALOG.

MARNING

LAY OUT THE ROBOT CABLES SO AS TO KEEP THE OPERATOR OR ANY OTHER PERSON FROM TRIPPING ON THEM. BODILY INJURY MAY RESULT IF SOMEONE TRIPS ON THE CABLES.




Fig. 3-8 Robot cable connections

5 User Wiring and User Tubing

WARNING

ALWAYS TURN OFF THE CONTROLLER AND SHUT OFF AIR SUPPLY BEFORE ATTEMPTING WIRING AND PIPING WORK. IF AIR OR POWER IS SUPPLIED DURING THIS WORK, THE MANIPULATOR MAY MOVE ERRONEOUSLY CAUSING A HAZARDOUS SITUATION.

1) The XC series robots are equipped with user wires and air tubes in the machine harness. The table below shows the number of wires and air tubes available for each robot model.

Robot model	User wiring	User tubing (Diameter)
R6YXCH250, R6YXCH350, R6YXCH400	14wires	4, 3tubes
R6YXC500, R6YXC600, R6YXC700, R6YXC800, R6YXC1000	24wires	6, 3tubes

(Robot models for custom specifications may have different wiring or tubing.)

The specifications of the user wires and air tubes are shown below. Always observe the specifications.

User Wiring

Rated voltage	30V
Allowable current	1.5A
Nominal cross-section area of conductor	0.2mm ²
Shield	Yes

User Tubing

Maximum pressure	0.58MPa (6Kgf/cm ²)		
Outer diameter × inner diameter	φ4mm × φ2.5mm		
	φ6mm × φ4mm		
Fluid	Dry clean air not containing deteriorated		
	compressor oil; filtration 40μm or less		

2) A D-sub connector for user wiring and a bulkhead union for user tubing are provided one each on the arm side and pedestal side. For their positions, refer to the dimensional outlines listed in our robot catalog.

- 3) Signal wiring connections in the machine harness
 - 1. R6YXCH250, R6YXCH350, R6YXCH400 Connector pins 1 to 14 can be used. Pin 15 is connected to a shield wire and cannot be used as a signal wire.

Signal	Connector	NO	Connection	NO	Connector	Color
		1		1		Brown
		2	1 1	2		Red
		3	1 1	3		Orange
		4	<u> </u>	4		Blue
		5	1 1	5		Violet
User signal line	10	6	1 1	6	10	Grey
	(Arm side)	7	1 1	7	(Base side)	White
		8		8		Black
		9		9		Brown
		10	1 1	10		Red
		11	1 1	11		Orange
		12	1 1	12		Blue
		13		13		Violet
		14	1 1	14		Grey
Shield		15	\\\\	15		Green
Flame ground				1	FG	Green

(Robots models with non-standard specifications may have different wiring colors.)


2. R6YXC500, R6YXC600, R6YXC700, R6YXC800, R6YXC1000 Connector pins 1 to 24 can be used. Pin 25 is connected to a shield wire and cannot be used as a signal wire.


Signal	Connector	NO	Connection	NO	Connector	Color	
		1	/	1		Brown	
		2		- 2		Red	
		3		3		Orange	
		4		4		Blue	
		5	1 1	- 5		Violet	
		6	1 1	6		Grey	
		7	ii	7		White	
		8		8		Black	
		9	1 1	9		Brown	
User signal line	10	10	1 1	10	10	Red	
_	(Arm side)	11	i	11	(Base side)	Orange	
			12		12		Blue
			13	1 1	13		Violet
			14	1 1	14		Grey
			15	1 1	15		White
			16		16		Black
		17		17		Brown	
		18		18		Red	
		19	1 1	19		Orange	
		20	<u> </u>	20		Blue	
		21	1 1	21			
		22	1 1	22			
		23		23			
		24		24			
Shield	1	25		25		Green	
Flame Ground				- 1	FG	Green	

(Robots models with non-standard specifications may have different wiring colors.)

As shown in Fig. 3-9, solder the user cable wires to the D-sub connector (supplied with the robot). Reattach the hood to the D-sub connector after soldering, then plug it into the user wiring connector.

The connector pinouts as viewed from the solder side are shown below.





(As viewed from solder side)

D-sub connector on base side (As viewed from solder side)

R6YXC500, R6YXC600, R6YXC700, R6YXC800, R6YXC1000

Fig. 3-9



WARNING

THE USER CABLE WIRES SHOULD HAVE A SHIELD WIRE. CONNECT IT TO THE SAME NO. PIN IN THE D-SUB CONNECTOR ON THE ROBOT SIDE, WHICH ALSO CONNECTS TO THE SHIELD WIRE. IF THIS TASK IS OMITTED, NOISE MAY CAUSE MALFUNCTION OF THE ROBOT.



⚠ WARNING

SECURELY ATTACH THE D-SUB CONNECTOR (SUPPLIED WITH THE ROBOT) INTO THE D-SUB CONNECTOR ON THE ROBOT SIDE, BY TIGHTENING THE SCREWS ON THE CONNECTOR HOOD. IF THIS CONNECTOR COMES LOOSE OR COMES OFF, MALFUNCTION MAY RESULT.



WARNING

AVOID FASTENING THE USER CABLE OR TUBE WITH THE MACHINE HARNESS, AS THIS MAY LEAD TO HARNESS BREAKAGE AND MALFUNCTION.

WARNING

MAKE SURE THAT THE USER CABLE ATTACHED TO THE D-SUB CONNECTOR FOR USER WIRING AND THE TUBE ATTACHED TO THE BULKHEAD UNION FOR USER TUBING WILL NOT INTERFERE WITH THE ROBOT MOVEMENT, ENTANGLE AROUND THE ROBOT OR FLAP AROUND DURING OPERATION. WIRING AND TUBING MIGHT THEN BE DAMAGED CAUSING MALFUNCTION OF THE ROBOT.

MWARNING

LAY OUT THE USER CABLE ATTACHED TO THE D-SUB CONNECTOR FOR USER WIRING AND THE TUBE ATTACHED TO THE BULKHEAD UNION FOR USER TUBING SO THAT THEY DO NOT OBSTRUCT THE MOVEMENT OF THE OPERATOR OR ANY OTHER PERSONS. BODILY INJURY MAY RESULT IF ANYONE TRIPS ON THE CABLE OR AIR TUBE.

CAUTION

THE D-SUB CONNECTOR SUPPLIED WITH THE ROBOT SHOULD BE CONNECTED TO THE ARM SIDE BY PIN CONTACT, AND TO THE PEDESTAL SIDE BY SOCKET CONTACT. USE CAUTION AT THESE POINTS WHEN SOLDERING.

CAUTION

BE SURE TO USE THE D-SUB CONNECTOR AND HOOD WHICH ARE SUPPLIED WITH THE ROBOT. USING OTHER TYPES MAY RESULT IN CONTACT FAILURE.

D-sub connectors (supplied with robot)

Robot model	D-sub connector on arm side	D-sub connector on base side	Hood	
R6YXCH250, R6YXCH350, R6YXCH400	DA-15P-NR	DA-15S-NR	DA-C1-J10R	
R6YXC500, R6YXC600, R6YXC700, R6YXC800, R6YXC1000	DB-25P-NR	DB-25S-NR	DB-C2-J9R	

Manufacturer: Japan Aviation Electronics Industry, Limited.

5) To check the operation and signal transmission between the end effector and the controller or peripheral equipment after making connections, refer to "6. Trial operation" in Chapter 1.

6 Attaching The End Effector

6-1 R-axis tolerable moment of inertia and acceleration coefficient

- 1) The moment of inertia of a load (end effector and workpiece) that can be attached to the R-axis is limited by the strength of the robot drive unit and residual vibration during positioning. It is therefore necessary to reduce the acceleration coefficient in accordance with the moment of inertia.
- 2) The R-axis tolerable moment of inertia and the acceleration coefficient versus R-axis moment of inertia for each robot model are shown in Fig. 3-10 to Fig. 3-61 on the subsequent pages. The symbols A^x, A^y, and A^R in each figure respectively indicate the acceleration coefficients of the X-axis, Y-axis and R-axis. The symbol I^R (J^R) is the moment of inertia of the load around the R-axis and m is the tip mass.

Example: R6YXCH250

Assume that the mass of the load installed to the R-axis is 1.5kg and the moment of inertia around the R-axis is 0.02kgm² (0.2kgf·cm·sec²). When the tip mass parameter is set to 2kg, the robot can be operated by reducing the X, Y and R-axis acceleration coefficients to 60%, as can be seen from Fig. 3-11.

Be sure to select an optimum tip mass and acceleration coefficient parameters that meet the mass of the load and moment of inertia before using the robot.

To make settings for the tip mass and acceleration coefficient, refer to the separate "OMRON Robot Controller User's Manual".

3) For information on how to calculate the moment of inertia of the load, refer to "6-2 Equation for moment of inertia calculation" in Chapter 3 of the standard model X user's manual. Note that it is not easy to precisely calculate the moment of inertia.

If a calculated value smaller than the actual moment of inertia is set, residual vibrations may occur. If this happens, reduce the acceleration coefficient parameter even further.

CAUTION

THE ROBOT MUST BE OPERATED WITH CORRECT TOLERABLE MOMENT OF INERTIA AND ACCELERATION COEFFICIENTS ACCORDING TO THE MANIPULATOR TIP MASS AND MOMENT OF INERTIA. IF THIS IS NOT OBSERVED, PREMATURE END TO THE LIFE OF THE DRIVE UNITS, DAMAGE TO THE ROBOT PARTS OR RESIDUAL VIBRATION DURING POSITIONING MAY RESULT.

ACAUTION

DEPENDING ON THE Z-AXIS POSITION, VIBRATION MAY OCCUR WHEN THE X, Y OR R-AXIS MOVES. IF THIS HAPPENS, REDUCE THE X, Y OR R-AXIS ACCELERATION TO AN APPROPRIATE LEVEL.

CAUTION

IF THE MOMENT OF INERTIA IS TOO LARGE, VIBRATION MAY OCCUR ON THE Z-AXIS DEPENDING ON ITS OPERATION POSITION. IF THIS HAPPENS, REDUCE THE Z-AXIS ACCELERATION TO AN APPRORIATE LEVEL.

6-1-1 Acceleration coefficient vs. moment of inertia (R6YXCH250)




Fig. 3-10 m=1kg




Fig. 3-11 m=2kg




Fig. 3-12 m=3kg

Ir (kgm²)

Jr (kgf ·cm ·sec2)

6-1-2 Acceleration coefficient vs. moment of inertia (R6YXCH350)




Fig. 3-13 m=1kg




Fig. 3-14 m=2kg




Fig. 3-15 m=3kg

Acceleration coefficient vs. moment of inertia (R6YXCH400) 6-1-3




Fig. 3-16 m=1kg




Fig. 3-17 m=2kg




Fig. 3-18 m=3kg

Jr (kgf ·cm ·sec2)

6-1-4 Acceleration coefficient vs. moment of inertia (R6YXC500)




Fig. 3-19 m=1kg




Fig. 3-20 m=2kg




Fig. 3-21 m=3kg

Ir (kgm²)

Ir (kgm²)

Jr (kgf ·cm ·sec2)

Jr (kgf · cm · sec2)




Fig. 3-22 m=4kg

Ir (kgm²) Jr (kgf ·cm ·sec²)

Ax, Ay, AR (%)




Fig. 3-23 m=5kg

Ir (kgm²)
Jr (kgf ·cm ·sec²)

Ir (kgm²)

Jr (kgf ·cm ·sec²)

Ax, Ay, AR (%)




Fig. 3-24 m=6, 7kg




Fig. 3-25 m=8, 9kg

Ir (kgm²) Jr (kgf ∙cm ∙sec²)

Ax, Ay, AR (%)




Fig. 3-26 m=10kg

Ir (kgm²) Jr (kgf·cm·sec²)

6-1-5 Acceleration coefficient vs. moment of inertia (R6YXC600)




Fig. 3-27 m=1kg





Fig. 3-28 m=2kg



Jr (kgf ⋅cm ⋅sec²)

Ir (kgm²)

Ir (kgm²)

Jr (kgf ·cm ·sec2)

Fig. 3-29 m=3kg




Fig. 3-30 m=4kg

Ir (kgm²) Jr (kgf ·cm ·sec²)

Ax, Ay, AR (%)




Fig. 3-31 m=5kg

Ir (kgm²)
Jr (kgf · cm · sec²)

Ir (kgm²)

Jr (kgf ·cm ·sec²)

Ax, Ay, AR (%)




Fig. 3-32 m=6, 7kg




Fig. 3-33 m=8, 9kg






Fig. 3-34 m=10kg

Ir (kgm²)

Jr (kgf ·cm ·sec²)

6-1-6 Acceleration coefficient vs. moment of inertia (R6YXC700)




Fig. 3-35 m=1kg




Fig. 3-36 m=2kg




Fig. 3-37 m=3, 4kg




Fig. 3-38 m=5, 6kg




Fig. 3-39 m=7, 8kg




Fig. 3-40 m=9, 10kg




Fig. 3-41 m=11 to 13kg




Fig. 3-42 m=14 to 16kg




Fig. 3-43 m=17 to 20kg

6-1-7 Acceleration coefficient vs. moment of inertia (R6YXC800)




Fig. 3-44 m=1kg




Fig. 3-45 m=2kg




Fig. 3-46 m=3, 4kg




Fig. 3-47 m=5, 6kg




Fig. 3-48 m=7, 8kg




Fig. 3-49 m=9, 10kg




Fig. 3-50 m=11 to 13kg




Fig. 3-51 m=14 to 16kg




Fig. 3-52 m=17 to 20kg

6-1-8 Acceleration coefficient vs. moment of inertia (R6YXC1000)




Fig. 3-53 m=1kg




Fig. 3-54 m=2kg




Fig. 3-55 m=3, 4kg




Fig. 3-56 m=5, 6kg




Fig. 3-57 m=7, 8kg




Fig. 3-58 m=9, 10kg




Fig. 3-59 m=11 to 13kg




Fig. 3-60 m=14 to 16kg




Fig. 3-61 m=17 to 20kg

6-2 Equation for moment of inertia calculation

For equation for moment of inertia calculation, refer to "6-2 Equation for moment of inertia calculation" in Chapter 3 of the standard model X user's manual.

6-3 Example of moment of inertia calculation

For example of moment of inertia calculation, refer to "6-3 Example of moment of inertia calculation" in Chapter 3 of the standard model X user's manual.


6-4 Attaching the end effector

WARNING


BEFORE ATTACHING THE END EFFECTOR, BE SURE TO TURN OFF THE CONTROLLER.


The manipulator part to which an end effector is attached must have adequate strength and rigidity, as well as gripping force to prevent positioning errors. Table 3-1 shows the maximum load that can be applied to the end effector attachment of each robot during operation. Recommended methods for attaching end effectors are shown in Table 3-2 and Fig. 3-65. Refer to Fig. 3-62 and Fig. 3-63 for details on the end effector attachment of each robot.

When checking end effector operation, refer to "6 Trial Operation" in Chapter 1.




R6YXCH250, R6YXCH350, R6YXCH400 : Z-axis tip shape






R6YXC500, R6YXC600: Z-axis tip shape

Fig. 3-62





R6YXC700, R6YXC800, R6YXC1000: Z-axis tip shape

Fig. 3-63

Table 3-1

Robot Model	Fxymax		Fzmax		Frmax		Mrmax		Mmax	
Mobot Model	N	kgf	N	kgf	N	kgf	Nm	kgfm	Nm	kgfm
R6YXCH250	46	5	40	4	121	12	6	0.6	5	0.5
R6YXCH350	46	5	40	4	121	12	6	0.6	5	0.5
R6YXCH400	46	5	40	4	121	12	6	0.6	5	0.5
R6YXC500	115	12	89	9	253	26	12	1.3	10	1.0
R6YXC600	115	12	89	9	253	26	12	1.3	10	1.0
R6YXC700	376	38	178	18	464	47	47	4.8	22	2.3
R6YXC800	376	38	159	16	464	47	47	4.8	20	2.0
R6YXC1000	341	35	159	16	464	47	43	4.4	20	2.0




Fig. 3-64 Maximum load applied to end effector attachment

Table 3-2

Robot Model	Bolts Used	Number of	Tightening torque		Hole diameter(mm)	
Nobot Wodel	Doits Osed	bolts	Nm	kgf · cm	Tiole dian	icter(iiiii)
R6YXCH250	M4 or lager	2 or more	4.5	46	12	+0.018 0
R6YXCH350	M4 or lager	2 or more	4.5	46	12	+0.018 0
R6YXCH400	M4 or lager	2 or more	4.5	46	12	+0.018 0
R6YXC500	M6 or lager	2 or more	15.3	156	18	+0.018 0
R6YXC600	M6 or lager	2 or more	15.3	156	18	+0.018 0
R6YXC700	M8 or lager	2 or more	37.0	380	22	+0.021 0
R6YXC800	M8 or lager	2 or more	37.0	380	22	+0.021 0
R6YXC1000	M8 or lager	2 or more	37.0	380	22	+0.021 0




Fig. 3-65



⚠ WARNING

THE END EFFECTOR ATTACHMENT MUST HAVE ADEQUATE STRENGTH TO WITHSTAND THE LOADS LISTED IN TABLE 3-1. IF TOO WEAK, THE ATTACHMENT MAY BREAK DURING ROBOT OPERATION AND FRAGMENTS FLY OFF CAUSING ACCIDENTS OR INJURIES.

WARNING

THE END EFFECTOR ATTACHMENT MUST HAVE SUFFICIENT RIGIDITY VERSUS THE LOADS LISTED IN TABLE 3-1. IF THIS RIGIDITY IS INADEQUATE, THE END EFFECTOR MAY VIBRATE DURING ROBOT OPERATION CAUSING BAD EFFECTS ON THE MANIPULATOR OPERATION.

WARNING

• WHEN THE END EFFECTOR IS ATTACHED BY SLOT CLAMPING, ALWAYS OBSERVE THE CONDITIONS LISTED IN TABLE 3-2. IF THESE ARE IGNORED, THE END EFFECTOR MAY COME LOOSE AND FLY OFF DURING ROBOT OPERATION, RESULTING IN AN ACCIDENT OR INJURY. •IN CASES WHERE OTHER ATTACHMENT METHODS ARE USED, BE SURE THAT THE END EFFECTOR WILL NOT COME OFF WHEN THE LOADS LISTED IN TABLE 3-1 ARE APPLIED.

WARNING

- THE TAPPED HOLE (SEE FIGS. 3-62, 3-63 AND 3-65) PROVIDED ON THE LOWER PART OF THE END EFFECTOR ATTACHMENT SHOULD BE USED ONLY FOR PREVENTING THE END EFFECTOR FROM COMING LOOSE.
- DO NOT FASTEN THE END EFFECTOR JUST BY USING THIS TAPPED HOLE. IF THE END EFFECTOR IS FASTENED ONLY WITH THIS TAPPED HOLE, IT MAY COME LOOSE FROM THE ATTACHMENT DURING ROBOT OPERATION AND FLY OFF RESULTING IN ACCIDENTS OR INJURIES

6-5 Gripping force of end effector

The gripping force of the end effector must have a sufficient extra margin of strength versus the workpiece weight and reaction force applied to the workpiece during robot operation.

The reaction force applied to the workpiece during operation can be calculated from the acceleration applied to the end effector attachment. The maximum acceleration on the end effector attachment of each robot model is listed in the table below. When the workpiece position is offset to the end effector attachment, the accelerations Amax and A^{xy} max become larger by an amount equal to the offset versus the arm length. When the R-axis rotates during operation, this acceleration A^{R} max must be taken into account.

Robot Model	Amax(m/sec²)	Axymax(m/sec²)	Azmax(m/sec²)	Armax(rad/sec ²)
R6YXCH250	62	45	23	140
R6YXCH350	71	48	23	120
R6YXCH400	91	46	23	120
R6YXC500	48	32	38	140
R6YXC600	52	27	38	140
R6YXC700	64	46	32	160
R6YXC800	67	39	32	160
R6YXC1000	63	39	32	136

Table 3-3 Maximum acceleration during robot operation




Fig. 3-66 Maximum acceleration on end effector attachment

M WARNING

THE GRIPPING FORCE OF THE END EFFECTOR MUST HAVE A SUFFICIENT EXTRA MARGIN OF STRENGTH TO PREVENT THE WORKPIECE FROM COMING LOOSE AND FLYING OFF DURING ROBOT OPERATION.

IF THE GRIPPING FORCE IS TOO WEAK, THE WORKPIECE MAY COME LOOSE AND FLY OFF CAUSING ACCIDENTS OR INJURIES.

Limiting the Movement Range with X-Axis 7 **Mechanical Stoppers** (Excluding R6YXCH250, R6YXCH350, R6YXCH400)

In the XC series (excluding R6YXCH250, R6YXCH350, R6YXCH400), the movement range can be limited by changing the X-axis mechanical stopper positions. (The Y-axis mechanical stopper positions are fixed and cannot be changed.) When the robot is shipped from the factory, the movement range is set to the maximum. If the maximum movement range is too large compared to the actual work range, or the manipulator might interfere with peripheral units, then the movement range can be limited as outlined below.

The X-axis mechanical stopper positions may slightly differ depending on machining precision.



WARNING

ALWAYS TURN OFF THE CONTROLLER BEFORE CHANGING THE MOVEMENT RANGE WITH MECHANICAL STOPPERS.



CAUTION

WHEN THE MECHANICAL STOPPERS ARE INSTALLED, THE SOFT LIMITS MUST BE SET TO A POINT INSIDE THE MECHANICAL STOPPER POSITIONS. (REFER TO "4 SETTING THE SOFT LIMITS" IN CHAPTER 4.)

To change the X-axis mechanical stopper positions, use the procedure below.

- 1) Prepare the following tools. Hex wrench set
- Turn off the robot controller.
- 3) Place a sign indicating the robot is being adjusted, to keep others from touching the controller switch.
- Enter the safeguard enclosure.
- 5) Remove the X-axis mechanical stoppers installed as shown in Fig. 3-67 and Fig. 3-68. Then reinstall the mechanical stoppers at the positions that determine the desired movement range by tightening them to the torque specified in Table 3-4.
- 6) Check that the movement range is limited by the mechanical stoppers as desired.

- 7) Go outside the safeguard enclosure.
- 8) Check that no one is inside the safeguard enclosure when turning on the controller.

Table 3-4

Robot Model	Bolt size	Tightening torque(kgf·cm)	Tightening torque(N·m)
R6YXC500, R6YXC600	M6	156	15.3
R6YXC700, R6YXC800, R6YXC1000	M8	380	37.2




Fig. 3-67 Mechanical stopper positions and movement range (R6YXC500, R6YXC600)





Fig. 3-68 Mechanical stopper positions and movement range (R6YXC700, R6YXC800, R6YXC1000)

8 Working Envelope and Mechanical Stopper Positions for Maximum Working Envelope

Working envelope of each robot and mechanical stopper positions for the maximum working envelope are shown in Fig. 3-69 to Fig. 3-76.



R6YXCH250 (Z-axis mechanical stopper position)





Fig.3-69 R6YXCH250







Fig.3-70 R6YXCH350



R6YXCH400 (Z-axis mechanical stopper position)





Fig.3-71 R6YXCH400



R6YXC500 (Z-axis mechanical stopper position)




Fig.3-72 R6YXC500




Fig.3-73 R6YXC600





Fig.3-74 R6YXC700







Fig.3-75 R6YXC800



Interference position
(a) Base flange
(b) Base rear side
(c) Base

R1000

R450

R450

R450

R450

Working envelope

Fig.3-76 R6YXC1000

X and Y-axis mechanical stopper positions (maximum working envelope)

Here, robot working envelope and mechanical stopper positions for the maximum working envelope are described using the R6YXC500 as an example. Refer to Fig. 3-72 for the R6YXC500. Other robot models are the same.

1) X and Y axes

- 1. Do not attempt operation outside the working envelope. On the XC series, the origin can be set at any position. The working envelope described in this manual is an area with the robot frontal reference.
- 2. Interference positions where a load may touch the robot within the working envelope and their radii are shown in the figure. Here, "a", "b" and "c" are the respective interference positions with the base flange, base rear panel, and base. Use caution not to allow the robot load to interfere with any part of the robot.
- 3. Interference positions where a load might touch the robot when the robot strikes the X-axis or Y-axis mechanical stoppers set for the maximum working envelope and their radii are shown at the mechanical stopper positions. Here, "b" and "c" are the respective interference positions with the base rear panel and the base.

2) Z-axis

Do not attempt work outside the working envelope. In particular, do not attempt work in the area between the working envelope and mechanical stopper position. Mechanical stoppers are installed at both the upper and lower ends of the movement range.



WARNING

THE ROBOT CABLE, USER WIRING OR TUBING MAY BE DAMAGED IF THE ROBOT LOAD INTERFERES WITH THEM RESULTING IN HAZARDOUS ROBOT MALFUNCTIONS. DO NOT OPERATE AT POINTS WHERE THE LOAD MAY INTERFERE WITH THE ROBOT CABLE, USER WIRING OR TUBING.

3) R-axis

The R-axis has no mechanical stoppers.



CAUTION

SINCE THE R-AXIS HAS NO MECHANICAL STOPPERS, MAKE CERTAIN THAT THE END EFFECTOR WIRING AND TUBING DO NOT BECOME ENTANGLED DURING OPERATION.

A urethane damper is installed to absorb the shock when an impact occurs with the mechanical stopper, so a certain amount of overrun occurs when the robot strikes the mechanical stopper. Use caution and take overrun into account since the end effector may interfere with the robot body and peripheral equipment or the robot body may interfere with the peripheral equipment. Maximum overrun amounts are listed below (for normal operation, maximum load mass, maximum speed).

Robot model	V auda	Vania	Z-axis		
Robot model	X-axis	Y-axis	Upper end	Lower end	
R6YXCH250, R6YXCH350, R6YXCH400	10°	2°	2mm	2mm	
R6YXC500, R6YXC600	6°	2°	5mm	2mm	
R6YXC700, R6YXC800, R6YXC1000	6°	2°	5mm	2mm	

Note: Here, ° (deg.) is the overrun angle at the X-axis and Y-axis joints.

- 1. When the robot strikes the X-axis or Y-axis mechanical stopper or another object, or when the R-axis collides with an object, speed reduction gears are locked while being meshed if the collision impact is large. If this happens, please contact our sales office or dealer.
- 2. When the robot strikes the Z-axis upper mechanical stopper excessively, the urethane damper may be splayed beyond the retaining ring. In this case, return the urethane damper to its original state.

Adjustment

I	Over	view		4-1
2	Safet	y Preca	autions	4-1
3	_	_	ne origin	
	3-1		ne reference	
	3-2 3-3		ite reset procedures	
	3-4		ing the origin position and adjusting the machine reference	
		3-4-1	Sensor method	4-2
		3-4-2	Mark method	4-2
		3-4-3	Stroke end method	4-3
4	Settin	ng the	Soft Limits	4-6
5	Settin	ng the	Standard Coordinates	4-8
6		_	ckers for Origin Positions, Movement Directions a	
7	Remo	oving t	he Robot Covers	4-11
8	Adju 8-1 8-2	Adjusti	ne Timing Belt Tensioning the belt tension (R6YXCH250, R6YXCH350, R6YXCH400)	4-16
	8-3	-	ing the belt tension (R6YXC700, R6YXC800, R6YXC1000)	

1 Overview

OMRON robots have been completely adjusted at the factory or sales representative before shipment, including the Z-axis origin position adjustment. However, when the operating conditions are changed and adjustment of the robot becomes necessary, follow the procedure described in this chapter.

2 Safety Precautions

- (1) Read and understand the contents of this chapter completely before attempting to adjust the robot.
- (2) Place a conspicuous sign indicating the robot is being adjusted, to prevent others from touching the controller switch, programming box or operation panel.
- (3) If a safeguard enclosure has not yet been provided right after installation of the robot, rope off or chain off the movement area around the manipulator in place of a safeguard enclosure, and observe the following points.
 - 1- Use stable posts which will not fall over easily.
 - 2- The rope or chain should be easily visible by everyone around the robot.
 - 3- Place a conspicuous sign prohibiting the operator or other personnel from entering the movement area of the manipulator.
- (4) To check operation after adjustment, refer to "6. Trial Operation" in Chapter 1.

3 Adjusting the origin

3-1 Absolute reset method

For information on absolute reset method, refer to "3 Adjusting the origin" in Chapter 4 of the standard model X user's manual.

3-2 Machine reference

For information on machine reference, refer to "3 Adjusting the origin" in Chapter 4 of the standard model X user's manual.

3-3 Absolute reset procedures

For information on absolute reset procedures, refer to "3 Adjusting the origin" in Chapter 4 of the standard model X user's manual.

3-4 Changing the origin position and adjusting the machine reference

For information on changing the origin position and adjusting the machine reference, refer to "3 Adjusting the origin" in Chapter 4 of the standard model X user's manual.

3-4-1 Sensor method

For information on sensor method, refer to "3 Adjusting the origin" in Chapter 4 of the standard model X user's manual.

3-4-2 Mark method

For information on mark method, refer to "3 Adjusting the origin" in Chapter 4 of the standard model X user's manual.

3-4-3 Stroke end method

The stroke end method is employed on the XC series robots for the absolute reset of the Z-axis.

The origin position of the Z-axis is fixed at the upper end of the Z-axis stroke, and it cannot be changed.

The machine reference is factory-adjusted at shipment, and readjustment is not necessary for normal use.

The readjustment in the following procedure is required, however, if the machine reference exceeds the tolerance range (26 to 74) of the absolute reset for any reason.



WARNING

INJURY CAN OCCUR IF HANDS OR FINGERS ARE SQUEEZED BETWEEN THE DRIVE PULLEY AND BELT. ALWAYS TURN OFF THE CONTROLLER AND USE CAUTION WHEN HANDLING THESE PARTS.

CAUTION

THE POSITIONAL SHIFT WILL OCCUR AFTER ADJUSTING THE MACHINE REFERENCE VALUE, SO POINT DATA SETTINGS ARE REQUIRED AGAIN.

- 1) Check that no one is inside the safeguard enclosure, and then turn on the controller.
- 2) Place a sign indicating the robot is being adjusted, to keep others from operating the controller or operation panel.
- 3) Perform the Z-axis absolute reset. To perform the Z-axis absolute reset, see "3-3 Absolute reset procedures" in Chapter 4.
- 4) Turn off the controller.
- 5) Enter the safeguard enclosure.
- 6) Remove the Y-axis upper cover and under cover (R6YXC500 to R6YC1000).

To remove the covers, see "7 Removing the Robot Covers" in Chapter 4. Place the upper cover on the robot base (pedestal) side with the machine harness still connected.

- 7) Prop the spline or end effector with a support stand to prevent the Z-axis from dropping.
- 8) Remove the bolts securing the Z-axis motor (See Figs. 4-1 to 4-3) and then remove the Z-axis motor.



WARNING

IF THE Z-AXIS MOTOR COMES OFF THE Z-AXIS BELT. THE Z-AXIS DROPS CAUSING A HAZARDOUS SITUATION. BE SURE TO PROP THE Z-AXIS WITH A SUPPORT STAND.

- 9) Adjust the distance (L) between the Z-axis mechanical stopper and the axis end so it is set to the value shown in Table 4-1. Then tighten the four bolts to reassemble the Z-axis motor. (See Fig. 4-4.) At this point, do not allow the spline shaft position to shift from the correct height.
- 10) After reassembling the Z-axis motor, adjust the timing belt tension. To adjust the timing belt tension, see "8 Adjusting the Timing Belt Tension" in Chapter 4.
- 11) Reattach the Y-axis upper cover and under cover (R6YXC500 to R6YXC1000).

To attach the covers, see "7 Removing the Robot Covers" in Chapter 4.

- 12) Go outside the safeguard enclosure.
- 13) Check that no one is inside the safeguard enclosure, and then turn on the controller.
- 14) Perform the Z-axis absolute reset.

To perform the Z-axis absolute reset, see "3-3 Absolute reset procedures" in Chapter 4.

After absolute reset is complete, use the following procedure to check if the **adjustment machine reference value** is within the tolerance range (26 and 74).



THE ADJUSTMENT MACHINE REFERENCE VALUE IS DISPLAYED WITH THE PROCEDURE BELOW.

ALWAYS CHECK THE ADJUSTMENT MACHINE REFERENCE VALUE WHEN THE MACHINE REFERENCE IS ADJUSTED.

- 1- Press the MODE key.
- 2- Press the F3 key to set MANUAL mode.
- 3- Press the F13 (LOWER+F3) key to select "RST. ABS".
- 4- After the Z-axis absolute reset is complete, press the F10 (UPPER+F5) to display the **adjustment machine reference value (%)**.

If **adjustment machine reference value** is outside the absolute reset tolerance range (26 to 74), remove the Z-axis motor again and make fine-adjustment to the spline shaft height, so that the **adjustment machine reference value** is within the absolute reset tolerance range.

Table 4-1

Robot Model	L
R6YXCH250, R6YXCH350, R6YXCH400	4mm
R6YXC500, R6YXC600	8mm
R6YXC700, R6YXC800, R6YXC1000	8mm




Fig. 4-1 R6YXCH250, R6YXCH350, R6YXCH400




Fig. 4-2 R6YXC500, R6YXC600




Fig. 4-3 R6YXC700, R6YXC800, R6YXC1000




Fig. 4-4

4 Setting the Soft Limits

In the XC series, the working envelope during manual and automatic operation can be limited by setting the plus soft limit [pulse] and minus soft limit [pulse] on each axis.

The origin point 0 [pulse] is used as the reference to set the soft limits. The working envelope can be limited by specifying the number of pulses from the 0 pulse position. For the working envelope of each robot, refer to the dimensional outlines listed in our robot catalog.

When performing actual checks of the soft limit settings, operate the robot manually from outside the safeguard enclosure.

- (1) Setting the X-axis and Y-axis soft limits
 - The soft limits must be set within the movement range limited by the mechanical stoppers as explained in Section 7 in Chapter 3 or within the range where the manipulator does not interfere with the peripheral equipment (but within maximum working envelope). Set the soft limits with the following procedure. Also use this procedure when the origin position has been changed. Likewise, in models where the mechanical stopper position cannot be changed, reduce the soft limits to narrow the working envelope when the actual working range of the robot is small or the manipulator interferes with the peripheral equipment.
- 1) Check that no one is inside the safeguard enclosure, and then turn on the controller.
- 2) Press the emergency stop button on the PB to set emergency stop. Refer to the "OMRON Robot Controller User's Manual" for further details on emergency stop and canceling emergency stop.
- 3) Place a sign indicating the robot is being adjusted, to keep others from operating the controller or operation panel.
- 4) Enter the safeguard enclosure while holding the PB.
- 5) Move the X-axis and Y-axis arms by hand to the mechanical stopper positions or to the point where interference with the peripheral equipment occurs, and note the X-axis and Y-axis plus (+) and minus (-) direction pulses displayed on the PB.
- 6) Check that no one is inside the safeguard enclosure, then cancel emergency stop from outside the safeguard enclosure.
- 7) Set the soft limits to within the figure for the X-axis and Y-axis encoder pulses that you noted above in step 5). This software limit setting must be made from outside the safeguard enclosure.
 - Refer to the "OMRON Robot Controller User's Manual" for further details on soft limit settings.

(2) Setting the Z-axis soft limits

Make this setting from outside the safeguard enclosure.

The Z-axis has mechanical stoppers fixed at the upper and lower ends of the Z-axis movement range. When the actual working range of the robot is smaller than the maximum working envelope or the manipulator interferes with the peripheral equipment, reduce the Z-axis plus (+) soft limit [pulses] to narrow the working envelope.

(3) Setting the R-axis soft limit

To make this setting, set emergency stop just as for the X-axis and Y-axis, or be sure to do this from outside the safeguard enclosure. The R-axis has no mechanical stoppers. When the actual working range of the R-axis is small or it interferes with the peripheral equipment, reduce the R axis plus (+) soft limit [pulse] and minus (-) soft limit [pulses] to narrow the working envelope.



OVERLOADS MAY OCCUR IF THE SOFT LIMIT IS ALMOST NEAR THE ENCODER PULSE AT THE MECHANICAL STOPPER AND THE OPERATING POINT IS USED AT THE EDGE OF THE MOVEMENT RANGE. SET THE SOFT LIMIT TO THE INNER SIDE OF THE MECHANICAL STOPPER WITH AN AMPLE SAFETY MARGIN.

(4) Relation between the X, Y and R-axis movement angle, the Z-axis movement distance and the number of pulses

The tables below are for calculating resolver pulses with respect to the X, Y and R-axis movement angles and to the Z-axis movement distance for each robot. Use these figures as a guide to set the soft limits.

X, Y and R-axis speed reduction ratio and Z-axis ball screw lead for each robot

Robot model	X-axis	Y-axis	Z-axis	R-axis
R6YXCH250, R6YXCH350, R6YXCH400	50	50	12mm	50
R6YXC500, R6YXC600	80	80	20mm	50
R6YXC700, R6YXC800	80	80	20mm	50
R6YXC1000	100	80	20mm	50

Operation angle/distance vs. number of resolver pulses

X, Y and R-axis speed reduction ratio

Speed ratio	Number of resolver pulses per turn (360 degrees)	
50	819200	
80	1310720	
100	1638400	

Z-axis

Lead	Number of resolver pulses per lead movement
12mm	16384
20mm	16384

5 Setting the Standard Coordinates



IF THE STANDARD COORDINATE SETTINGS ARE INCORRECT, THE ACCELERATION CANNOT BE OPTIMIZED TO MATCH THE ARM POSITION. THIS RESULTS IN TOO SHORT A SERVICE LIFE, DAMAGE TO THE DRIVE UNIT, OR RESIDUAL VIBRATION DURING POSITIONING. IN ADDITION, THE CARTESIAN COORDINATE ACCURACY WILL BE IMPAIRED.

Setting the standard coordinates enables the following operations and functions.

- 1. Optimizes acceleration according to arm position during automatic operation.
- 2. Allows moving robot arm tip at right angles.
- 3. Allows using shift coordinates.
- 4. Enables commands such as linear interpolation and arm switching.

The procedure for setting standard coordinates and cautions are shown below.

- 1) Check that no one is inside the safeguard enclosure, and then turn on the controller.
- 2) Check that the soft limits are correctly set.

 If not correctly set, adjust the soft limits while referring to the description of "4 Setting the Soft Limits" in Chapter 4.
- 3) Place a sign indicating the robot is being adjusted, to keep others from operating the controller or operation panel.
- 4) Enter the safeguard enclosure while holding the PB. Stay outside the robot movement range at this time.
- 5) Make the standard coordinate settings while referring to methods for "Setting the Standard Coordinates" as explained in the "OMRON Robot Controller User's Manual". Never enter within the robot movement range.
- 6) When the standard coordinate settings are complete, check the following points from outside the safeguard enclosure.
 - 1. Check that the robot arm tip can move at right angles in MANUAL operation (cartesian coordinates).
 - 2. Check that the values nearly equal to the X-axis arm and Y-axis arm lengths are entered in "Arm length" of the axis parameter 10.

If the above points are not satisfied, the standard coordinate settings are incorrect, so make the standard coordinate settings again.

Affixing Stickers for Origin Positions, Movement Directions and Axis Names


The robot comes packed with stickers showing origin positions, movement directions and axis names as shown in Fig. 4-5. Using the following procedure, attach these stickers in conspicuous points on the robot after changing the origin position and installing peripheral equipment.

- 1) Check that no one is inside the safeguard enclosure, and then turn on the controller.
- 2) Move the robot to the 0 pulse position.

 To move the axes to their "0" pulse positions, see "Chapter 4 Point trace function" in the "OMRON Robot Controller User's Manual".
- 3) Turn off the controller.
- 4) Place a sign indicating the robot is being adjusted, to keep others from operating the controller switch.
- 5) Enter the safeguard enclosure.
- 6) Being careful not to move the origin positions, attach stickers at conspicuous points on matching sides of components such as the robot arm of each axis, base (robot pedestal) and end effector. Affix stickers nearby showing the axis name and direction of movement. Use a cloth moistened with alcohol to remove grease from the surface where you will affix the stickers. After the surface is dry, affix the stickers securely. (See Fig. 4-6)

A CAUTION

AFFIX THE ORIGIN POSITION STICKERS PRECISELY ON THE ORIGIN POSITIONS. ALIGN THE DIRECTION OF MOVEMENT STICKERS WITH THE JOG DIRECTION AND AFFIX THEM CORRECTLY. AFFIX EACH AXIS NAME STICKER ON THE CORRECT AXIS. AFFIXING THE STICKER AT A WRONG LOCATION MAY CAUSE FAULTY OPERATION AND HAZARDOUS SITUATIONS.






Fig. 4-6 Positions for affixing the stickers (R6YXC500)

7 Removing the Robot Covers

To remove the robot cover, follow the procedure below.

- 1) Prepare the necessary tools.
 - Hex wrench set
 - Phillips-head screwdriver
- 2) Turn off the controller.
- 3) Place a sign indicating the robot is being adjusted, to keep others from operating the controller switch.
- 4) Enter the safeguard enclosure.
- 5) Remove the covers while referring to Fig. 4-7 to Fig. 4-9. Screws used to fasten each cover are listed in Tables 4-2 to 4-4.

Table 4-2 R6YXCH250, R6YXCH350, R6YXCH400 (See Fig. 4-7)

Cover name	Screw No.	Screw size	Qty
Base (robot pedestal) rear cover	1	M4x6	4
Base (robot pedestal) front cover	2	M4x6	4
Y-axis arm upper cover	3 4 5	M3x6 M3x10 M3x16	4 2 2

Table 4-3 R6YXC500, R6YXC600 (See Fig. 4-8)

Cover name	Screw No.	Screw size	Qty
Base (robot pedestal) rear cover 1	1	M4x6	8
Base (robot pedestal) rear cover 2	2	M4x6	4
Base (robot pedestal) front cover	3	M4x6	8
X-axis arm upper cover	4	M4x6	2
Y-axis arm upper cover	5	M3x6	4
	6	M3x50	4
X-axis arm under cover	7	M4x6	4
Y-axis arm under cover	8	M4x6	4

Table 4-4 R6YXC700, R6YXC800, R6YXC1000 (See Fig. 4-9)

Cover name	Screw No.	Screw size	Qty
Base (robot pedestal) rear cover 1	1	M4x6	8
Base (robot pedestal) rear cover 2	2	M4x6	4
Base (robot pedestal) front cover	3	M4x6	8
X-axis arm upper cover	4	M4x8	2
Y-axis arm upper cover	5	M4x6	4
	6	M4x50	4
Y-axis arm under cover	7	M4x6	4 (6 for R6YXC1000)




Fig. 4-7






Fig. 4-8








Fig. 4-9

8 **Adjusting the Timing Belt Tension**

The XC series robots use a timing belt for controlling the movement of the Z and R axes. If the belt becomes slack, use the following procedure to give proper tension to the belt.

WARNING

THE MOTOR AND SPEED REDUCTION GEAR CASING ARE EXTREMELY HOT AFTER AUTOMATIC OPERATION, SO BURNS MAY OCCUR IF THESE ARE TOUCHED. BEFORE TOUCHING THESE PARTS, TURN OFF THE CONTROLLER, WAIT FOR A WHILE AND CHECK THAT THE TEMPERATURE HAS COOLED.

WARNING

INJURY CAN OCCUR IF HANDS OR FINGERS ARE SQUEEZED BETWEEN THE DRIVE PULLEY AND BELT. ALWAYS TURN OFF THE CONTROLLER AND USE CAUTION WHEN HANDLING THESE PARTS.

CAUTION

SINCE A POSITIONAL SHIFT OCCURS AFTER ADJUSTING THE BELT TENSION, IT IS NECESSARY TO MAKE ABSOLUTE RESET, STANDARD COORDINATE SETTING AND POINT DATA SETTING AGAIN.




Fig. 4-10 Belt tension adjustment




Fig. 4-11 Stay (example)

8-1 Adjusting the belt tension R6YXCH250, R6YXCH350, R6YXCH400

WARNING

IF THE Z-AXIS PULLEY COMES OFF THE Z-AXIS BELT, THE Z-AXIS DROPS CAUSING A HAZARDOUS SITUATION. TURN OFF THE CONTROLLER AND BE SURE TO PROP THE Z-AXIS WITH A SUPPORT STAND BEFORE BEGINNING ADJUSTMENT

Adjust the Z-axis and R-axis timing belts of the R6YXCH250, R6YXCH350 and R6YXCH400 with the procedure below.

- 1) Prepare the necessary tools.
 - Push-pull scale
 - Stay (See Fig. 4-11. This stay should be prepared by the user.)
 - Hex wrench set
 - Phillips-head screwdriver
 - Scale
- 2) Turn off the controller.
- 3) Place a sign indicating the robot is being adjusted, to keep others from operating the controller switch.
- 4) Enter the safeguard enclosure.
- 5) Remove the Y-axis upper cover.
 - Refer to "7 Removing the Robot Covers" in Chapter 4 for removing the cover.
 - Place the upper cover on the robot base (pedestal) side with the machine harness still connected.
- 6) Prop the spline or end effector with a support stand to prevent the Z-axis from dropping (when adjusting the Z-axis belt tension).
- 7) Adjust the belt tension by two people as follows.

 Using the push-pull scale, one person applies a load perpendicular to the middle of the belt. The other person checks the slack of the belt. (See Fig. 4-10 and Fig. 4-11.)
- 8) The correct load to be applied to the belt of each robot model and the resulting slack are shown in Tables 4-5 and 4-6. When the load producing the specified slack is within this range, no adjustment is required. If not, adjust the tension with the following procedure.
- (1) Z-axis belt adjustment
 - 1. Loosen the bolt 1 shown in Fig. 4-12.
 - 2. If the load producing the slack specified in Table 4-5 (step 7) above) is smaller than the specified range, move the Z-axis motor in the direction increasing the tension. If the load is greater than this, move it in the direction reducing the tension. Then, retighten the bolt.
 - 3. Recheck the belt tension using the same procedure in step 7). When the load applied to produce the specified slack is within the specified range of Table 4-5, the adjustment is okay. If not, repeat the above procedure from steps 1 to 3.

- (2) R-axis belt adjustment
 - 1. Loosen the bolt 2 shown in Fig. 4-12.
 - 2. If the load producing the slack specified in Table 4-6 (step 7) above) is smaller than the specified range, move the R-axis motor in the direction increasing the tension. If the load is greater than this, move it in the direction reducing the tension. Then, retighten the bolt.
 - 3. Recheck the belt tension using the same procedure in step 7). When the load applied to produce the specified slack is within the specified range of Table 4-6, the adjustment is okay. If not, repeat the above procedure from steps 1 to 3.
- 9) After adjustment is complete, tighten the bolt 1 or 2 to the torque specified in Table 4-7.
- 10) Reattach the upper cover to the Y-axis arm.Refer to "7 Removing the Robot Covers" in Chapter 4 for attaching the cover.
- 11) Go outside the safeguard enclosure.
- 12) Check that no one is inside the safeguard enclosure, and then turn on the controller.




Fig. 4-12 R6YXCH250, R6YXCH350, R6YXCH400

8-2 Adjusting the belt tension (R6YXC500, R6YXC600)

WARNING

IF THE Z-AXIS PULLEY COMES OFF THE Z-AXIS BELT, THE Z-AXIS DROPS CAUSING A HAZARDOUS SITUATION. TURN OFF THE CONTROLLER AND BE SURE TO PROP THE Z-AXIS WITH A SUPPORT STAND BEFORE BEGINNING ADJUSTMENT.

Adjust the Z-axis and R-axis timing belts of the R6YXC500 and R6YXC600 with the procedure below.

- 1) Prepare the necessary tools.
 - Push-pull scale
 - Stay (See Fig. 4-11. This stay should be prepared by the user.)
 - Hex wrench set
 - Phillips-head screwdriver
 - Scale
- 2) Turn off the controller.
- 3) Place a sign indicating the robot is being adjusted, to keep others from operating the controller switch.
- 4) Enter the safeguard enclosure.
- 5) Remove the Y-axis upper and under covers.
 - Refer to "7 Removing the Robot Covers" in Chapter 4 for removing the covers. Place the upper cover on the robot base (pedestal) side with the machine harness still connected.
- 6) Prop the spline or end effector with a support stand to prevent the Z-axis from dropping (when adjusting the Z-axis belt tension).
- 7) Adjust the belt tension by two people as follows.

 Using the push-pull scale, one person applies a load perpendicular to the middle of the belt. The other person checks the slack of the belt. (See Figs. 4-10 and 4-11.)
- 8) The correct load to be applied to the belt of each robot model and the resulting slack are shown in Tables 4-5 and 4-6. When the load producing the specified slack is within this range, no adjustment is required. If not, adjust the tension with the following procedure.
- (1) Z-axis belt adjustment
 - 1. Loosen the bolt 1 shown in Fig. 4-13.
 - 2. If the load producing the slack specified in Table 4-5 (step 7) above) is smaller than the specified range, move the Z-axis motor in the direction increasing the tension. If the load is greater than this, move it in the direction reducing the tension. Then, retighten the bolt.
 - 3. Recheck the belt tension using the same procedure in step 7). When the load applied to produce the specified slack is within the specified range of Table 4-5, the adjustment is okay. If not, repeat the above procedure from steps 1 to 3.

- (2) R-axis belt adjustment
 - 1. Loosen the bolt 2 shown in Fig. 4-13.
 - 2. If the load producing the slack specified in Table 4-6 (step 7) above) is smaller than the specified range, move the R-axis motor in the direction increasing the tension. If the load is greater than this, move it in the direction reducing the tension. Then, retighten the bolt.
 - 3. Recheck the belt tension using the same procedure in step 7). When the load applied to produce the specified slack is within the specified range of Table 4-6, the adjustment is okay. If not, repeat the above procedure from steps 1 to 3.
- 9) After adjustment is complete, tighten the bolt 1 or 2 to the torque specified in Table 4-7.
- 10) Reattach the upper and under covers to the Y-axis arm.
 Refer to "7 Removing the Robot Covers" in Chapter 4 for attaching the covers.
- 11) Go outside the safeguard enclosure.
- 12) Check that no one is inside the safeguard enclosure, and then turn on the controller.




Fig. 4-13 R6YXC500, R6YXC600

8-3 Adjusting the belt tension (R6YXC700,R6YXC800,R6YXC1000)



IF THE Z-AXIS PULLEY COMES OFF THE Z-AXIS BELT, THE Z-AXIS DROPS CAUSING A HAZARDOUS SITUATION. TURN OFF THE CONTROLLER AND BE SURE TO PROP THE Z-AXIS WITH A SUPPORT STAND BEFORE BEGINNING ADJUSTMENT.

Adjust the Z-axis and R-axis timing belts of the R6YXC700, R6YXC800 and R6YXC1000 with the procedure below.

- 1) Prepare the necessary tools.
 - Push-pull scale
 - Stay (See Fig. 4-11. This stay should be prepared by the user.)
 - Hex wrench set
 - Phillips-head screwdriver
 - Scale
- 2) Turn off the controller.
- 3) Place a sign indicating the robot is being adjusted, to keep others from operating the controller switch.
- 4) Enter the safeguard enclosure.

harness still connected.

- 5) Remove the Y-axis upper and under covers.

 Refer to "7 Removing the Robot Covers" in Chapter 4 for removing the covers.

 Place the upper cover on the robot base (pedestal) side with the machine
- 6) Prop the spline or end effector with a support stand to prevent the Z-axis from dropping (when adjusting the Z-axis belt tension).
- 7) Adjust the belt tension by two people as follows.

 Using the push-pull scale, one person applies a load perpendicular to the middle of the belt. The other person checks the slack of the belt. (See Figs. 4-10 and 4-11.)
- 8) The correct load to be applied to the belt of each robot model and the resulting slack are shown in Tables 4-5 and 4-6. When the load producing the specified slack is within this range, no adjustment is required. If not, adjust the tension with the following procedure.
- (1) Z-axis belt adjustment
 - 1. Loosen the bolt 1 shown in Fig. 4-14.
 - 2. If the load producing the slack specified in Table 4-5 (step 7) above) is smaller than the specified range, move the Z-axis motor in the direction increasing the tension. If the load is greater than this, move it in the direction reducing the tension. Then, retighten the bolt.
 - 3. Recheck the belt tension using the same procedure in step 7). When the load applied to produce the specified slack is within the specified range of Table 4-5, the adjustment is okay. If not, repeat the above procedure from steps 1 to 3.

- (2) R-axis belt adjustment
 - 1. Loosen the bolt 2 shown in Fig. 4-14.
 - 2. If the load producing the slack specified in Table 4-6 (step 7) above) is smaller than the specified range, move the R-axis motor in the direction increasing the tension. If the load is greater than this, move it in the direction reducing the tension. Then, retighten the bolt.
 - 3. Recheck the belt tension using the same procedure in step 7). When the load applied to produce the specified slack is within the specified range of Table 4-6, the adjustment is okay. If not, repeat the above procedure from steps 1 to 3.
- 9) After adjustment is complete, tighten the bolt 1 or 2 to the torque specified in Table 4-7.
- 10) Reattach the upper and under covers to the Y-axis arm.
 Refer to "7 Removing the Robot Covers" in Chapter 4 for attaching the covers.
- 11) Go outside the safeguard enclosure.
- 12) Check that no one is inside the safeguard enclosure, and then turn on the controller.




Fig. 4-14 R6YXC700, R6YXC800, R6YXC1000

Table 4-5 Z-axis belt specifications

Robot model	Load (N)	Load (kgf)	Slack (mm)
R6YXCH250, R6YXCH350	2.3 to 2.5	0.23 to 0.26	0.7
R6YXCH400	2.3 to 2.5	0.23 to 0.26	1.4
R6YXC500, R6YXC600	5.7 to 6.3	0.58 to 0.64	1.6
R6YXC700, R6YXC800	5.7 to 6.3	0.58 to 0.64	2.8
R6YXC1000	5.7 to 6.3	0.58 to 0.64	4.4

Table 4-6 R-axis belt specifications

Robot model Load (N)		Load (kgf)	Slack (mm)
R6YXCH250, R6YXCH350	1.3 to 1.7	0.13 to 0.17	2.1
R6YXCH400	1.3 to 1.7	0.13 to 0.17	2.8
R6YXC500, R6YXC600	2.1 to 2.9	0.22 to 0.30	1.9
R6YXC700, R6YXC800	3.6 to 5.0	0.37 to 0.51	2.7
R6YXC1000	3.6 to 5.0	0.37 to 0.51	4.3

Table 4-7 Tightening torque

Robot model	Axis	Bolt size	Tightening torque (kgf·cm)	Tightening torque (N·m)
R6YXCH250, R6YXCH350,	Z	M3	20	2.0
R6YXCH400	R	M3	20	2.0
DCVVCEAA DCVVCCAA	Z	M5	92	9.0
R6YXC500, R6YXC600	R	M4	46	4.5
R6YXC700, R6YXC800,	Z	M5	92	9.0
R6YXC1000	R	M4	46	4.5

Periodic Inspecition

1	Ove	rview		5-1
2	Prec	autions		5-2
3	Dail	y Inspe	ction	5-3
4	Six-	Month	Inspection	5-5
5	Repl	acing t	he Harmonic Drive	5-8
	5-1	_	cement period	
	5-2	Basic	replacement procedure for harmonic drive and precautions	5-9
		5-2-1	R6YXCH250, R6YXCH350, R6YXCH400	5-11
		5-2-2	R6YXC500, R6YXC600	5-27
		5-2-3	R6YXC700, R6YXC800, R6YXC1000	5-42
6	Repl	acing t	he bellows	5-59

1 Overview

Daily and periodic inspection of the OMRON robot is essential in order to ensure safe and efficient operation. This chapter describes the periodic inspection items and procedures for the OMRON XC series robots.

Periodic inspection includes:

- Daily inspection
- 6-month inspection
- Replacement of speed reduction gear (harmonic drive)

Make sure that you thoroughly understand details of the inspection and follow the procedures and precautions explained in this chapter.

If the robot or controller requires a repair or parts replacement, please contact OMRON EUROPE, B.V. Company or local sales office.

2 Precautions

- (1) Periodic inspection must be performed by or in the presence of personnel who have received the Robot Training given by OMRON or OMRON dealers.
- (2) Do not attempt any inspection, adjustment, repair and parts replacement not described in this manual. This work requires specialized technical knowledge and skill, and may also involve work hazards.
- (3) When inspection is required inside the safeguard enclosure, always turn off the controller and also the external switch board.
- (4) If the inspection or maintenance procedure calls for operation of the robot, stay outside the safeguard enclosure.
- (5) Place a sign indicating the robot is being inspected, to keep others from operating the controller switch, programming box or operation panel.
- (6) Use only the lubricants specified by OMRON or OMRON dealers.
- (7) To check the operation after inspection, refer to "6 Trial operation" in Chapter 1.



- WHEN YOU NEED TO TOUCH THE TERMINALS OR CONNECTORS ON THE OUTSIDE OF THE CONTROLLER DURING INSPECTION, ALWAYS FIRST TURN OFF THE CONTROLLER POWER SWITCH AND ALSO THE POWER SOURCE IN ORDER TO PREVENT POSSIBLE ELECTRICAL SHOCK.
- NEVER TOUCH ANY INTERNAL PARTS OF THE CONTROLLER.

For precautions on handling the controller, refer to the "OMRON Robot Controller User's Manual".

3 Daily Inspection

The following is an inspection list that must be performed every day before and after operating the robot.

(1) Inspection to be performed with the controller turned off

- 1) Turn off the controller.
- 2) Place a sign indicating the robot is being inspected, to keep others from operating the controller switch.
- 3) Enter the safeguard enclosure and check the following points.

Checkpoint	Procedure
Machine harness Robot cable User cable and wiring	Check for scratches, dents and excessive bend and kinks. (If the machine harness or robot cable is damaged, contact OMRON dealer.)
Regulator, joints, air tube, solenoid valve, air cylinder	Check air pressure. Check for air leaks. Check drain. Check air filter for clogging or damage.
Exterior of robot, bellows at manipulator tip*	Check for damage. (If damage is found, contact OMRON dealer)

^{*} Grease may adhere to the inside of the bellows depending on robot operation time or robot work. But this does not have adverse effects on robot performance including the cleanliness degree.

(2) Inspection to be performed with the controller turned on

- 1) Check that no one is inside the safeguard enclosure, and then turn on the controller.
- 2) Place a sign indicating the robot is being inspected, to keep others from operating the controller, programming box or operation panel.
- 3) Check the following points from outside the safeguard enclosure.

Checkpoint	Procedure
Safeguard enclosure	Check if the safeguard enclosure is in place. Check if emergency stop is triggered when the door is opened. Check if warning labels are affixed at the entrance and clearly visible.
Emergency stop device	Press the emergency stop button to check if it works.
Robot movement	Check for abnormal movement and excessive vibration and noise. (If any abnormal symptom is found, contact OMRON dealer.)
Z-axis brake operation *1	Check if the brake works to stop the Z-axis from dropping more than 3mm from the stationary point. (If any abnormal operation is found, contact OMRON dealer.)

^{*1} Visually check the Z-axis movement when you press the emergency stop button from outside the safeguard enclosure and also when you turn off the controller.

(3) Adjustment and parts replacement

- 1) After inspection, if you notice any adjustment or parts replacement is needed, first turn off the controller and then enter the safeguard enclosure to perform the necessary work. After adjustment or replacement is finished, again review the checkpoints outlined in (1) and (2) above.
- 2) If repair or parts replacement is required for the robot or controller, please contact your OMRON dealer. This work requires specialized technical knowledge and skill, so do not attempt it by yourself.

Six-Month Inspection 4

Take the following precautions when performing 6-month inspection.



⚠ WARNING

INJURY CAN OCCUR IF HANDS OR FINGERS ARE SQUEEZED BETWEEN THE DRIVE PULLEY AND BELT. ALWAYS TURN OFF THE CONTROLLER AND USE CAUTION WHEN HANDLING THESE PARTS.



WARNING

THE Z-AXIS WILL SLIDE DOWN WHEN THE Z-AXIS BRAKE IS RELEASED, CAUSING A HAZARDOUS SITUATION. DO NOT RELEASE THE BRAKE WHEN LUBRICATING THE Z-AXIS PARTS.

When lubricating the ball screw, spline shaft and linear busing shaft, observe the following precautions.



WARNING

PRECAUTIONS WHEN HANDLING GREASE:

- INFLAMMATION MAY OCCUR IF THIS GETS IN THE EYES. BEFORE HANDLING THE GREASE, WEAR YOUR SAFETY GOGGLES TO ENSURE THE GREASE WILL NOT COME IN CONTACT WITH THE EYES.
- INFLAMMATION MAY OCCUR IF THE GREASE COMES INTO CONTACT WITH SKIN. BE SURE TO WEAR PROTECTIVE GLOVES TO PREVENT CONTACT WITH SKIN.
- DO NOT TAKE ORALLY OR EAT. (EATING WILL CAUSE DIARRHEA AND VOMITING.)
- HANDS AND FINGERS MIGHT BE CUT WHEN OPENING THE CONTAINER, SO USE PROTECTIVE GLOVES.
- •KEEP OUT OF THE REACH OF CHILDREN.
- DO NOT HEAT THE GREASE OR PLACE NEAR AN OPEN FLAME SINCE THIS COULD LEAD TO SPARKS AND FIRES.

EMERGENCY TREATMENT:

- IF THIS GREASE GETS IN THE EYES, WASH LIBERALLY WITH PURE WATER FOR ABOUT 15 MINUTES AND CONSULT A PHYSICIAN FOR TREATMENT.
- IF THIS GREASE COMES IN CONTACT WITH THE SKIN, WASH AWAY COMPLETELY WITH SOAP AND WATER.
- IF TAKEN INTERNALLY, DO NOT INDUCE VOMITING BUT PROMPTLY CONSULT A PHYSICIAN FOR TREATMENT.

WARNING

DISPOSING OF GREASE AND THE CONTAINER:

- PROPER DISPOSAL IS COMPULSORY UNDER FEDERAL, STATE AND LOCAL REGULATIONS. TAKE APPROPRIATE MEASURES IN COMPLIANCE WITH LEGAL REGULATIONS.
- •DO NOT PRESSURIZE THE EMPTY CONTAINER. PRESSURIZING MAY CAUSE THE CONTAINER TO RUPTURE.
- DO NOT ATTEMPT TO WELD, HEAT UP, DRILL HOLES OR CUT THIS CONTAINER. THIS MIGHT CAUSE THE CONTAINER TO EXPLODE AND THE REMAINING MATERIALS INSIDE IT TO IGNITE.



CAUTION

UNLESS GREASE SPECIFIED BY OMRON IS USED, THE SERVICE LIFE OF THE BALL SCREW, BALL SPLINE AND LINEAR BUSHING SHAFT WILL SHORTEN.

CAUTION

HOW TO KEEP GREASE:

- •TIGHTLY CAP THE GREASE TUBE OR CONTAINER TO PREVENT DUST OR MOISTURE FROM ENTERING IT.
- •KEEP THE GREASE IN DARK LOCATIONS NOT EXPOSED TO DIRECT SUNLIGHT.

(1) Inspection to be performed with the controller turned off

- 1) Turn off the controller.
- 2) Place a sign showing that the robot is being inspected, to keep others from operating the controller switch.
- 3) Enter the safeguard enclosure and check the following points.

Checkpoint	Procedure
Manipulator bolts and screws (Only for	
major bolts and screws exposed	Check for looseness and tighten if necessary.*1
externally)	
Z-axis and R-axis timing belts	Check belt tension. (See 8 in Chapter 4.)
Detection areas of the origin sensors of	Clean if it is dirty.
the X-axis, Y-axis, and R-axis	,
Controller	Check for looseness at each terminal and connector on the
Controller	panel. (See 4 in Chapter 3.)
	Every 6 month, lubricate the Z-axis ball screw nut with
Grease lubrication of Z-axis ball screw,	grease gun, and the linear shaft, spline shaft and ball screw
spline, linear shaft	shaft by hand after removing the old grease. The specified
	grease is LG2 (Nihon Seiko).
7 axis ball spling ball scrow	Check for backlash. (If any abnormality is found, contact
Z-axis ball spline, ball screw	OMRON dealer.)

*1 Bolt tightening torque

Bolt size	Tightening torque (kgf⋅cm)	Tightening torque (N⋅m)
M3 button head bolt	14	1.4
M3	20	2.0
M4	46	4.5
M5	92	9.0
M6	156	15.3
M8	380	37
M10	720	71
M12	1310	128

(2) Inspection to be performed with the controller turned on

\triangle	,
$\overline{}$	

WARNING

THE ROBOT CONTROLLER MUST BE INSTALLED OUTSIDE THE SAFEGUARD ENCLOSURE, TO PREVENT A HAZARDOUS SITUATION IN WHICH YOU OR ANYONE ENTER THE SAFEGUARD ENCLOSURE TO INSPECT THE CONTROLLER WHILE IT IS TURNED ON.

⚠ WARNING

- BODILY INJURY MAY OCCUR FROM COMING INTO CONTACT WITH THE FAN WHILE IT IS ROTATING.
- WHEN REMOVING THE FAN COVER FOR INSPECTION, FIRST TURN OFF THE CONTROLLER AND MAKE SURE THE FAN HAS STOPPED.

After turning on the controller, check the following points.

Checkpoint	Procedure	
Cooling fan at rear of controller	 Check if the fan rotates normally. Check if objects blocking the fan are located and remove if any are found. Check for abnormal noise from the rotating fan. If abnormal noise is heard, visually check and remove the cause. If no cause is found, contact OMRON dealer. Check for dust on the fan cover. Remove and clean if necessary. 	

(3) Adjustment and parts replacement

- 1) If adjustment or parts replacement is required after inspection, turn off the robot controller before entering the safeguard enclosure and beginning the work. Follow the instructions explained in items (1) and (2) for six-month inspection.
- 2) If repair or parts replacement is required for the robot or controller, please contact your OMRON dealer. This work requires specialized technical knowledge and skill, so do not attempt it by yourself.

5 Replacing the Harmonic Drive

The XC series robots use a harmonic drive as the speed reduction gear for the X, Y and R axes. Harmonic drives need to be replaced after a specified operation time. Use the guideline explained below to determine the replacement period and replace the harmonic drive periodically.

Since the XC series robots use long-life harmonic grease, it is not necessary to replace the harmonic grease.

5-1 Replacement period

where

The harmonic drive replacement period is determined by the total number of turns of the wave generator used in the harmonic drive. It is recommended to replace the harmonic drive when the total number of turns has reached 8.4×10^8 (at ambient operating temperatures of 0°C to +40°C). This means that the replacement period will differ depending on the following operating conditions. If the robot operation duty ratio is high or the robot is operated in environments at higher temperatures, the harmonic drive should be replaced earlier.

Replacement period = $8.4 \times 10^8 / (n \times 60 \times h \times D \times N \times \theta)$ years

n : Number of axis movements per minute

 θ : Average turn per axis movement

N : Speed reduction ratioh : Operation time per dayD : Operation days per year

For example, when the robot is used under the following conditions, the replacement period for the X-axis harmonic drive of the R6YXC500 can be calculated as follows

n : 10 θ : 0.25 N : 80

h : 24 hours per day D : 240 days per year

Replacement period = $8.4 \times 10^8 / (n \times 60 \times h \times D \times N \times \theta)$

 $= 8.4 \times 10^{8} / (10 \times 60 \times 24 \times 240 \times 80 \times 0.25)$

= 12.2 years

Table 5-1 Harmonic drive speed reduction ratio

Robot model	X-axis	Y-axis	R-axis
R6YXCH250, R6YXCH350, R6YXCH400	50	50	50
R6YXC500, R6YXC600	80	80	50
R6YXC700, R6YXC800	80	80	50
R6YXC1000	100	80	50

Table 5-2 Bolt tightening torque

Bolt size	Tightening torque (kgf⋅cm)	Tightening torque (N·m)
M3 button head bolt	14	1.4
M3	20	2.0
M4	46	4.5
M5	92	9.0
M6	156	15.3
M8	380	37
M10	720	71

5-2 Basic replacement procedure for harmonic drive and precautions

Basic procedures and precautions for replacing the harmonic drive are described below. Before beginning the replacement work, always be sure to read these replacement procedures and caution.

WARNING

THE MOTOR AND SPEED REDUCTION GEAR CASING ARE EXTREMELY HOT AFTER AUTOMATIC OPERATION. SO BURNS MAY OCCUR IF THESE ARE TOUCHED. BEFORE TOUCHING THESE PARTS, TURN OFF THE CONTROLLER. WAIT FOR A WHILE AND CHECK THAT THE TEMPERATURE HAS COOLED.

M WARNING

PRECAUTIONS WHEN HANDLING GREASE, CLEANNING OIL:

- •INFLAMMATION MAY OCCUR IF THIS GETS IN THE EYES. BEFORE HANDLING THE GREASE, WEAR YOUR SAFETY GOGGLES TO ENSURE THE GREASE WILL NOT COME IN CONTACT WITH THE EYES.
- INFLAMMATION MAY OCCUR IF THE GREASE COMES INTO CONTACT WITH SKIN. BE SURE TO WEAR PROTECTIVE GLOVES TO PREVENT CONTACT WITH SKIN.
- DO NOT TAKE ORALLY OR EAT. (EATING WILL CAUSE DIARRHEA AND VOMITING.)
- HANDS AND FINGERS MIGHT BE CUT WHEN OPENING THE CONTAINER, SO USE PROTECTIVE GLOVES.
- •KEEP OUT OF THE REACH OF CHILDREN.
- DO NOT HEAT THE GREASE OR PLACE NEAR AN OPEN FLAME SINCE THIS COULD LEAD TO SPARKS AND FIRES.

EMERGENCY TREATMENT:

- IF THIS GREASE GETS IN THE EYES, WASH LIBERALLY WITH PURE WATER FOR ABOUT 15 MINUTES AND CONSULT A PHYSICIAN FOR TREATMENT.
- IF THIS GREASE COMES IN CONTACT WITH THE SKIN, WASH AWAY COMPLETELY WITH SOAP AND WATER.
- IF TAKEN INTERNALLY, DO NOT INDUCE VOMITING BUT PROMPTLY CONSULT A PHYSICIAN FOR TREATMENT.



WARNING

DISPOSING OF HARMONIC GREASE, CLEANING OIL AND THE CONTAINER:

- PROPER DISPOSAL IS COMPULSORY UNDER FEDERAL, STATE AND LOCAL REGULATIONS. TAKE APPROPRIATE MEASURES IN COMPLIANCE WITH LEGAL REGULATIONS.
- DO NOT PRESSURIZE THE EMPTY CONTAINER. PRESSURIZING MAY CAUSE THE CONTAINER TO RUPTURE.
- DO NOT ATTEMPT TO WELD, HEAT UP, DRILL HOLES OR CUT THIS CONTAINER, THIS MIGHT CAUSE THE CONTAINER TO EXPLODE AND THE REMAINING MATERIALS INSIDE IT TO IGNITE.



⚠ WARNING

WHEN REMOVING THE WAVE GENERATOR FROM THE MOTOR SHAFT OR REINSTALLING IT BACK ONTO THE MOTOR SHAFT, USE CAUTION TO AVOID AS MUCH AS POSSIBLE, APPLYING A THRUST LOAD TO THE MOTOR SHAFT. IF A LOAD IS APPLIED, THE RESOLVER MAY BE DAMAGED RESULTING IN A HAZARDOUS SITUATION OF THE ROBOT TROUBLE



ACAUTION

THE HARMONIC DRIVE SERVICE LIFE MAY SHORTEN IF THE GREASE RECOMMENDED BY OMRON IS NOT USED

Recommended grease

Use the following harmonic drive grease. 4B No.2 (made by Harmonic Drive Systems Inc.)



CAUTION

HARMONIC DRIVE:

- DO NOT APPLY STRONG SHOCKS OR IMPACTS TO THESE PARTS SUCH AS WITH A HAMMER. ALSO, DO NOT SCRATCH, SCAR OR DENT THESE PARTS BY DROPPING, ETC. SUCH ACTIONS WILL DAMAGE THE HARMONIC DRIVE.
- •THE SPECIFIED PERFORMANCE CANNOT BE MAINTAINED IF ANY PART OF THE HARMONIC DRIVE IS USED IN A DAMAGED STATE. THIS DAMAGE OR WEAR MAY ALSO LEAD TO TROUBLE WITH THE HARMONIC DRIVE.



CAUTION

SINCE A POSITIONAL SHIFT OCCURS AFTER REPLACING THE HARMONIC DRIVE, IT IS NECESSARY TO MAKE ABSOLUTE RESET, STANDARD COORDINATE SETTING AND POINT DATA SETTING AGAIN.

5-2-1 R6YXCH250, R6YXCH350, R6YXCH400

The following steps describe procedures and precautions when replacing the harmonic drives of the R6YXCH250, R6YXCH350 and R6YXCH400. For the bolt tightening torques in this work, refer to Table 5-2.

1. X-axis

- 1) Prepare the following tools and items.
 - Harmonic grease 4B No.2
 - Waste cloth (rag)
 - Phillips-head screwdriver
 - Hex wrench set
 - Screw Lock (thread sealant)
 - Ratchet handle
 - Hexagonal socket set
 - Extension bar
 - Torque-limiting wrench
 - Replacement parts (See table below.)

Replacement parts			
Parts name	Type No .	OMRON Parts No.	Note
Harmonic	SHF-20-50	KN3-M2110-001	
	S71(JIS)	KN3-M2159-000	Top of harmonic drive
O-ring	Rubber wire diameter 1.50mm x Ring inner diameter 49.00mm	KN3-M2143-000	For motor
	Rubber wire diameter 0.99mm x Ring inner diameter 53.28mm	KN3-M2144-000	Supplied with harmonic drive

- 2) Turn off the controller.
- 3) Place a sign indicating that the robot is being inspected, to keep others from operating the controller switch.
- 4) Enter the safeguard enclosure.
- 5) Remove the base (robot pedestal) front and rear covers.

 Refer to "7 Removing the Robot Covers" in Chapter 4 for removing the covers.



WHEN YOU REMOVE THE X-AXIS ARM INSTALLATION BOLTS (M3×40L, 8 PIECES) IN THE NEXT STEP, THE X-AXIS ARM MAY COME OFF CAUSING A HAZARDOUS SITUATION. BE ESPECIALLY CAREFUL TO KEEP THE ARM FROM FALLING WHEN A HEAVY TOOL IS ATTACHED TO THE ARM TIP.

6) Remove the X-axis arm installation bolts (M3×40L, 8 pieces). (See Fig. 5-1.)




Fig. 5-1



AN O-RING IS FITTED TO THE X-AXIS ARM, SO BE CAREFUL NOT TO LET IT DROP INTO THE PERIPHERAL UNIT. (SEE FIG. 5-2.)





Fig. 5-2

7) Disconnect the connectors on the X-axis motor power cable XM and resolver cable XP.

8) Remove the base assembly bolts (M6 \times 14L, 6 pieces) to separate base 1 and base 2. (See Fig. 5-1 and Fig. 5-3.)



9) Remove the bolts (M5×12L, 4 pieces) securing the motor and remove the motor from base 1. (See Fig. 5-4.)




Fig. 5-4



AN O-RING IS FITTED TO THE MOTOR, SO BE CAREFUL NOT TO LET IT DROP INTO THE PERIPHERAL UNIT.

- 10) Remove the wave generator from the motor shaft. The wave generator is secured with an M3 set screw. (See Fig. 5-6.)
- 11) Remove the X-axis harmonic drive installation bolts (M3×20L, 16 pieces). (See Fig. 5-5.)




Fig. 5-5

12) Remove the X-axis harmonic drive from the top of base 1.



AN O-RING IS FITTED TO THE X-AXIS HARMONIC DRIVE, SO BE CAREFUL NOT TO LET IT DROP INTO THE PERIPHERAL UNIT.

13) Fit an O-ring (supplied with the harmonic drive) coated with harmonic grease into the O-ring groove on the new harmonic drive. Apply small amounts of "Screw Lock" to the bolts (M3×20L, 16 pieces) and tighten them to secure the harmonic drive from the backside of the base. (See Fig. 5-5.)



CAUTION

DO NOT ALLOW THE O-RING TO GET CAUGHT OUT OF THE GROOVE DURING REASSEMBLY. A TROUBLE WILL OCCUR IF THE ROBOT IS OPERATED WITH THE O-RING LEFT CAUGHT OUT OF THE GROOVE.

14) Apply harmonic grease to the new wave generator and flexible spline. See Fig. 5-6 for applying grease properly.




Fig. 5-6

- 15) Fit the wave generator onto the motor shaft and fully insert it against the motor. Then, apply small amounts of "Screw Lock" to the M3 set screw (1 piece) you removed earlier and tighten it to secure the wave generator. (See Fig. 5-6.)
- 16) Fit a new O-ring to the motor and secure the motor to base 1 with the bolts (M5×12L, 4 pieces) you removed earlier. (See Fig. 5-4.)



DO NOT ALLOW THE O-RING TO GET CAUGHT OUT OF THE GROOVE DURING REASSEMBLY, A TROUBLE WILL OCCUR IF THE ROBOT IS OPERATED WITH THE O-RING LEFT CAUGHT OUT OF THE GROOVE.

- 17) Fasten base 1 to base 2 with the bolts (M6×14L, 6 pieces) you removed earlier. (See Fig. 5-3.)
- 18) Reattach the connectors on the X-axis motor power cable XM and resolver cable XP.
- 19) Fit a new O-ring into the O-ring groove on the X-axis arm and place the arm on the harmonic drive. Then, apply small amounts of "Screw Lock" to the bolts (M3×40L, 8 pieces) you removed earlier and tighten them uniformly to secure the X-axis arm to the base. (See Fig. 5-1 and Fig. 5-2.)



CAUTION

DO NOT ALLOW THE O-RING TO GET CAUGHT OUT OF THE GROOVE DURING REASSEMBLY. A TROUBLE WILL OCCUR IF THE ROBOT IS OPERATED WITH THE O-RING LEFT CAUGHT OUT OF THE GROOVE.

- 20) Reattach the base (robot pedestal) front and rear covers.
- 21) Go outside the safeguard enclosure.
- 22) Check that no one is inside the safeguard enclosure, and then turn on the controller.



AFTER THE HARMONIC DRIVE IS REPLACED, AN ABSOLUTE RESET MUST BE PERFORMED, AND THE STANDARD COORDINATE AND POINT DATA MUST BE RESET. REFER TO "CHAPTER 4 ADJUSTMENT" TO ADJUST IT.

2. Y-axis

- 1) Prepare the following tools and items.
 - Harmonic grease 4B No.2
 - Waste cloth (rag)
 - Phillips-head screwdriver
 - Hex wrench set
 - Screw Lock (thread sealant)
 - Torque-limiting wrench
 - Replacement parts (See table below.)

Replacement parts			
Parts name	Type No.	OMRON Parts No.	Note
Harmonic drive	SHF-17-50	KN3-M2510-001	
	S63(JIS)	KN3-M2519-000	Lower part of harmonic drive
O-ring	Rubber wire diameter 1.00mm x Ring inner diameter 29.50mm	KN3-M257K-000	For motor
	Rubber wire diameter 0.80mm x Ring inner diameter 45.40mm	KN3-M257L-000	Supplied with harmonic drive

- 2) Turn off the controller.
- 3) Place a sign indicating that the robot is being inspected, to keep others from operating the controller switch.
- 4) Enter the safeguard enclosure.
- 5) Remove the Y-axis arm upper cover. Place the cover on the robot base (pedestal) side with the machine harness still connected. Refer to "7 Removing the Robot Covers" in Chapter 4 for removing the covers.



WHEN YOU REMOVE THE Y-AXIS ARM INSTALLATION BOLTS (M3×20L, 8 PIECES) IN THE NEXT STEP, THE Y-AXIS ARM MAY COME OFF CAUSING A HAZARDOUS SITUATION. BE ESPECIALLY CAREFUL TO KEEP THE ARM FROM FALLING WHEN A HEAVY TOOL IS ATTACHED TO THE ARM TIP..

6) Remove the Y-axis arm installation bolts (M3×20L, 8 pieces). (See Fig. 5-7.)




Fig. 5-7

7) Remove the Y-axis arm and place it where it will not obstruct the work.

CAUTION

AN O-RING IS FITTED TO THE UPPER SURFACE OF THE HARMONIC DRIVE, SO BE CAREFUL NOT TO LET IT DROP INTO THE PERIPHERAL UNIT.

- 8) Remove the wave generator from the motor shaft. The wave generator is secured with an M3 set screws (2 pieces). (See Fig. 5-10.)
- 9) Remove the flange installation bolts (M5×20, 6 pcs) and then detach the flange from the X-axis arm. Next, remove the bolts (M3×20, 6 pcs) securing the Y-axis harmonic drive. (See Fig. 5-8.)




Fig. 5-8

10) Remove the Y-axis harmonic drive from the flange.

CAUTION

AN O-RING IS FITTED TO THE FLANGE, SO BE CAREFUL NOT TO DROP IT INTO PERIPHERAL UNITS. (SEE FIG. 5-9.)




Fig. 5-9

11) Remove the four bolts temporarily tightened to the new harmonic drive.



CAUTION

REMOVE ONLY THE FOUR BOLTS SHOWN IN FIG. 5-10 AT THIS POINT. NEVER REMOVE THE BOLTS ON THE OPPOSITE SIDE. IF THEY ARE REMOVED, THE HARMONIC DRIVE AXIS MAY DEVIATE FROM THE CENTER CAUSING A TROUBLE.

- 12) Fit a new O-ring coated with harmonic grease into the O-ring groove on the Flange. (See Fig. 5-9.)
- 13) Place the new harmonic drive on the flange. Apply small amounts of "Screw Lock" (thread sealer) to the bolts (M3×20, 6 pcs) and tighten them equally from the backside of the flange to secure the harmonic drive. Next, place the flange on the X-axis arm and tighten the bolts (M5×20) from the backside to secure the flange. (See Fig. 5-8.)



CAUTION

DO NOT ALLOW THE O-RING TO GET CAUGHT OUT OF THE GROOVE DURING REASSEMBLY, A TROUBLE WILL OCCUR IF THE ROBOT IS OPERATED WITH THE O-RING LEFT CAUGHT OUT OF THE GROOVE.

- 14) Fit an O-ring (supplied with the harmonic drive) coated with harmonic grease into the O-ring groove on the new harmonic drive
- 15) Apply harmonic grease to the new wave generator and flexible spline. See Fig. 5-10 for applying grease properly.

16) Fit the wave generator onto the motor shaft and fully insert it against the motor. Then, apply small amounts of "Screw Lock" to the M3 set screw (2 piece) you removed earlier and tighten it to secure the wave generator. (See Fig. 5-10.)




Fig. 5-10

17) Secure the Y-axis arm to the harmonic drive with the bolts (M3×20L, 8 pieces) you removed earlier. Apply small amounts of "Screw Lock" to the bolts and tighten them uniformly to secure the Y-axis arm. (See Fig. 5-7.)

CAUTION

DO NOT ALLOW THE O-RING TO GET CAUGHT OUT OF THE GROOVE DURING REASSEMBLY. A TROUBLE WILL OCCUR IF THE ROBOT IS OPERATED WITH THE O-RING LEFT CAUGHT OUT OF THE GROOVE. WHEN REASSEMBLING THE HARMONIC DRIVE, BE CAREFUL TO KEEP THE CIRCULAR SPLINE FROM COMING OFF. IF IT COMES OFF, THE HARMONIC DRIVE AXIS WILL DEVIATE FROM THE CENTER CAUSING A TROUBLE.

- 18) Reattach the Y-axis arm upper cover.
- 19) Go outside the safeguard enclosure.
- 20) Check that no one is inside the safeguard enclosure, and then turn on the controller.

3. R-axis

- 1) Prepare the following tools and items.
 - Harmonic grease 4B No.2
 - Waste cloth (rag)
 - Phillips-head screwdriver
 - Hex wrench set
 - Screw Lock (thread sealant)
 - Torque-limiting wrench
 - Adjustable wrench
 - Replacement parts (See table below.)

Replacement parts			
Parts name	Type No .	OMRON Parts No.	Note
Harmonic drive	SHF-14-50	KN3-M1821-001	
	S53(JIS)	KN3-M1895-000	Lower part of harmonic drive Upper part of bellows. (2 pieces)
	Rubber wire diameter 0.80mm x Ring inner diameter 23.70mm	KN3-M181H-000	For wave generator
	Rubber wire diameter 0.60mm x Ring inner diameter 37.10mm	KN5-M181G-000	Supplied with harmonic drive
Edge seal	VR18A	KN3-M1886-000	

- 2) Turn off the controller.
- 3) Place a sign indicating that the robot is being inspected, to keep others from operating the controller switch.
- 4) Enter the safeguard enclosure.
- 5) Remove the Y-axis upper cover and bellows. Place the cover on the robot base (pedestal) side with the machine harness still connected.

 Refer to "7 Removing the Robot Covers" in Chapter 4 for removing and reattaching the covers. Refer to "6 Replacing the bellows" in Chapter 5 for removing and reattaching the bellows.
- 6) Remove the bolts (M4×8L, 4 pieces) securing the bearing to the upper end of the spline and remove the spline mount plate, spline and bearing from the holder. (See Fig. 5-11.)




Fig. 5-11



THE Z-AXIS WILL SLIDE DOWN WHEN THE U-NUT IS REMOVED IN THE NEXT STEP, CAUSING A HAZARDOUS SITUATION. PROP THE Z-AXIS WITH A SUPPORT STAND BEFORE LOOSENING THE U-NUT.

7) While placing a steel rod or similar tool through the 5mm diameter hole at the lower part of the spline, loosen the U-nut at the top of the spline with the wrench, and remove the bearing. (See Fig. 5-12.)

Use a round steel rod with a diameter slightly smaller than 5mm. Avoid using a square rod because the spline might be damaged by the edge of the rod.

After removing the bearing, refit the U-nut to the top of the spline shaft to keep the spline shaft from falling out.




Fig. 5-12

8) Remove the button bolts (M3×20L, 6 pieces) on the underside of the Y-axis arm and remove the plate fastening the spline and the harmonic drive. (See Fig. 5-13.)




Fig. 5-13

AN O-RING IS FITTED TO THE FASTENING PLATE, SO BE CAREFUL NOT TO LET IT DROP INTO THE PERIPHERAL UNIT. (SEE FIG. 5-14.)




Fig. 5-14

9) Remove the bolts (M3×6L, 3 pieces) securing the R-axis motor plate at the top of the Y-axis arm. (See Fig. 5-15.)




Fig. 5-15

- 10) Loosen the pulley set screw (M4, 2 pieces) and remove the pulley from the wave generator. (See Fig. 5-15.)
- 11) Remove the harmonic drive installation bolts (M3×18L, 8 pieces) and pull out the harmonic drive from the bottom of the Y-axis arm. (See Fig. 5-15.)

CAUTION

AN O-RING IS FITTED TO THE HARMONIC DRIVE, SO BE CAREFUL NOT TO LET IT DROP INTO THE PERIPHERAL UNIT.

- 12) Remove the retaining ring for the wave generator and pull out the wave generator from the bottom of the Y-axis arm. (See Fig. 5-16.)
- 13) Apply harmonic grease to the new wave generator. See Fig. 5-16 for applying grease properly.
- 14) Fit a new O-ring into the O-ring groove on the wave generator. (See Fig. 5-16.)




Fig. 5-16

15) Insert the new wave generator into the Y-axis arm from the bottom, and secure it with the retaining ring. The chamfered side of the retaining ring should face downwards.



DO NOT ALLOW THE O-RING TO GET CAUGHT OUT OF THE GROOVE DURING REASSEMBLY. A TROUBLE WILL OCCUR IF THE ROBOT IS OPERATED WITH THE O-RING LEFT CAUGHT OUT OF THE GROOVE.

- 16) Apply harmonic grease to the circular spline. See Fig. 5-16 for applying grease properly.
- 17) Remove the four bolts temporarily tightened to the new harmonic drive.



REMOVE ONLY THE FOUR BOLTS SHOWN IN FIG. 5-16 AT THIS POINT. NEVER REMOVE THE BOLTS ON THE OPPOSITE SIDE. IF THEY ARE REMOVED, THE HARMONIC DRIVE AXIS MAY DEVIATE FROM THE CENTER CAUSING A TROUBLE.

18) Fit an O-ring (supplied with the harmonic drive) coated with harmonic grease into the O-ring groove on the new harmonic drive. Apply small amounts of "Screw Lock" to the bolts (M3×18L, 8 pieces) and tighten them to secure the harmonic drive to the Y-axis arm from the top of the Y-axis arm.

CAUTION

DO NOT ALLOW THE O-RING TO GET CAUGHT OUT OF THE GROOVE DURING REASSEMBLY. A TROUBLE WILL OCCUR IF THE ROBOT IS OPERATED WITH THE O-RING LEFT CAUGHT OUT OF THE GROOVE. WHEN REASSEMBLING THE HARMONIC DRIVE, BE CAREFUL TO KEEP THE CIRCULAR SPLINE FROM COMING OFF. IF IT COMES OFF, THE HARMONIC DRIVE AXIS WILL DEVIATE FROM THE CENTER CAUSING A TROUBLE.

- 19) Apply small amounts of "Screw Lock" to the M4 set screws (2 pieces) and tighten them to secure the pulley to the wave generator.
- 20) Check that the timing belt is fitted on the wave generator pulley and motor pulley, and then secure the motor plate. (See Fig. 5-15.)



CAUTION


IT IS NECESSARY TO APPLY CORRECT TENSION TO THE TIMING BELT DURING REASSEMBLY REFER TO "8 ADJUSTING THE TIMING BELT TENSION" IN CHAPTER 4.

21) Fit a new O-ring into the O-ring groove on the fastening plate and also replace the edge seal on the fastening plate with new one. (See Fig. 5-17.) Next, secure the fastening plate to the harmonic drive with the button bolts (M3×20L, 6 pieces) you removed earlier. (See Fig. 5-13.) At this point, be careful to keep the spline shaft from coming off the spline nut.



CAUTION

THE HARMONIC DRIVE SERVICE LIFE MAY SHORTEN IF THE EDGE SEAL EFFECT IS INSUFFICIENT, SO CAREFULLY REASSEMBLE THE PARTS.



5-25

- 22) Insert the spline into the holder, fit the bearing onto the spline and tighten the U-nut to secure the baring. (Utilize the φ5 through-hole when tightening the U-nut like you did to loosen it.) (See Fig. 5-11 and Fig. 5-12.)
- 23) Attach the bearing mount plate to the holder and fasten them with the bolts you removed earlier (M4×8L, 4 pieces).
- 24) Reattach the Y-axis arm upper cover.
- 25) Go outside the safeguard enclosure.
- 26) Check that no one is inside the safeguard enclosure, and then turn on the controller.



AFTER THE HARMONIC DRIVE IS REPLACED, THE ABSOLUTE RESET MUST BE PERFORMED, AND THE POINT DATA MUST BE RESET. REFER TO "CHAPTER 4 ADJUSTMENT" TO ADJUST IT.

5-2-2 **R6YXC500**, **R6YXC600**

The following steps describe procedures and precautions when replacing the harmonic drives of the R6YXC500 and R6YXC600.

For the bolt tightening torques in this work, refer to Table 5-2.

1. X-axis

- 1) Prepare the following tools and items.
 - Harmonic grease 4B No.2
 - Waste cloth (rag)
 - Phillips-head screwdriver
 - Hex wrench set
 - Screw Lock (thread sealant)
 - Ratchet handle
 - Hexagonal socket set
 - Extension bar
 - Torque-limiting wrench
 - Replacement parts (See table below.)

Replacement parts			
Parts name	Type No .	OMRON Parts No.	Note
Harmonic	SHF-25-80	KN4-M2110-001	
O-ring	S90(JIS)	KN4-M2143-000	Top of harmonic drive
	Rubber wire diameter 1.78mm x Ring inner diameter 85.00mm	KN4-M2159-000	Base (robot pedestal)
	Rubber wire diameter 1.78mm x Ring inner diameter 69.57mm	KN5-M2143-000	Motor
	Rubber wire diameter 1.30mm x Ring inner diameter 66.50mm	KN5-M257L-000	Supplied with harmonic drive

- 2) Turn off the controller.
- 3) Place a sign indicating that the robot is being inspected, to keep others from operating the controller switch.
- 4) Enter the safeguard enclosure.
- 5) Remove the base (robot pedestal) front and rear covers and the X-axis arm upper cover.
 - Refer to "7 Removing the Robot Covers" in Chapter 4 for removing the covers.
- 6) Disconnect the connectors on the X-axis motor power cable XM and resolver cable XP.

7) Remove the bolts (M6×20L, 4 pieces) securing the motor holder by using the ratchet handle, M6 hexagonal socket, socket adapter and extension bar. (See Fig. 5-18.)




Fig. 5-18

8) With the motor still attached to the motor holder, pull out the motor by swaying it gently right and left. If it is difficult to remove the motor holder, slowly rotate the X-axis arm and again try removing the motor holder.



CAREFULLY REMOVE THE MOTOR HOLDER SO AS NOT TO LET HANDS OR FINGERS GET PINCHED BETWEEN THE MOTOR HOLDER AND THE BASE.

AN O-RING IS FITTED TO THE MOTOR HOLDER, SO BE CAREFUL NOT TO LET IT DROP INTO THE PERIPHERAL UNIT.

9) Remove the bolts (M6×14L, 4 pieces) securing the motor and remove the motor from the motor holder. (See Fig. 5-18.)

A CAUTION

AN O-RING IS FITTED TO THE MOTOR, SO BE CAREFUL NOT TO LET IT DROP INTO THE PERIPHERAL UNIT.

10) Remove the wave generator from the motor shaft. The wave generator is secured with an M4 set screw and keyway. (See Fig. 5-22.)

CAUTION

A SPACER IS INSERTED BETWEEN THE WAVE GENERATOR AND THE MOTOR, SO BE CAREFUL NOT TO LOSE IT.




WHEN YOU REMOVE THE X-AXIS ARM INSTALLATION BOLTS (M4×40L, 8 PIECES) IN THE NEXT STEP, THE X-AXIS ARM MAY COME OFF CAUSING A HAZARDOUS SITUATION. BE ESPECIALLY CAREFUL TO KEEP THE ARM FROM FALLING WHEN A HEAVY TOOL IS ATTACHED TO THE ARM TIP.

WARNING

REMOVING THE X-AXIS ARM IS DANGEROUS FOR JUST ONE PERSON. ALWAYS USE TWO OR MORE PEOPLE, OR REMOVE THE Y-AXIS ARM IN ADVANCE.

REFER TO "2. Y-AXIS" OF "5-2-2" FOR REMOVING THE Y-AXIS ARM.


11) Remove the X-axis arm installation bolts (M4×40L, 8 pieces). (See Fig. 5-19.)



12) Remove the X-axis arm and place it where it will not obstruct the work.

CAUTION

AN O-RING IS FITTED TO THE X-AXIS ARM, SO BE CAREFUL NOT TO LET IT DROP INTO THE PERIPHERAL UNIT. (SEE FIG. 5-20.)



13) Remove the bolts (M4×20L, 12 pieces) securing the X-axis harmonic drive. (See Fig. 5-21.)




Fig. 5-21

14) Remove the X-axis harmonic drive from the top of the base.



AN O-RING IS FITTED TO THE X-AXIS HARMONIC DRIVE, SO BE CAREFUL NOT TO LET IT DROP INTO THE BASE OR PERIPHERAL UNIT.

15) Fit an O-ring (supplied with the harmonic drive) coated with harmonic grease into the O-ring groove on the new harmonic drive. (See Fig. 5-22.) Apply small amounts of "Screw Lock" to the bolts (M4×20L, 12 pieces) and tighten them to secure the harmonic drive from the backside of the base. (See Fig. 5-21.)

CAUTION

DO NOT ALLOW THE O-RING TO GET CAUGHT OUT OF THE GROOVE DURING REASSEMBLY. A TROUBLE WILL OCCUR IF THE ROBOT IS OPERATED WITH THE O-RING LEFT CAUGHT OUT OF THE GROOVE.

- 16) Apply harmonic grease to the new wave generator and flexible spline. See Fig. 5-22 for applying grease properly.
- 17) Fit a new O-ring into the O-ring groove on the X-axis arm (see Fig. 5-20) and secure it to the harmonic drive. Then apply small amounts of "Screw Lock" to the bolts (M4×40L, 8 pieces) you removed earlier and tighten them uniformly to secure the X-axis arm. (See Fig. 5-19.)

CAUTION

DO NOT ALLOW THE O-RING TO GET CAUGHT OUT OF THE GROOVE DURING REASSEMBLY. A TROUBLE WILL OCCUR IF THE ROBOT IS OPERATED WITH THE O-RING LEFT CAUGHT OUT OF THE GROOVE.

18) Fit the spacer and wave generator onto the motor shaft, and fully insert them against the motor. Then, apply small amounts of "Screw Lock" to the M4 set screw (1 piece) you removed earlier and tighten it to secure the wave generator onto the motor shaft. (See Fig. 5-22.)




Fig. 5-22

19) Fit the O-ring to the motor and secure the motor to the motor holder with the bolts (M6×14L, 4 pieces) you removed earlier. (See Fig. 5-18 and Fig. 5-22.)



DO NOT ALLOW THE O-RING TO GET CAUGHT OUT OF THE GROOVE DURING REASSEMBLY. A TROUBLE WILL OCCUR IF THE ROBOT IS OPERATED WITH THE O-RING LEFT CAUGHT OUT OF THE GROOVE.

20) Fit a new O-ring coated with harmonic grease into the O-ring groove on the motor holder and tighten the bolts (M6×20L, 4 pieces) you removed earlier to temporarily secure the motor holder to the base. (See Fig. 5-18.)

CAUTION

DO NOT ALLOW THE O-RING TO GET CAUGHT OUT OF THE GROOVE DURING REASSEMBLY. A TROUBLE WILL OCCUR IF THE ROBOT IS OPERATED WITH THE O-RING LEFT CAUGHT OUT OF THE GROOVE.

- 21) Uniformly tighten the four bolts (M6×20L) temporarily fastened in the previous step while moving the X-axis by hand slowly left and right through 45°. If any jamming or catching is felt while moving the axis at this time, then reassemble from the beginning.
- 22) Reattach the connectors on the X-axis motor power cable XM and resolver cable XP.
- 23) Reattach the base (robot pedestal) front and rear covers and the X-axis arm upper cover.

- 24) Go outside the safeguard enclosure.
- 25) Check that no one is inside the safeguard enclosure, and then turn on the controller.



AFTER THE HARMONIC DRIVE IS REPLACED, AN ABSOLUTE RESET MUST BE PERFORMED, AND THE STANDARD COORDINATE AND POINT DATA MUST BE RESET. REFER TO "CHAPTER 4 ADJUSTMENT" TO ADJUST IT.

2. Y-axis

- 1) Prepare the following tools and items.
 - Harmonic grease 4B No.2
 - Waste cloth (rag)
 - Phillips-head screwdriver
 - Hex wrench set
 - Screw Lock (thread sealant)
 - Torque-limiting wrench
 - Replacement parts (See table below.)

Replacement parts			
Parts name	Type No .	OMRON Parts No.	Note
Harmonic drive	SHF-20-80	KN4-M2510-001	
O-ring	Rubber wire diameter 1.78mm x Ring inner diameter 72.75mm	KN4-M257K-000	Lower part of harmonic drive
	Rubber wire diameter 1.50mm x Ring inner diameter 49.00mm	KN3-M2143-000	For motor
	Rubber wire diameter 0.99mm x Ring inner diameter 53.28mm	KN3-M2144-000	Supplied with harmonic drive

- 2) Turn off the controller.
- 3) Place a sign indicating that the robot is being inspected, to keep others from operating the controller switch.
- 4) Enter the safeguard enclosure.
- 5) Remove the Y-axis arm upper cover. Place the cover on the robot base (pedestal) side with the machine harness still connected. Refer to "7 Removing the Robot Covers" in Chapter 4 for removing the covers.
- 6) Disconnect the connectors on the Y-axis motor power cable YM and resolver cable YP.
- 7) Remove the Y-axis motor installation bolts (M5×14L, 4 pieces) and then remove the Y-axis motor by swaying it gently right and left. (See Fig. 5-23.)




Fig. 5-23




AN O-RING IS FITTED TO THE MOTOR, SO BE CAREFUL NOT TO LET IT DROP INTO THE PERIPHERAL UNIT.

8) Remove the wave generator from the motor shaft. The wave generator is secured with an M4 set screws. (See Fig. 5-27.)

WARNING

WHEN YOU REMOVE THE Y-AXIS ARM INSTALLATION BOLTS (M3×20L, 12 PIECES) IN THE NEXT STEP, THE Y-AXIS ARM MAY COME OFF CAUSING A HAZARDOUS SITUATION. BE ESPECIALLY CAREFUL TO KEEP THE ARM FROM FALLING WHEN A HEAVY TOOL IS ATTACHED TO THE ARM TIP.

9) Remove the Y-axis arm installation bolts (M3×20L, 12 pieces). (See Fig. 5-24.)



10) Remove the Y-axis arm and place it where it will not obstruct the work.



CAUTION

AN O-RING IS FITTED TO THE UPPER SURFACE OF THE HARMONIC DRIVE, SO BE CAREFUL NOT TO LET IT DROP INTO THE PERIPHERAL UNIT.

11) Remove the Y-axis harmonic drive installation bolts (M3×40L, 8 pieces) from the bottom of the arm. (See Fig. 5-25.)




Fig. 5-25

12) Remove the Y-axis harmonic drive from the top of the X-axis arm.

AN O-RING IS FITTED TO THE UPPER SURFACE OF THE X-AXIS, SO BE CAREFUL NOT TO LET IT DROP INTO THE PERIPHERAL UNIT. (SEE FIG. 5-26.)




Fig. 5-26

- 13) Fit a new O-ring coated with harmonic grease into the O-ring groove on the X-axis arm. (See Fig. 5-26.)
- 14) Place the new harmonic drive on the X-axis arm, and secure it with the bolts (M3×40L, 8 pieces) you removed earlier. Apply small amounts of "Screw Lock" to the bolts and tighten them uniformly to secure the harmonic drive from the backside. (See Fig. 5-25.)



DO NOT ALLOW THE O-RING TO GET CAUGHT OUT OF THE GROOVE DURING REASSEMBLY. A TROUBLE WILL OCCUR IF THE ROBOT IS OPERATED WITH THE O-RING LEFT CAUGHT OUT OF THE GROOVE.

- 15) Fit an O-ring (supplied with the harmonic drive) coated with harmonic grease into the O-ring groove on the new harmonic drive. (See Fig. 5-27.)
- 16) Secure the Y-axis arm to the harmonic drive with the bolts (M3×20L, 12 pieces) you removed earlier. Apply small amounts of "Screw Lock" to the bolts and tighten them uniformly to secure the Y-axis arm. (See Fig. 5-24.)



DO NOT ALLOW THE O-RING TO GET CAUGHT OUT OF THE GROOVE DURING REASSEMBLY. A TROUBLE WILL OCCUR IF THE ROBOT IS OPERATED WITH THE O-RING LEFT CAUGHT OUT OF THE GROOVE.

17) Apply harmonic grease to the new wave generator and flexible spline. See Fig. 5-27 for applying grease properly.

18) Fit the wave generator onto the motor shaft, and fully insert it against the motor. Then, apply small amounts of "Screw Lock" to the M4 set screw (1 piece) you removed earlier and tighten it to secure the wave generator. (See Fig. 5-27.)




Fig. 5-27

19) Fit a new O-ring to the motor and tighten the bolts (M5×14L, 4 pieces) you removed earlier to temporarily secure the motor to the Y-axis arm. (See Fig. 5-23 and Fig. 5-27.)



DO NOT ALLOW THE O-RING TO GET CAUGHT OUT OF THE GROOVE DURING REASSEMBLY. A TROUBLE WILL OCCUR IF THE ROBOT IS OPERATED WITH THE O-RING LEFT CAUGHT OUT OF GROOVE.

- 20) Uniformly tighten the four bolts (M5×12L) temporarily fastened in the previous step while moving the Y-axis by hand slowly left and right through 45°. If any jamming or catching is felt while moving the axis at this time, then reassemble from the beginning.
- 21) Reattach the connectors on the Y-axis motor power cable YM and resolver cable YP.
- 22) Reattach the Y-axis arm upper cover.
- 23) Go outside the safeguard enclosure.
- 24) Check that no one is inside the safeguard enclosure, and then turn on the controller.



AFTER THE HARMONIC DRIVE IS REPLACED, AN ABSOLUTE RESET MUST BE PERFORMED, AND THE STANDARD COORDINATE AND POINT DATA MUST BE RESET. REFER TO "CHAPTER 4 ADJUSTMENT" TO ADJUST IT.

3. R-axis

- 1) Prepare the following tools and items.
 - Harmonic grease 4B No.2
 - Waste cloth (rag)
 - Phillips-head screwdriver
 - Hex wrench set
 - Screw Lock (thread sealant)
 - Torque-limiting wrench
 - Hook wrench
 - Replacement parts (See table below.)

Replacement parts			
Parts name	Type No .	OMRON Parts No.	Note
Harmonic drive	SHF-17-50	KN4-M1821-000	
O-ring	Rubber wire diameter 1.78mm x Ring inner diameter 63.22mm	KN4-M1896-000	Lower part of harmonic drive Upper part of bellows (2 pieces)
	Rubber wire diameter 0.80mm x Ring inner diameter 45.40mm	KN3-M257L-000	Supplied with harmonic drive
Edge seal	VR22A	KN4-M1886-000	

- Turn off the controller.
- 3) Place a sign indicating that the robot is being inspected, to keep others from operating the controller switch.
- 4) Enter the safeguard enclosure.
- 5) Remove the Y-axis upper cover and bellows. Place the cover on the robot base (pedestal) side with the machine harness still connected. Refer to "7 Removing the Robot Covers" in Chapter 4 for removing and reattaching the covers. Refer to "6 Replacing the bellows" in Chapter 5 for removing and reattaching the bellows.



THE Z-AXIS WILL SLIDE DOWN WHEN THE SPLINE MOUNTING BOLTS (M5×16L, 4 PIECES) ARE REMOVED IN THE NEXT STEP, CAUSING A HAZARDOUS SITUATION. PROP THE Z-AXIS WITH A SUPPORT STAND BEFORE LOOSENING THESE BOLTS.

6) Remove the bolts (M5×16L, 4 pieces) securing the bearing to the upper end of the spline and remove the spline and bearing from the holder. (See Fig. 5-28.)




Fig. 5-28

7) While placing a steel rod or similar tool through the 7mm diameter hole at the lower part of the spline, loosen the U-nut at the top of the spline with the wrench, and remove the bearing and bearing mount plate. (See Fig. 5-29.)

Use a round steel rod with a diameter slightly smaller than 7mm. Avoid using a square rod because the spline might be damaged by the edge of the rod.

At this point, be careful to keep the spline shaft from coming off the spline nut.




Fig. 5-29

8) Remove the bolts (M3×25L, 8 pieces) on the underside of the Y-axis arm and remove the plate fastening the spline and the harmonic drive. (See Fig. 5-30.)




Fig. 5-30

AN O-RING IS FITTED TO THE FASTENING PLATE, SO BE CAREFUL NOT TO LET IT DROP INTO THE PERIPHERAL UNIT. (SEE FIG. 5-31.)





Fig. 5-31

- 9) Remove the bolts (M4×10L, 4 pieces) securing the R-axis motor plate at the top of the Y-axis arm. (See Fig. 5-32.)
- 10) Loosen the pulley set screw (M4, 2 pieces) and remove the pulley from the wave generator. (See Fig. 5-32.)
- 11) Remove the harmonic drive installation bolts (M3×16L, 9 pieces) and pull out the harmonic drive from the bottom of the Y-axis arm. (See Fig. 5-32.)




CAUTION

AN O-RING IS FITTED TO THE FASTENING PLATE, SO BE CAREFUL NOT TO LET IT DROP INTO THE PERIPHERAL UNIT.

12) Remove the retaining ring for the wave generator and pull out the wave generator from the bottom of the Y-axis arm.

13) Apply harmonic grease to the new wave generator. See Fig. 5-33 for applying grease properly.



- Fig. 5-33
- 14) Insert the new wave generator into the Y-axis arm from the bottom, and secure it with the retaining ring. The chamfered side of the retaining ring should face downwards
- 15) Apply harmonic grease to the circular spline. See Fig. 5-33 for applying grease properly.
- 16) Remove the four bolts temporarily tightened to the new harmonic drive.



CAUTION

REMOVE ONLY THE FOUR BOLTS SHOWN IN FIG. 5-33 AT THIS POINT. NEVER REMOVE THE BOLTS ON THE OPPOSITE SIDE. IF THEY ARE REMOVED, THE HARMONIC DRIVE AXIS MAY DEVIATE FROM THE CENTER CAUSING A TROUBLE.

17) Fit an O-ring (supplied with the harmonic drive) coated with harmonic grease into the O-ring groove on the new harmonic drive. (See Fig. 5-33.) Apply small amounts of "Screw Lock" to the bolts (M3×16L, 9 pieces) and tighten them to secure the harmonic drive to the Y-axis arm from the top of the Y-axis arm. (See Fig. 5-32.)



CAUTION

DO NOT ALLOW THE O-RING TO GET CAUGHT OUT OF THE GROOVE DURING REASSEMBLY. A TROUBLE WILL OCCUR IF THE ROBOT IS OPERATED WITH THE O-RING LEFT CAUGHT OUT OF THE GROOVE. WHEN REASSEMBLING THE HARMONIC DRIVE, BE CAREFUL TO KEEP THE CIRCULAR SPLINE FROM COMING OFF. IF IT COMES OFF, THE HARMONIC DRIVE AXIS WILL DEVIATE FROM THE CENTER CAUSING A TROUBLE.

- 18) Apply small amounts of "Screw Lock" to the M4 set screws (2 pieces) and tighten them to secure the pulley to the wave generator. (See Fig. 5-32.)
- 19) Fit the timing belt onto the wave generator pulley and motor pulley, and then secure the motor plate. (See Fig. 5-32.)



CAUTION

IT IS NECESSARY TO APPLY CORRECT TENSION TO THE TIMING BELT DURING REASSEMBLY, REFER TO "8 ADJUSTING THE TIMING BELT TENSION" IN CHAPTER 4.

20) Fit a new O-ring into the O-ring groove on the fastening plate and also replace the edge seal with new one. Then secure the fastening plate to the harmonic drive with the bolts (M3×25L, 8 pieces) you removed earlier. (See Fig. 5-30 and Fig. 5-34.)


At this point, be careful to keep the spline shaft from coming off the spline nut.



CAUTION

THE HARMONIC DRIVE SERVICE LIFE MAY SHORTEN IF THE EDGE SEAL EFFECT IS INSUFFICIENT, SO CAREFULLY REASSEMBLE THE PARTS.

- 21) Insert the bearing mount plate and bearing onto the spline from the top, and tighten the U-nut to secure the baring. (Utilize the φ7 through-hole when tightening the U-nut like you did to loosen it.) (See Fig. 5-29.)
- 22) Insert the spline and bearing through the holder and secure them with the bolts you removed earlier (M5×16L, 4 pieces). (See Fig. 5-28.)
- 23) Reattach the Y-axis arm upper cover.
- 24) Go outside the safeguard enclosure.
- 25) Check that no one is inside the safeguard enclosure, and then turn on the controller.



5-2-3 R6YXC700, R6YXC800, R6YXC1000

The following steps describe procedures and precautions when replacing the harmonic drives of the R6YXC700, R6YXC800 and R6YXC1000. For the bolt tightening torques in this work, refer to Table 5-2.

1. X-axis

- 1) Prepare the following tools and items.
 - Harmonic grease 4B No.2
 - Waste cloth (rag)
 - Phillips-head screwdriver
 - Hex wrench set
 - Screw Lock (thread sealant)
 - · Ratchet handle
 - Hexagonal socket set
 - Extension bar
 - Torque-limiting wrench
 - Replacement parts (See table below.)

Replacement parts			
Parts name	Type No .	OMRON Parts No.	Note
Harmonic drive	SHF-32-80	KN5-M2110-001	R6YXC700, R6YXC800
	SHF-32-100	KN5-M2110-101	R6YXC1000
O-ring	S115(JIS)	KN5-M2159-000	Top of harmonic drive
	Rubber wire diameter 1.78mm x Ring inner diameter 78.97mm	KN5-M2144-000	Base (robot pedestal)
	Rubber wire diameter 1.78mm x Ring inner diameter 69.57mm	KN5-M2143-000	Motor
	Rubber wire diameter 1.50mm x Ring inner diameter 87.50mm	KN5-M2199-000	Supplied with harmonic drive

- 2) Turn off the controller.
- 3) Place a sign indicating that the robot is being inspected, to keep others from operating the controller switch.
- 4) Enter the safeguard enclosure.
- 5) Remove the base (robot pedestal) front and rear covers and the X-axis arm upper cover.
 - Refer to "7 Removing the Robot Covers" in Chapter 4 for removing the covers.
- 6) Disconnect the connectors on the X-axis motor power cable XM and resolver cable XP.

7) Remove the bolts (M6×20L, 4 pieces) securing the motor by using the ratchet handle, M6 hexagonal socket, socket adapter and extension bar. (See Fig. 5-35.)




Fig. 5-35

8) Slowly pull out the motor while holding it slantways. (See Fig. 5-36.) If it is difficult to remove the motor, slowly rotate the X-axis arm and again try removing the motor.

A CAUTION

CAREFULLY REMOVE THE MOTOR SO AS NOT TO LET HANDS OR FINGERS GET PINCHED BETWEEN THE MOTOR AND THE BASE. AN O-RING IS FITTED TO THE MOTOR AND THE SPACER, SO BE CAREFUL NOT TO LET IT DROP INTO THE PERIPHERAL UNIT.




Fig. 5-36

9) Remove the wave generator from the motor shaft. The wave generator is secured with an M4 set screw and keyway. (See Fig. 5-40.)

WARNING

WHEN YOU REMOVE THE X-AXIS ARM INSTALLATION BOLTS (M5×55L, 8 PIECES) IN THE NEXT STEP, THE X-AXIS ARM MAY COME OFF CAUSING A HAZARDOUS SITUATION. BE ESPECIALLY CAREFUL TO KEEP THE ARM FROM FALLING WHEN A HEAVY TOOL IS ATTACHED TO THE ARM TIP.



WARNING

REMOVING THE X-AXIS ARM IS DANGEROUS FOR JUST ONE PERSON. ALWAYS USE TWO OR MORE PEOPLE, OR REMOVE THE Y-AXIS ARM IN ADVANCE.

REFER TO "2. Y-AXIS" OF "5-2-3" FOR REMOVING THE Y-AXIS ARM.

10) Remove the X-axis arm installation bolts (M5×55L, 8 pieces). (See Fig. 5-37.)




Fig. 5-37

11) Remove the X-axis arm and place it where it will not obstruct the work.

AN O-RING IS FITTED TO THE X-AXIS ARM, SO BE CAREFUL NOT TO LET IT DROP INTO THE PERIPHERAL UNIT. (SEE FIG. 5-38.)





Fig. 5-38

12) Remove the bolts (M5×25L 8 pieces and M5×35L 8 pieces) securing the X-axis harmonic drive. (See Fig. 5-39.)



13) Remove the X-axis harmonic drive from the top of the base.

CAUTION

AN O-RING IS FITTED TO THE X-AXIS HARMONIC DRIVE, SO BE CAREFUL NOT TO LET IT DROP INTO THE BASE OR PERIPHERAL UNIT. 14) Fit an O-ring (supplied with the harmonic drive) coated with harmonic grease into the O-ring groove on the new harmonic drive. (See Fig. 5-40.) Apply small amounts of "Screw Lock" to the bolts (M5×25L 8 pieces and M5×35L 8 pieces) and tighten them to secure the harmonic drive from the backside of the base. (See Fig. 5-39.)

CAUTION

DO NOT ALLOW THE O-RING TO GET CAUGHT OUT OF THE GROOVE DURING REASSEMBLY. A TROUBLE WILL OCCUR IF THE ROBOT IS OPERATED WITH THE O-RING LEFT CAUGHT OUT OF THE GROOVE.

- 15) Apply harmonic grease to the new wave generator and flexible spline. See Fig. 5-40 for applying grease properly.
- 16) Fit a new O-ring into the O-ring groove on the X-axis arm and secure it to the harmonic drive. Then apply small amounts of "Screw Lock" to the bolts (M5×55L, 8 pieces) you removed earlier and tighten them uniformly to secure the X-axis arm. (See Fig. 5-37 and Fig. 5-38.)



CAUTION

DO NOT ALLOW THE O-RING TO GET CAUGHT OUT OF THE GROOVE DURING REASSEMBLY. A TROUBLE WILL OCCUR IF THE ROBOT IS OPERATED WITH THE O-RING LEFT CAUGHT OUT OF THE GROOVE.

17) Fit the wave generator onto the motor shaft, and fully insert it against the motor. Then, apply small amounts of "Screw Lock" to the M4 set screw (1 piece) you removed earlier and tighten it to secure the wave generator onto the motor shaft. (See Fig. 5-40.)




Fig. 5-40

18) Fit a new O-ring to the motor and temporarily fasten the motor and spacer to the base with the bolts (M6×20L, 4 pieces) you removed earlier. Insert a new O-ring between the spacer and the base at this point. Insert the motor with the wave generator into the harmonic drive while holding the motor slantways. If it is difficult to insert the motor, try inserting it again while slowly rotating the X-axis arm. (See Fig. 5-36.)



CAUTION

DO NOT ALLOW THE O-RING TO GET CAUGHT OUT OF THE GROOVE DURING REASSEMBLY. A TROUBLE WILL OCCUR IF THE ROBOT IS OPERATED WITH THE O-RING LEFT CAUGHT OUT OF THE GROOVE.

- 19) Uniformly tighten the four bolts (M6×20L) temporarily fastened in the previous step while moving the X-axis by hand slowly left and right through 45°. If any jamming or catching is felt while moving the axis at this time, then reassemble from the beginning.
- 20) Reattach the connectors on the X-axis motor power cable XM and resolver cable XP

- 21) Reattach the base (robot pedestal) front and rear covers and the X-axis arm upper cover.
- 22) Go outside the safeguard enclosure.
- 23) Check that no one is inside the safeguard enclosure, and then turn on the controller.



AFTER THE HARMONIC DRIVE IS REPLACED, AN ABSOLUTE RESET MUST BE PERFORMED, AND THE STANDARD COORDINATE AND POINT DATA MUST BE RESET. REFER TO "CHAPTER 4 ADJUSTMENT" TO ADJUST IT.

2. Y-axis

- 1) Prepare the following tools and items.
 - Harmonic grease 4B No.2
 - Waste cloth (rag)
 - Phillips-head screwdriver
 - Hex wrench set
 - Screw Lock (thread sealant)
 - Torque-limiting wrench
 - Replacement parts (See table below.)

Replacement parts			
Parts name	Type No .	OMRON Parts No.	Note
Harmonic drive	SHF-25-80	KN4-M2110-001	
, ,	S90(JIS)	KN4-M2143-000	Lower part of harmonic drive
	Rubber wire diameter 1.78mm x Ring inner diameter 69.57mm	KN5-M2143-000	For motor
	Rubber wire diameter 1.30mm x Ring inner diameter 66.50mm	KN5-M257L-000	Supplied with harmonic drive

- 2) Turn off the controller.
- 3) Place a sign indicating that the robot is being inspected, to keep others from operating the controller switch.
- 4) Enter the safeguard enclosure.
- 5) Remove the Y-axis arm upper cover. Place the cover on the robot base (pedestal) side with the machine harness still connected.
 - Refer to "7 Removing the Robot Covers" in Chapter 4 for removing the covers.
- 6) Disconnect the connectors on the Y-axis motor power cable YM and resolver cable YP.
- 7) Remove the Y-axis motor installation bolts (M6×20L, 4 pieces) and then remove the Y-axis motor by swaying it gently right and left.(See Fig. 5-41.)




Fig. 5-41



ACAUTION

AN O-RING IS FITTED TO THE MOTOR, SO BE CAREFUL NOT TO LET IT DROP INTO THE PERIPHERAL UNIT.

8) Remove the wave generator from the motor shaft. The wave generator is secured with an M4 set screws. (See Fig. 5-45.)



CAUTION

WHEN YOU REMOVE THE Y-AXIS ARM INSTALLATION BOLTS (M4×20L, 16 PIECES) IN THE NEXT STEP, THE Y-AXIS ARM MAY COME OFF CAUSING A HAZARDOUS SITUATION. BE ESPECIALLY CAREFUL TO KEEP THE ARM FROM FALLING WHEN A HEAVY TOOL IS ATTACHED TO THE ARM TIP.

9) Remove the Y-axis arm installation bolts (M4×20L, 16 pieces). (See Fig. 5-42.)




Fig. 5-42


10) Remove the Y-axis arm and place it where it will not obstruct the work.



CAUTION

AN O-RING IS FITTED TO THE UPPER SURFACE OF THE HARMONIC DRIVE, SO BE CAREFUL NOT TO LET IT DROP INTO THE PERIPHERAL UNIT.

11) Remove the Y-axis harmonic drive installation bolts (M4×45L, 8 pieces). (See Fig. 5-43.)




12) Remove the Y-axis harmonic drive from the top of the X-axis arm.



CAUTION

AN O-RING IS FITTED TO THE UPPER SURFACE OF THE X-AXIS, SO BE CAREFUL NOT TO LET IT DROP INTO THE PERIPHERAL UNIT. (SEE FIG. 5-44.)



- 13) Fit a new O-ring coated with harmonic grease into the O-ring groove on the X-axis arm. (See Fig. 5-44.)
- 14) Place the new harmonic drive on the X-axis arm, and secure it with the bolts (M4×45L, 8 pieces) you removed earlier. Apply small amounts of "Screw Lock" to the bolts and tighten them uniformly to secure the harmonic drive from the backside. (See Fig. 5-43.)



DO NOT ALLOW THE O-RING TO GET CAUGHT OUT OF THE GROOVE DURING REASSEMBLY. A TROUBLE WILL OCCUR IF THE ROBOT IS OPERATED WITH THE O-RING LEFT CAUGHT OUT OF THE GROOVE.

- 15) Fit an O-ring (supplied with the harmonic drive) coated with harmonic grease into the O-ring groove on the new harmonic drive. (See Fig. 5-45.)
- 16) Secure the Y-axis arm to the harmonic drive with the bolts (M4×20L, 16 pieces) you removed earlier. Apply small amounts of "Screw Lock" to the bolts and tighten them uniformly to secure the Y-axis arm. (See Fig. 5-42.)

CAUTION

DO NOT ALLOW THE O-RING TO GET CAUGHT OUT OF THE GROOVE DURING REASSEMBLY. A TROUBLE WILL OCCUR IF THE ROBOT IS OPERATED WITH THE O-RING LEFT CAUGHT OUT OF THE GROOVE.

- 17) Apply harmonic grease to the new wave generator and flexible spline. See Fig. 5-45 for applying grease properly.
- 18) Fit the wave generator onto the motor shaft, and fully insert it against the motor. Then, apply small amounts of "Screw Lock" to the M4 set screw (1 piece) you removed earlier and tighten it to secure the wave generator. (See Fig. 5-45.)




Fig. 5-45

19) Fit a new O-ring to the motor and tighten the bolts (M6×20L, 4 pieces) you removed earlier to temporarily secure the motor to the Y-axis arm. (See Fig. 5-41.)Insert a new O-ring between the spacer and the Y-axis arm at this point.

CAUTION

DO NOT ALLOW THE O-RING TO GET CAUGHT OUT OF THE GROOVE DURING REASSEMBLY. A TROUBLE WILL OCCUR IF THE ROBOT IS OPERATED WITH THE O-RING LEFT CAUGHT OUT OF THE GROOVE.

- 20) Uniformly tighten the four bolts (M6×20L) temporarily fastened in the previous step while moving the Y-axis by hand slowly left and right through 45°. If any jamming or catching is felt while moving the axis at this time, then reassemble from the beginning.
- 21) Reattach the connectors on the Y-axis motor power cable YM and resolver cable YP.
- 22) Reattach the Y-axis arm upper cover.
- 23) Go outside the safeguard enclosure.
- 24) Check that no one is inside the safeguard enclosure, and then turn on the controller.

CAUTION

AFTER THE HARMONIC DRIVE IS REPLACED, AN ABSOLUTE RESET MUST BE PERFORMED, AND THE STANDARD COORDINATE AND POINT DATA MUST BE RESET. REFER TO "CHAPTER 4 ADJUSTMENT" TO ADJUST IT.

3. R-axis

- 1) Prepare the following tools and items.
 - Harmonic grease 4B No.2
 - Waste cloth (rag)
 - Phillips-head screwdriver
 - Hex wrench set
 - Screw Lock (thread sealant)
 - Torque-limiting wrench
 - Hook wrench
 - Replacement parts (See table below.)

	Replacement parts									
Parts name	Type No .	OMRON Parts No.	Note							
Harmonic drive	SHF-20-50	KN5-M1821-001								
	S63(JIS)	KN9-M1895-200	Upper part of bellows (2 pieces)							
O-ring	S71(JIS)	KN3-M2159-000	Lower part of harmonic drive							
	Rubber wire diameter 0.99mm x Ring inner diameter 53.28mm	KN3-M2144-000	Supplied with harmonic drive							
Edge seal	VR28A	KN5-M1886-000								

- 2) Turn off the controller.
- 3) Place a sign indicating that the robot is being inspected, to keep others from operating the controller switch.
- 4) Enter the safeguard enclosure.
- 5) Remove the Y-axis upper cover and bellows. Place the cover on the robot base (pedestal) side with the machine harness still connected. Refer to "7 Removing the Robot Covers" in Chapter 4 for removing and reattaching the covers. Refer to "6 Replacing the bellows" in Chapter 5 for removing and reattaching the bellows.



WARNING

THE Z-AXIS WILL SLIDE DOWN WHEN THE SPLINE MOUNTING BOLTS (M5×16L, 4 PIECES) ARE REMOVED IN THE NEXT STEP, CAUSING A HAZARDOUS SITUATION. PROP THE Z-AXIS WITH A SUPPORT STAND BEFORE LOOSENING THESE BOLTS.

6) Remove the bolts (M5×16L, 4 pieces) securing the bearing to the upper end of the spline and remove the spline and bearing from the holder. (See Fig. 5-46.)




Fig. 5-46

7) While placing a steel rod or similar tool through the 8mm diameter hole at the lower part of the spline, loosen the U-nut at the top of the spline with the hook wrench, and remove the bearing and bearing mount plate. (See Fig. 5-47.)

Use a round steel rod with a diameter slightly smaller than 8mm. Avoid using a square rod because the spline might be damaged by the edge of the rod.

At this time, be careful to keep the spline shaft from coming off the spline nut.




Fig. 5-47

8) Remove the bolts (M3×30L, 8 pieces) on the underside of the Y-axis arm and remove the plate fastening the spline and the harmonic drive. (See Fig. 5-48)




Fig. 5-48



AN O-RING IS FITTED TO THE FASTENING PLATE, SO BE CAREFUL NOT TO LET IT DROP INTO THE PERIPHERAL UNIT. (SEE FIG. 5-49.)




Fig. 5-49

- 9) Remove the bolts (M4×15L, 4 pieces) securing the R-axis motor plate at the top of the Y-axis arm. (See Fig. 5-50.)
- 10) Loosen the pulley set screw (M4, 2 pieces) and remove the pulley from the wave generator. (See Fig. 5-50.)
- 11) Remove the harmonic drive installation bolts (M3×30L, 13 pieces) and pull out the harmonic drive from the bottom of the Y-axis arm. (See Fig. 5-50.)




Fig. 5-50



AN O-RING IS FITTED TO THE FASTENING PLATE, SO BE CAREFUL NOT TO LET IT DROP INTO THE PERIPHERAL UNIT.

12) Remove the retaining ring for the wave generator and pull out the wave generator from the bottom of the Y-axis arm.

13) Apply harmonic grease to the new wave generator. See Fig. 5-51 for applying grease properly.




Fig. 5-51

- 14) Insert the new wave generator into the Y-axis arm from the bottom, and secure it with the retaining ring. The chamfered side of the retaining ring should face downwards.
- 15) Apply harmonic grease to the circular spline. See Fig. 5-51 for applying grease properly.
- 16) Fit an O-ring (supplied with the harmonic drive) coated with harmonic grease into the O-ring groove on the new harmonic drive. (See Fig. 5-51.) Apply small amounts of "Screw Lock" to the bolts (M3×30L, 13 pieces) and tighten them to secure the harmonic drive to the Y-axis arm from the top of the Y-axis arm. (See Fig. 5-50.)



DO NOT ALLOW THE O-RING TO GET CAUGHT OUT OF THE GROOVE DURING REASSEMBLY. A TROUBLE WILL OCCUR IF THE ROBOT IS OPERATED WITH THE O-RING LEFT CAUGHT OUT OF THE GROOVE.

- 17) Apply small amounts of "Screw Lock" to the M4 set screws (2 pieces) and tighten them to secure the pulley to the wave generator. (See Fig. 5-50.)
- 18) Fit the timing belt onto the wave generator pulley and motor pulley, and then secure the motor plate. (See Fig. 5-50.)



IT IS NECESSARY TO APPLY CORRECT TENSION TO THE TIMING BELT DURING REASSEMBLY. REFER TO "8 ADJUSTING THE TIMING BELT TENSION" IN CHAPTER 4.

19) Fit a new O-ring into the O-ring groove on the fastening plate and also replace the edge seal with new one. Then secure the fastening plate to the harmonic drive with the bolts (M3×30L, 8 pieces) you removed earlier. (See Fig. 5-48 and Fig. 5-52.)

At this point, be careful to keep the spline shaft from coming off the spline nut.



THE HARMONIC DRIVE SERVICE LIFE MAY SHORTEN IF THE EDGE SEAL EFFECT IS INSUFFICIENT, SO CAREFULLY REASSEMBLE THE PARTS.




Fig. 5-52

- 20) Insert the bearing mount plate and bearing onto the spline from the top, and tighten the U-nut to secure the baring. (Utilize the φ8 through-hole when tightening the U-nut like you did to loosen it.) (See Fig. 5-47.)
- 21) Insert the spline and bearing through the holder and secure them with the bolts you removed earlier (M5×16L, 4 pieces). (See Fig. 5-46.)
- 22) Reattach the Y-axis arm upper cover.
- 23) Go outside the safeguard enclosure.
- 24) Check that no one is inside the safeguard enclosure, and then turn on the controller.



AFTER THE HARMONIC DRIVE IS REPLACED, THE ABSOLUTE RESET MUST BE PERFORMED, AND THE POINT DATA MUST BE RESET. REFER TO "CHAPTER 4 ADJUSTMENT" TO ADJUST IT.

6 Replacing the bellows

The XC series robots use bellows to prevent dust generation from the spline shaft. If the bellows are broken, replace them as explained below. For bolt tightening torque in this work, see Table 5-2. Perform the replacement work while referring to Table 5-3 and Fig. 5-53.

WARNING

THE MOTOR AND SPEED REDUCTION GEAR CASING ARE EXTREMELY HOT AFTER AUTOMATIC OPERATION, SO BURNS MAY OCCUR IF THESE ARE TOUCHED. BEFORE TOUCHING THESE PARTS, TURN OFF THE CONTROLLER, WAIT FOR A WHILE AND CHECK THAT THE TEMPERATURE HAS FELL DOWN SUFFICIENTLY.

- 1) Prepare the following tools and items.
 - · Hex wrench set
 - Phillips-head screwdriver
- 2) Turn off the controller.
- 3) Place a sign indicating that the robot is being inspected, to keep others from operating the controller switch.
- Enter the safeguard enclosure.
- Remove the end effector.
- 6) Loosen set screws 3, 9, 15 located on the bellows bottom clamp plate. (There are two pieces each.)
- 7) Remove the screws and bolts 1, 7, 13 on the bellows top clamp plate.
- 8) Pull out the bellows bottom clamp plates from the spline shaft.



CAUTION

O-RINGS 4, 10, 16 ARE FITTED TO THE TOP OF THE BELLOWS, SO BE CAREFUL NOT TO DROP THEM INTO PERIPHERAL UNITS.



CAUTION

O-RINGS 5, 11, 17 ARE FITTED TO THE BOTTOM OF THE BELLOWS, SO BE CAREFUL NOT TO DROP THEM INTO PERIPHERAL UNITS.

- 9) Replace O-rings 6, 12, 18 fitted to the spline shaft with new ones.
- 10) Fit new O-rings 5, 11, 17 to one of the bellows bottom clamp plates, insert the bellows end between the two clamp plates, and tighten bolts 2, 8, 14 to fasten them.

USE CAUTION NOT TO LET O-RINGS TO PROTRUDE FROM THEIR GROOVES AND BE PINCHED. IF THE ROBOT IS OPERATED WHILE AN O-RING IS STILL PINCHED, THE CLEANLINESS DEGREE MAY DEGRADE.

- 11) Attach the clamp plate to the top of the bellows.
- 12) Fit O-rings 4, 10, 16 into the O-ring grooves on the robot body.
- 13) Attach the bellows to the spline shaft. A little bit large force is required due to O-rings, but fully insert the bellows all the way into the position. (Refer to Fig, 5-53 for installation height.)
- 14) Tighten bolts 1, 7, 13 to secure the bellows top clamp plate.



USE CAUTION NOT TO LET O-RINGS TO PROTRUDE FROM THEIR GROOVES AND BE PINCHED. IF THE ROBOT IS OPERATED WHILE AN O-RING IS STILL PINCHED, THE CLEANLINESS DEGREE MAY DEGRADE.

- 15) Rotate the bellows bottom clamp plates to correct a twist in the bellows.
- 16) Tighten set screws 3, 9, 15 on the bellows bottom clamp plate. (There are 2 pieces each.)
- 17) Reattach the end effector.
- 18) Go outside the safeguard enclosure.
- 19) Check that no one is inside the safeguard enclosure, and then turn on the controller.

Table 5-3 (See also Fig. 5-53.)

Robot model	Part name	No.	Size/spec	Q'ty
R6YXCH250	Hex socket head bolt	1	M3x12	8
R6YXCH350	Hex socket head bolt	2	M3x12	8
R6YXCH400	Set screw	3	M4x6	2
	O-ring	4	S53	1
	O-ring	5	\$50	1
	O-ring	6	S14	1
R6YXC500	Hex socket head bolt	7	M3x10	12
R6YXC600	Hex socket head bolt	8	M3x10	8
	Set screw	9	M4x6	2
	O-ring	10	S63	1
	O-ring	11	S50	1
	O-ring	12	S16	1
R6YXC700	Hex socket head bolt	13	M3x8	12
R6YXC800	Hex socket head bolt	14	M3x10	8
R6YXC1000	Set screw	15	M4x6	2
	O-ring	16	S63	1
	O-ring	17	S50	1
	O-ring	18	P18	1




Fig. 5-53

Specifications

1	Man	ıpulator	6-1
		Basic specification	
	1-2	Robot inner wiring diagram	6-4
	1-3	Wiring table	6-6

1 Manipulator

1-1 Basic specification

D	obot mo	dal	DCVVCUSEO	R6YXCH350	DC)///CLI400		
, n	1000		R6YXCH250	R6YXCH400			
	X-axis	Arm length	125mm	225mm	225mm		
Axis		Rotation angle	±115°	±115°	±115°		
specifi-	Y-axis	Arm length	125mm	125mm	175mm		
cations	I-axis	Rotation angle	±130°	±128°	±143°		
Cations	Z-axis	Stroke	150mm	150mm	150mm		
	R-axis	Rotation angle	±180°	±180°	±180°		
		X-axis	200W	200W	200W		
Motor		Y-axis	100W	100W	100W		
Motor		Z-axis	100W	100W	100W		
		R-axis	100W	100W	100W		
		XYresultant	4.0m/s	5.0m/s	6.0m/s		
Maximum	Maximum speed		1.0m/s	1.0m/s	1.0m/s		
		R-axis	1020°/s 1020°/s		1020°/s		
		XY-axes	±0.01mm	±0.01mm	±0.01mm		
Repeatabi	lity *1	Z-axis	±0.01mm	±0.01mm	±0.01mm		
		R-axis	±0.005°	±0.005°	±0.005°		
Payload			3kg	3kg	3kg		
R-axis tolerak	ole momen	t of inertia *2	0.05	5kgm²(0.5kgfcm	ns²)		
User wirin	g		10 cables	10 cables	10 cables		
User tubin	g (Outer	diameter)	4x3	4x3	4x3		
Travel limi	t		1.Soft limit 2.Mechanical limit (XYZ-axes)				
Robot cab	le		3.5m	(option: 5m, 10	Om)		
Weight			16kg	16kg	16kg		
Cleanlines	s class		Class 10 (0.1 micron base, during air suction)				
Suction air	r flow		60 NI/min				
*1 At constant ambient temperature (VV)							

^{*1} At constant ambient temperature (XY)

^{*2} There are limits to acceleration coefficient settings.

ſ	Robot mo	del	R6YXC500	R6YXC600	
X-axis		Arm length	250mm	350mm	
Auto	A-axis	Rotation angle	±120°	±120°	
Axis	Y-axis	Arm length	250mm	250mm	
specifi- cations	1-axis	Rotation angle	±142°	±145°	
Cations	Z-axis	Stroke	200, 300mm	200, 300mm	
	R-axis	Rotation angle	±180°	±180°	
		X-axis	400W	400W	
Motor		Y-axis	200W	200W	
Motor		Z-axis	200W	200W	
		R-axis	100W	100W	
		XYresultant	4.9m/s	5.6m/s	
axaxspeed		Z-axis	1.7m/s	1.7m/s	
		R-axis	876°/s	876°/s	
		XY-axes	±0.02mm	±0.02mm	
Repeatab	ility *1	Z-axis	±0.01mm	±0.01mm	
		R-axis	±0.005°	±0.005°	
Payload			10kg	10kg	
R-axis tolera	ble momen	t of inertia *2	0.12kgm² (1.2kgfcms²)	
User wirir	ng		20 cables	20 cables	
User tubir	ng (Outer	diameter)	6x3	6x3	
Travel lim	it		1.Soft limit 2.Mechanical limit (XYZ-axes)		
Robot cal	ole		3.5m (option	n: 5m, 10m)	
Weight			31kg	33kg	
Cleanline	ss class		Class 10 (0.1 micron ba	ase, during air suction)	
Suction a	ir flow		60 NI/min		

^{*1} At constant ambient temperature (XY)

^{*2} There are limits to acceleration coefficient settings.

Robot Model			R6YXC700	R6YXC800	R6YXC1000	
	Varia	Arm length	350mm	450mm	550mm	
	X-axis	Rotation angle	±120°	±120°	±120°	
Axis	Vavia	Arm length	350mm	350mm	450mm	
specifi-	Y-axis	Rotation angle	±145°	±145°	±145°	
cations	Z-axis	Stroke	200, 400mm	200, 400mm	200, 400mm	
	R-axis	Rotation angle	±180°	±180°	±180°	
		X-axis	800W	800W	800W	
M-4		Y-axis	400W	400W	400W	
Motor		Z-axis	400W	400W	400W	
		R-axis	200W	200W	200W	
		XY resultant	6.7m/s	7.3m/s	8.0m/s	
Maximum speed		Z-axis	1.7m/s	1.7m/s	1.7m/s	
		R-axis	600°/s	600°/s	600°/s	
Repeatab	ility *1	X,Y-axes	±0.02mm ±0.02mm		±0.02mm	
		Z-axis	±0.01mm	±0.01mm	±0.01mm	
		R-axis	±0.005°	±0.005°	±0.005°	
Payload			20kg	20kg	20kg	
R-axis tolera	ble mome	nt of inertia *2	0.3	32kgm²(3.2kgfcm	ns²)	
User wirir	ng		20 cables	20 cables	20 cables	
User tubir	ng (Oute	er diameter)	6x3	6x3	6x3	
Travel lim	it		1.Soft limit 2.N	lechanical limit (XYZ-axes)	
Robot cable			3.5	m,option:5m,10n	n	
Weight			57kg	58kg	59kg	
Cleanliness class Class 10 (0.1 micron base, during air suct					ng air suction)	
Suction a	ir flow		60 NI/min			

^{*1} At constant ambient temperature (XY)

Sound level

Robot model	Maximum sound pressure level of robot (lat 10dB or more difference from background sound pressure level)	Position of maximum sound pressure level		
R6YXCH250, R6YXCH350, R6YXCH400	69.8dB	1.0m away from the rear of robot, 1.6m height		
R6YXC500, R6YXC600	69.7dB	1.0m away from the rear of robot, 1.6m height		
R6YXC700, R6YXC800, R6YXC1000	69.4dB	1.0m away from the rear of robot, 1.6m height		

Note: Sound level may increase when sound reflecting objects are located near the robot

^{★2} There are limits to acceleration coefficient settings.

1-2 Robot inner wiring diagram




Fig. 6-1 YK250XC(H), YK350XC(H), YK400XC(H)




Fig. 6-2 YK500XC, YK600XC, YK700XC, YK800XC, YK1000XC

1-3 Wiring table

Robot cable wiring table

Signal	Connector	No	Connection	No	Connector	Color	Wire
Resolver S2		1	√ ₩\	1		Blue	0.15sq
S4		2	<u> </u>	2		Orange	Twisted pair
S1	VD	3	- 	3		Green	0.15sq
S3	XP	4	<u> </u>	4		Brown	Twisted pair
R1		5	<u> </u>	5		Gray	0.15sq
R2		6		6		Red	Twisted pair
DG		7	+ +	7		Green	0.3sq
Resolver S2		1	─	19		Black	0.15sq
S4	YP	2	 ₩-	20		Yellow	Twisted pair
S1		3	<u> </u>	21	XY	Pink	0.15sq
S3		4	──┼ᠰ ┼	22	^1	Purple	Twisted pair
R1		5	<u> </u>	23		White	0.15sq
R2		6		24		Blue/Red	Twisted pair
DG		7	+ +	25		Green	0.3sq
FG	FG	1	→ ₩	18		Orange/White	0.15sq
			<u> </u>	36		Green/White	0.15sq
HLIM				10		Green	0.3sq
GND24				11			
HLIM				28		Green	0.3sq
GND24				29			
Origin Sensor GND		3	<u> </u>	13		Yellow/Black	0.15sq
ORG	XORG	2		12		Pink/Black	Twisted pair
24V		1	- 	9		Purple/White	0.15sq
Origin Sensor 24V		1		27		White/Blue	Twisted pair
ORG	YORG	2	- 	30		Blue/Red2	0.15sq
GND		3		31		Orange/White2	Twisted pair
U	XM	1		2	XM	Black	0.75sq
V	XIVI	2		3	/ //vi	Red	0.75sq
W		3		4		White	0.75sq
FG	Round terminal			1		Yellow/Green	0.75sq
U	YM	1		2	YM	Yellow	0.75sq
V		2		3		Brown	0.75sq
W		3		4		Blue	0.75sq

Signal	Connector	No	Connection	No	Connector	Color	Wire
Resolver S2		1	₩	1		Blue	0.15sq
S4		2	<u> </u>	2		Orange	Twisted pair
S1	ZP	3	- 	3		Green	0.15sq
S3	ZP	4	- 	4		Brown	Twisted pair
R1		5	<u></u> ₩ ;	5		Gray	0.15sq
R2		6	├ ─┼	- 6		Red	Twisted pair
DG		7	+	7		Green	0.3sq
Brake MB+	ZBK	1	1 W !	14		Black	0.15sq
MB-	ZDIX	2	→ ;	16		Yellow	Twisted pair
				15	ZR	Pink	0.15sq
			 	17	Zn	Purple	Twisted pair
Resolver S2		1	<u> </u>	19		White	0.15sq
S4	RP	2	<u> </u>	20		Blue/Red	Twisted pair
S1		3	<u> </u>	21		Orange/White	0.15sq
S3		4	<u> </u>	22		Green/White	Twisted pair
R1		5	XX :	23		Brown/White	0.15sq
R2		6		24		Gray/White	Twisted pair
DG		7	+	25		Green	0.3sq
FG	FG	1	1	18		Red/White	0.15sq
			<u> </u>	36		Black/White	0.15sq
			i i I I				
HLIM				10		Green	0.3sq
GND24				11			
HLIM				28		Green	0.3sq
GND24				29			
Origin Sensor 24V		1	1 1	27		White/Blue	0.15sq
ORG	RORG	2	<u> </u>	30		Blue/Red2	0.15sq
GND		3	\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\	31		Orange/White2	Twisted pair
U	ZM	1		2	ZM	Black	0.75sq
V	ZIVI	2		3	ZIVI	Red	0.75sq
W		3		4		White	0.75sq
FG	Round terminal			1		Yellow/Green	0.75sq
U	RM	1		2	RM	Yellow	0.75sq
V		2		3		Brown	0.75sq
W		3		4		Blue	0.75sq

Machine harness wiring table YK250XC(H), YK350XC(H), YK400XC(H)

Y-axis arm					ı	Base sid	
Signal	Connector	-	Connection	_	Connector	Color	Wire
Y-axis Resolver	52	1		1		Brown	0.2mm ²
	34	2		2		White	Twisted pair
Ş	51	3	- 	- 3		Red	0.2mm ²
9	3 YP	4	—÷₩÷—	4	YP	White	Twisted pair
F	R1	5		- 5		Orange	0.2mm ²
F	32	6	;W.;	6		White	Twisted pair
Г)G	7		7		Green	Shield
	52	1		1		Brown	0.2mm ²
	34	2		2		Black	Twisted pair
	1	3		3		Red	0.2mm ²
	3 ZP	4	XX	4	ZP	Black	Twisted pair
	11	5		5		Orange	0.2mm ²
	12	6	:_XX :	6	<u>. </u>	Black	Twisted pair
)G	7	<u> </u>	7		Green	Shield
	_	1		1			
	52	2	í XX ì	2	<u> </u>	Brown	0.2mm² Twisted pair
	54	-		-		Gray	
	51	3	<u> </u>	3		Red	0.2mm ²
	RP	4	v	4	RP	Gray	Twisted pair
	R1	5		5		Orange	0.2mm ²
	R2	6		6		Gray	Twisted pair
)G	7		7		Green	Shield
Y-axis motor	J	1		1		Brown	
,	√ YM	2		2	YM	Red	0.75mm ²
1	V	3		3		Orange	
Z-axis motor	J	1		1		Blue	
,	√ ZM	2		2	ZM	Purple	0.75mm ²
1	V	3		3		Gray	
R-axis motor	J	1		1		Black	
	V RM	2		2	RM	White	0.75mm ²
1	v	3		3		Red	0.7011111
Z-axis brake	1	1		1		Purple	
	ZBK	2		2	ZBK	Gray	0.3mm ²
Z-axis brake	_	F		F		aray	
		1	· · · ·	1		Brown	
		2	<u>í 1</u>	2	<u> </u>	Red	
		3	1 1	3		Orange	
		4	1 1	4			
		-	1 1	-	<u> </u>	Blue	0.2mm ²
User signal line	10	5	i i	5	10	Purple	
· ·		6	i ;	6		Gray	
		7		7		White	
		8		8		Brown	
		9		9		Red	
		10		10		Orange	
		11		11			0.2mm ²
		12		12			0.211111
		13		13			
		14		14			
Frame ground		15		15	1	Green	Shield
Frame ground			_	1	FG	Green	Shield
Origin Sensor 24\	/	1	1 1	1		White	
OF		2	<u> </u>	2	YORG	Purple	0.2mm ²
GN		3	<u> </u>	3	10110	Gray	U.ZIIIII
Origin Sensor 24\		1		1		White	
		2		2	POPG	Blue	0.02
OF		3	」	3	RORG		0.2mm ²
GN		٥		٥	Daynel to 1 1	Gray	0.756=
	Round terminal			\vdash		Yellow/Green	0.75sq
	Round terminal				Round terminal	Diue	0.75sq

Machine harness wiring table YK500XC, YK600XC, YK700XC, YK800XC, YK1000XC

Signal	Connector	No	Connection	No	Connector	Base s Color	Wire	
Y-axis Resolver S2	Connector	1	- A	1	Connector	Brown		
S4	-	2		2		White	0.2mm² Twisted pair	
S1	-	3		3		Red	0.2mm ²	
S3	YP	4	; XX ;	4	YP	White	Twisted pair	
R1	- YP	5		5	YP	Orange		
	-	6	! XX !	6		White	0.2mm ² Twisted pair	
R2	-	7		7		Green	-	
7-axis Resolver S2	-	1	.4	-		Brown	Shield	
E divide i reconver	-	\vdash	ſXX ì	1			0.2mm² Twisted pair	
S4	-	2	<u> </u>	2		Black	•	
S1	-	3		3		Red	0.2mm² Twisted pair	
S3	ZP	4	V	4	ZP	Black	•	
R1	-	5	- XX	5		Orange	0.2mm² Twisted pair	
R2	-	6		6		Black		
DG		7		7		Green	Shield	
R-axis Resolver S2	-	1	\mathcal{M}_{1}	1		Brown	0.2mm ²	
S4	_	2		2		Gray	Twisted pair	
S1		3	:W:	3		Red	0.2mm² Twisted pair	
S3	RP	4	 -	4	RP	Gray		
R1		5		5		Orange	0.2mm ²	
R2	_	6		- 6		Gray	Twisted pair	
DG		7	<u> </u>	7		Green	Shield	
Y-axis motor U		1		1		Brown		
V	T YM	2		2	YM	Red	0.75mm ²	
W	7 !	3		3		Orange		
Z-axis motor U		1		1		Blue		
V	ZM	2		2	ZM	Purple	0.75mm ²	
W	7	3		3		Gray	0.7 0.1.111	
R-axis motor U	+	1		1		Black		
V	RM	2		2	RM	White	0.75mm ²	
W		3		3	LIVI	Brown	0.7511111	
	+	1		1		White		
Z-axis brake 1	ZBK	2		2	ZBK	Black	0.3mm ²	
Z-axis brake 2	+	_				DIACK		
	-		,-,			D		
		1	í ì	1		Brown	0.2mm ²	
		2	!!!	2		Red		
		3	- i i	3		Orange		
		4	1 1	4		Blue		
		5	iii	5		Purple		
		6	1 1	6	IO	Gray		
		7	- i i	7		White		
		8		8		Black		
		9	- i i	9		Brown		
		10	1 1	10		Red		
		11		11		Orange		
User signal line	10	12		12		Blue		
Oser signal line	Ю	13	 	13		Brown		
						Red		
		-	 	14		neu		
		14 15	1 1	-		Orange		
		14	1 1 11	14				
		14 15	1 1	14 15 16		Orange Blue		
		14 15 16	1 1	14 15 16 17		Orange Blue Purple		
		14 15 16 17		14 15 16 17 18		Orange Blue Purple Gray	0.2mm²	
		14 15 16 17 18	1 1	14 15 16 17 18 19		Orange Blue Purple Gray White	0.2mm²	
		14 15 16 17 18 19		14 15 16 17 18 19 20		Orange Blue Purple Gray White Black	0.2mm²	
		14 · 15 · 16 · 17 · 18 · 19 · 20 · 21		14 15 16 17 18 19 20 21		Orange Blue Purple Gray White Black Brown	0.2mm²	
		14 · 15 · 16 · 17 · 18 · 20 · 21 22		14 15 16 17 18 19 20 21 22		Orange Blue Purple Gray White Black Brown Red	0.2mm²	
		14 · 15 · 16 · 17 · 18 · 19 · 20 · 21 · 22 · 23		14 15 16 17 18 19 20 21 22 23		Orange Blue Purple Gray White Black Brown Red Orange	0.2mm²	
	_	14 15 16 17 18 19 20 21 22 23 24		- 14 - 15 - 16 - 17 - 18 - 19 - 20 21 22 23 24		Orange Blue Purple Gray White Black Brown Red Orange Blue		
	_	14 · 15 · 16 · 17 · 18 · 19 · 20 · 21 · 22 · 23		14 15 16 17 18 19 20 21 22 23 24 25		Orange Blue Purple Gray White Black Brown Red Orange Blue Green	Shield	
Frame ground	-	14 · 15 · 16 · 17 · 18 · 19 · 20 · 21 · 22 · 23 · 24 · 25 · · 2		14 15 16 17 18 19 20 21 22 23 24 25	FG	Orange Blue Purple Gray White Black Brown Red Orange Blue Green Green		
	-	14 15 16 17 18 19 20 21 22 23 24 25 1		14 15 16 17 18 19 20 21 22 23 24 25 1		Orange Blue Purple Gray White Black Brown Red Orange Blue Green Green Brown	Shield Shield	
Frame ground Origin Sensor 24V ORG	YORG	14 · 15 · 16 · 17 · 18 · 19 · 20 · 21 · 22 · 23 · 24 · 25 · · 2		14 15 16 17 18 19 20 21 22 23 24 25 1	FG	Orange Blue Purple Gray White Black Brown Red Orange Blue Green Green Brown Red	Shield	
Frame ground Origin Sensor 24V	YORG	14 15 16 17 18 19 20 21 22 23 24 25 25 3 3		14 15 16 17 18 19 20 21 22 23 24 25 1 1		Orange Blue Purple Gray White Black Brown Red Orange Blue Green Green Brown Red Orange	Shield Shield	
Frame ground Origin Sensor 24V ORG GND	YORG	14 15 16 17 18 19 20 21 22 23 24 25 21 2 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1		14 15 16 17 18 19 20 21 22 23 24 25 1 1 1 2 2 3		Orange Blue Purple Gray White Black Brown Red Orange Blue Green Green Brown Red Orange Brown Red Orange Brown Red Orange	Shield Shield	
Frame ground Origin Sensor 24V ORG GND	YORG	14 · 15 · 16 · 17 · 18 · 19 · 20 · 21 · 22 · 23 · 24 · 25 · · 2 · 1 · 2 · 3 · 1 · 2 · 2		14 15 16 17 18 19 20 21 22 23 24 25 1 1 2 2 3 3 1 2 2 2 3		Orange Blue Purple Gray White Black Brown Red Orange Blue Green Green Brown Red Orange	Shield Shield	
Frame ground Origin Sensor 24V ORG GND Origin Sensor 24V		14 15 16 17 18 19 20 21 22 23 24 25 21 2 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1		14 15 16 17 18 19 20 21 22 23 24 25 1 1 1 2 2 3	YORG	Orange Blue Purple Gray White Black Brown Red Orange Blue Green Green Brown Red Orange Brown Red Orange Brown Red Orange	Shield Shield 0.2mm²	
Frame ground Origin Sensor 24V ORG GND Origin Sensor 24V ORG		14 · 15 · 16 · 17 · 18 · 19 · 20 · 21 · 22 · 23 · 24 · 25 · · 2 · 1 · 2 · 3 · 1 · 2 · 2		14 15 16 17 18 19 20 21 22 23 24 25 1 1 2 2 3 3 1 2 2 2 3	YORG	Orange Blue Purple Gray White Black Brown Red Orange Blue Green Brown Red Orange Brown Red Orange Brown Red Orange Brown Red Orange Brown Blue Orange	Shield Shield 0.2mm²	

Motor wiring table YK250XC(H), YK350XC(H), YK400XC(H), YK500XC, YK600XC, YK700XC, YK800XC, YK1000XC


Signa	l	Color	Connection	No.	Connector
Resolver	\$2 \$4 \$1 \$3 R1	Yellow - Blue - Red - Black - White -		- 1 - 2 - 3 - 4 - 5	XP,YP,ZP,RP
	R2 SHIELD	Green -		- 6 - 7	
Motor	V W	Red - White - Black -		- 1 - 2 - 3	XM, YM, ZM, RM
	PE	Yellow/Green		- 1	Round terminal
Brake	BK BK	Yellow -		- 1 - 2	ZBK (Z-axis motor only)

Origin sensor wiring table

Signal	Color	Connection	No.	Connector
+24V	Brown -		- 1	
ORG	Black -		- 2	XORG, YORG, RORG
0V	Blue -		- 3	

Revision History

A manual revision code appears as a suffix to the catalog number on the front cover of the manual.



The following table outlines the changes made to the manual during each revision. Page numbers refer to the previous revision.

Revision code	Date	Revised content
01	April 2010	Original production